

## **USING THE HIGHWAY SAFETY RESEARCH CENTER CHILD RESTRAINT RECALL LIST**

**Last Revisions – Newer Model List: February 5, 2010**

**Older Model List: December 22, 2009**

### **About Child Restraints and Recalls**

It is very important to pay attention to recall notices and for parents to check if their seats are safe to use or if they need to be repaired or replaced. Recalls can be issued for any failure to meet Federal Motor Vehicle Safety Standard 213 established and enforced by the National Highway Traffic Safety Administration (NHTSA). Many recalls are issued due to reasons related to the crashworthiness of the child restraint, but some recalls are for deviations from the standards relating to labeling requirements, flammability of the upholstery or padding, or for parts that may come loose and pose a choking hazard.

Child restraints (CRs) are required to have a label indicating the manufacturer, model information, and date of manufacture. CRs should not be used if the labels are missing such that the manufacturer, model name, number, and date of manufacture cannot be determined.

Child restraint manufacturers have supplied registration cards with each new seat since 1993. It is important for the user to complete the registration card and send it to the manufacturer for quick notification in the event of a recall or safety notification. If the card for a restraint has been lost, it can be registered by contacting the manufacturer through the phone numbers provided in the instructions and on the label on the seat.

Some recall notices are related to problems that do not make the restraints unsafe in a crash, but all problems should be corrected. Phone numbers are provided on the recall list when a corrective action can be taken. The manufacturer should be able to advise the parent whether to continue using the current restraint or to obtain another one until the problem can be corrected.

In cases where the manufacturer has gone out of business or discontinued replacement programs, parents are advised to destroy the seat and use another one. Unsafe seats should NOT be thrown in the trash where they can be picked up and used by others. Discarded seats should be taken apart and stripped of upholstery, padding and straps and then destroyed by having them crushed to prevent others from using them.

To report any suspected child restraint or vehicle safety defects, call the National Highway Traffic Safety Administration Auto Safety Hotline at 888-327-4236.

### **About Older Child Restraints and Recalls**

Child restraints manufactured before 1981 were not required to be crash tested and must not be used. Most child passenger safety advocates recommend that CRs older than ten years should be replaced by a new one. Note that some manufacturers and safety advocates recommend replacing CRs before 10 years and some child restraints are stamped with an expiration date. Parents and other caregivers are encouraged to contact the child restraint manufacturer for model specific recommendations.

Older models, those manufactured since 1981, are included as a part of the HSRC recall list because parents and other care givers will sometimes choose to use child restraints older than ten years even though it goes against the recommendations of most organizations and advocates. Knowing that a particular model is under recall, and if the defect can be corrected, should help to encourage the care giver to destroy the older CR and obtain a new one.

## About the HSRC Recall List

The UNC Highway Safety Research Center (HSRC) child restraint (CR) recall list identifies recalls and safety notifications for child restraint systems known by the HSRC at the time it is published. This list is updated by HSRC as soon as possible after recall notifications are announced and after the information can be verified for completeness and accuracy. To be notified via email whenever the HSRC Recall List is updated, go to [www.hsrc.unc.edu/recalls](http://www.hsrc.unc.edu/recalls) and click on the link to "Sign up for automatic email notification of updates to the HSRC recall list."

The HSRC recall list is formatted in a relatively compact format without much detail, but does serve to indicate if a particular model has been recalled. Users of this list are encouraged to obtain more detailed information about recent recalls through the "Most Recent Car Seat Recall Announcements and Notices" page of the HSRC Recall List website. Users of this (or any other) recall list should remind parents/caregivers to contact the CR manufacturer to be certain whether or not a particular CR is affected by any recalls.

The HSRC recall list is formatted with older models being separated from newer models. Recalls for models of child restraints where most or all of the effected units are 10 years old or older appear at the end of the list. A separate index for the older models precedes the list. The listing of older models with recalls will only be updated as "newer" models get to be old enough to be moved to the "older" models list.

The index listing numbers and page numbers for the older models section will stay the same until the older model section is updated or otherwise revised. Programs that make multiple copies of the list, e. g., for use at clinics or permanent checking stations, should only have to make copies of the older model section when it is revised regardless of how often the main (newer model) section is revised.

## Instructions for Using the PDF Version of the HSRC Recall List

Find the manufacturer, model name, model number, and date of manufacture on the label of the child restraint itself. Using this information:

1. Look to see if the manufacturer and model name and/or model number are listed in the index\*. **Child restraints under recall are listed in the index by both model name and model number.** Each entry on the list and in the index is assigned a "List #" based on its location in the list. The list is alphabetized by manufacturer and model name. List #'s for individual models will change in subsequent lists as models are added to or removed from the list.
2. If that model name or model number is listed in the index, note the "List # (number)" and use the List # to locate the recall information for that model. Once located, check to see if the date range for the recall includes the date of manufacture listed on the label of the child restraint.
3. If the restraint is included in the recall, the CR manufacturer should be contacted for verification of the recall and steps to take to correct the problem.
4. If the manufacturer has gone out of business or discontinued their repair or replacement program, the CR should be destroyed after a replacement restraint is obtained.
5. If the restraint is not included in the recall, inform the parent of this but still refer the parent to the manufacturer for verification of the restraint's recall status and to make sure it is registered with the manufacturer in case there is a recall issued on it in the future.

\*Note that Dorel Juvenile Group (DJG) products are indexed under each individual product line (Alpha Elite, Beatrix Potter, Cosco, Eddie Bauer, Maxi-Cosi, and Safety 1st) as well as under the broader "Dorel" label.

For further information, contact:

Bill Hall

The University of North Carolina Highway Safety Research Center  
CB# 3430, Chapel Hill, NC 27599  
919-962-2202 or (in NC) 800-672-4527 or [bill\\_hall@unc.edu](mailto:bill_hall@unc.edu)

The following lists identify recalls and safety notifications for child restraints (CRs) known by the UNC Highway Safety Research Center (HSRC) as of February 5, 2010. This list is updated by HSRC as soon as possible after recall notifications are announced. Updated versions are available on-line at [www.hsrc.unc.edu](http://www.hsrc.unc.edu) or by phone at 919-962-2202 or 800-672-4527 (in NC). The most recent addition(s) to the list is/are denoted by ">>".

CRs are required to have labels indicating the manufacturer, model name and number, and date of manufacture. Model names and numbers are listed for most of the recalls. Model numbers followed by one or more "x" should be read as "model numbers beginning with." If the label is missing on your CR, contact the manufacturer to see if it can be identified through other information. **A CR should not be used if its recall status cannot be determined because the model name, model number, date of manufacture or manufacturer is not available.**

CRs manufactured before 1981 were not required to be crash tested and must not be used. Most child passenger safety advocates recommend that CRs older than ten years should be replaced by a new one. Note that some manufacturers and safety advocates recommend replacing CRs before 10 years. **Models older than ten years and under recall are included on a separate list with a separate index.** The index for older models can be found following the last page of the "Models Less Than 10 Years Old" recall list and the list of older models with recalls follows the second index. **The "Models At Least 10 Years Old" list was last revised December 22, 2009.**

Some of the recalls/notifications for CRs on this list may be more or less date- or lot-specific than what is listed. More detailed information should be obtained through the manufacturer and **it is the manufacturer who can and should make the final determination if a specific CR is subject to recall.**

Some of the recall notices are related to problems that do not make the seats unsafe in a crash, but **all problems should be corrected.** Phone numbers are provided when a corrective action can be taken. The manufacturer should advise you whether to continue using your current CR or to obtain another one until the problem can be corrected.

**In cases where the manufacturer has gone out of business or discontinued replacement programs, you are advised to destroy the CR and obtain and use another one as soon as possible.** Do not throw unsafe models in the trash where they can be picked up and used by others. Discarded CRs should be destroyed by having them crushed. At the least, they should be taken apart and stripped of upholstery, padding and straps to prevent others from using them.

To report any suspected safety seat or vehicle safety defects, contact the National Highway Traffic Safety Administration Auto Safety Hotline: (888) 327-4236.

## CHILD RESTRAINTS LESS THAN 10 YEARS OLD

### Index of Recalls and Safety Notifications

Model numbers (noted by a "#") and model names for child restraints under recall are followed by their list number (that corresponds to the "List #" for each listing). Model numbers followed by an "x" should be read as "model numbers beginning with." If the model # is not found, check the model name also. Model #'s are not available for all model names. **Note:** Dorel Juvenile Group products are indexed under each individual product line (Alpha Elite, Beatrix Potter, Cosco, Eddie Bauer, Maxi-Cosi, and Safety 1<sup>st</sup>) as well as under "Dorel."

|  |  |   |
|--|--|---|
| <p><b>Alcot</b><br/>ALL MODELS ..... 1</p> <p><b>All Our Kids</b><br/>ALL MODELS ..... 2</p> <p><b>Alpha Elite (Dorel)</b><br/># 22331 BLA ..... 3, 4<br/># 22332 RLA ..... 3, 4<br/>Comfort Infant Seat ..... 3, 4</p> <p><b>American Motors</b><br/>ALL MODELS ..... 5</p> <p><b>Baby Trend</b><br/># 6400 ..... 7<br/># 6439 ..... 6<br/># 6448 ..... 6</p> | <p># 6481 ..... 6<br/>Rigid Latch-Loc ..... 6<br/>Rigid Latch-Loc Base ..... 7</p> <p><b>Babyhood Industries</b><br/>ALL MODELS ..... 8</p> <p><b>Basic Comfort</b><br/>ALL MODELS ..... 9</p> <p><b>Beatrix Potter (Dorel)</b><br/># 02-620-xxx ..... 10<br/># 02-621-SAL ..... 10<br/>Designer 22 ..... 10</p> <p><b>Bolform</b><br/>ALL MODELS ..... 11</p> | <p><b>Britax</b><br/># E902228 ..... 12<br/># E9031 ..... 26, 27<br/># E906 ..... 23<br/># E9L06 ..... 23<br/># E9L07 ..... 29<br/># E9L14 ..... 14, 15, 16<br/># E9L20 ..... 15, 16<br/># E9L30 ..... 20, 21, 22<br/># E9L32 ..... 28<br/># E9L3998 ..... 24<br/># E9L39x ..... 25<br/># E9L47 ..... 17<br/># E9L5490 ..... 19<br/># E9L54E7 ..... 18, 19<br/># E9L54H6 ..... 18<br/># E9L54H7 ..... 18<br/># E9L54M6 ..... 18</p> |
|--|--|---|

|                                 |                    |                             |        |   |                    |
|---------------------------------|--------------------|-----------------------------|--------|---|--------------------|
| <b>Britax (Continued)</b>       |                    | # I420 MAR . . . . .        | 40     | # 93443 . . . . .                       | 47                 |
| # E9L57 . . . . .               | 13                 | Infant Car Seat . . . . .   | 40     | # 93446 . . . . .                       | 53                 |
| # E9L80 . . . . .               | 15, 16             |                             |        | # 93504 . . . . .                       | 53                 |
| # E9W06 . . . . .               | 23                 | <b>Cosco</b>                |        | # 93514 . . . . .                       | 47, 52             |
| Advantage . . . . .             | 12                 | # 02-331 . . . . .          | 41     | Alpha Omega . . . . .                   | 41, 42, 43         |
| Boulevard . . . . .             | 13                 | # 02-332 . . . . .          | 41     | Alpha Omega Elite . . . . .             | 42                 |
| Companion . . . . .             | 14, 15, 16         | # 02-531 . . . . .          | 41     | Designer 22 . . . . .                   | 44                 |
| Decathlon . . . . .             | 17                 | # 02-533 . . . . .          | 41     | DreamRide . . . . .                     | 45                 |
| Frontier . . . . .              | 18, 19             | # 02-537 . . . . .          | 41     | Hi Back Booster . . . . .               | 46                 |
| Husky . . . . .                 | 20, 21             | # 02014 . . . . .           | 52     | High Rise Booster . . . . .             | 48                 |
| Marathon . . . . .              | 22, 23             | # 02015 . . . . .           | 52     | Infant Car Seat . . . . .               | 49                 |
| Regent . . . . .                | 24, 25             | # 02019 . . . . .           | 52     | Regal Ride . . . . .                    | 50                 |
| Super Elite . . . . .           | 26, 27             | # 02084 . . . . .           | 52     | Touriva . . . . .                       | 51, 52, 53         |
| Traveller Plus . . . . .        | 28                 | # 02094 . . . . .           | 52     |   |                    |
| Wizard . . . . .                | 29                 | # 02114 . . . . .           | 52     | <b>Disney (Dorel)</b>                   |                    |
|                                 |                    | # 02332 . . . . .           | 43     | # 22-305 NAB . . . . .                  | 54                 |
| <b>Century</b>                  |                    | # 02409 . . . . .           | 46     | # 22-305 PPH . . . . .                  | 54                 |
| # 44612 . . . . .               | 32                 | # 02442 . . . . .           | 46, 47 | # 22-355 LBF . . . . .                  | 54                 |
| # 44622 . . . . .               | 31                 | # 02443 . . . . .           | 46, 47 | # 22-355 PWK . . . . .                  | 54                 |
| # 44630 . . . . .               | 31                 | # 02445 . . . . .           | 46     | # 22-627 AWF . . . . .                  | 54                 |
| # 44631 . . . . .               | 31                 | # 02448 . . . . .           | 46, 47 | Infant Car Seat . . . . .               | 54                 |
| # 44662 . . . . .               | 31                 | # 02449 . . . . .           | 46     |   |                    |
| # 44709 . . . . .               | 33                 | # 02450 . . . . .           | 46     | <b>Dodge [Integrated]</b>               |                    |
| # 45100 . . . . .               | 30                 | # 02480 . . . . .           | 46     | Caravan . . . . .                       | 130, 131, 132, 133 |
| # 45200 . . . . .               | 30                 | # 02495 . . . . .           | 46     | Grand Caravan . . . . .                 | 130, 131, 132, 133 |
| # 45600 . . . . .               | 30                 | # 02504 . . . . .           | 52     |   |                    |
| # 45700 . . . . .               | 30                 | # 02514 . . . . .           | 52, 53 | <b>Dorel</b>                            |                    |
| # 4662 . . . . .                | 32                 | # 02518 . . . . .           | 52     | # 02-331 (Cosco) . . . . .              | 41                 |
| Accel . . . . .                 | 30                 | # 02519 . . . . .           | 52, 53 | # 02-332 (Cosco) . . . . .              | 41                 |
| Bravo . . . . .                 | 31                 | # 02524 . . . . .           | 52, 53 | # 02-531 (Cosco) . . . . .              | 41                 |
| Encore . . . . .                | 32                 | # 02531 . . . . .           | 43     | # 02-533 (Cosco) . . . . .              | 41                 |
| Smart Move . . . . .            | 33                 | # 02533 . . . . .           | 43     | # 02-537 (Cosco) . . . . .              | 41                 |
|                                 |                    | # 02537 . . . . .           | 43     | # 02-555 (Cosco) . . . . .              | 41                 |
| <b>Chicco</b>                   |                    | # 02555 . . . . .           | 43     | # 02-620-xxx (Beatrix Potter) . . . . . | 10                 |
| # All . . . . .                 | 34                 | # 02584 . . . . .           | 52     | # 02-620-xxx (Safety 1st) . . . . .     | 112                |
| Cortina Travel System . . . . . | 34                 | # 02803 . . . . .           | 52     | # 02-621-SAL (Beatrix Potter) . . . . . | 10                 |
| Key Fit . . . . .               | 34                 | # 02806 . . . . .           | 52     | # 02-621-SAL (Safety 1st) . . . . .     | 112                |
| Key Fit 30 . . . . .            | 34                 | # 02821 . . . . .           | 52     | # 02014 (Cosco) . . . . .               | 52                 |
|                                 |                    | # 02825 . . . . .           | 52     | # 02015 (Cosco) . . . . .               | 52                 |
| <b>Childcare</b>                |                    | # 02935 . . . . .           | 52     | # 02019 (Cosco) . . . . .               | 52                 |
| ALL MODELS . . . . .            | 1                  | # 22-001FSM . . . . .       | 45     | # 02084 (Cosco) . . . . .               | 52                 |
|                                 |                    | # 22-297 . . . . .          | 48     | # 02094 (Cosco) . . . . .               | 52                 |
| <b>Chrysler [Aftermarket]</b>   |                    | # 22-298 . . . . .          | 48     | # 02114 (Cosco) . . . . .               | 52                 |
| ALL MODELS . . . . .            | 35                 | # 22-299 . . . . .          | 48     | # 02332 (Cosco) . . . . .               | 43                 |
|                                 |                    | # 22-300 CSF . . . . .      | 49     | # 02409 (Cosco) . . . . .               | 46                 |
| <b>Chrysler [Integrated]</b>    |                    | # 22-300 FZN . . . . .      | 49     | # 02409 (Eddie Bauer) . . . . .         | 64                 |
| Town and Country . . . . .      | 126, 127, 128, 129 | # 22-300 JJV . . . . .      | 49     | # 02442 (Cosco) . . . . .               | 46, 47             |
|                                 |                    | # 22-300 OSF . . . . .      | 49     | # 02442 (Eddie Bauer) . . . . .         | 64                 |
| <b>Collier-Keyworth</b>         |                    | # 22-300 THD . . . . .      | 49     | # 02443 (Cosco) . . . . .               | 46, 47             |
| ALL MODELS . . . . .            | 36                 | # 22-300 TWD . . . . .      | 49     | # 02443 (Eddie Bauer) . . . . .         | 64                 |
|                                 |                    | # 22-300-JOS GB1B . . . . . | 44     | # 02445 (Cosco) . . . . .               | 46                 |
| <b>Combi</b>                    |                    | # 22100 . . . . .           | 53     | # 02445 (Eddie Bauer) . . . . .         | 64                 |
| # 8065 . . . . .                | 38                 | # 22100x . . . . .          | 51     | # 02448 (Cosco) . . . . .               | 46, 47             |
| # 8074 . . . . .                | 38                 | # 22111x . . . . .          | 51     | # 02448 (Eddie Bauer) . . . . .         | 64                 |
| # 8086 . . . . .                | 38                 | # 22130x . . . . .          | 51     | # 02449 (Cosco) . . . . .               | 46                 |
| # 8087 . . . . .                | 39                 | # 22139MON . . . . .        | 50     | # 02449 (Eddie Bauer) . . . . .         | 64                 |
| # 8100 . . . . .                | 37                 | # 22150 . . . . .           | 42     | # 02450 (Cosco) . . . . .               | 46                 |
| # 8520 . . . . .                | 38                 | # 22155 . . . . .           | 42     | # 02450 (Eddie Bauer) . . . . .         | 64                 |
| Avatar . . . . .                | 37                 | # 22180 . . . . .           | 42     | # 02480 (Cosco) . . . . .               | 46                 |
| Centre . . . . .                | 38                 | # 22269 . . . . .           | 42     | # 02480 (Eddie Bauer) . . . . .         | 64                 |
| Shuttle . . . . .               | 39                 | # 93084 . . . . .           | 52     | # 02495 (Cosco) . . . . .               | 46                 |
|                                 |                    | # 93094 . . . . .           | 52     | # 02495 (Eddie Bauer) . . . . .         | 64                 |
| <b>Compass Baby</b>             |                    | # 93100x . . . . .          | 51     | # 02504 (Cosco) . . . . .               | 52                 |
| # I420 ARD . . . . .            | 40                 | # 93111x . . . . .          | 51     | # 02514 (Cosco) . . . . .               | 52, 53             |
| # I420 FUO . . . . .            | 40                 |                             |        |   |                    |

**Dorel (Continued)**

|                                       |        |   |            |                                     |            |
|---------------------------------------|--------|---|------------|-------------------------------------|------------|
| # 02518 (Cosco) .....                 | 52     | # 22-627 FRK (Eddie Bauer) .....        | 65         | Infant Car Seat (Disney) .....      | 54         |
| # 02519 (Cosco) .....                 | 52, 53 | # 22-627 KGS (Eddie Bauer) .....        | 65         | Infant Car Seat (Eddie Bauer) ..... | 65         |
| # 02524 (Cosco) .....                 | 52, 53 | # 22-627 SNW (Eddie Bauer) .....        | 65         | Infant Car Seat (Safety 1st) .....  | 116        |
| # 02531 (Cosco) .....                 | 43     | # 22-627 WAV (Safety 1st) .....         | 116        | Intera (Safety 1st) .....           | 115        |
| # 02533 (Cosco) .....                 | 43     | # 22-627 WPR (Eddie Bauer) .....        | 65         | Mico (Maxi-Cosi) .....              | 89, 90     |
| # 02537 (Cosco) .....                 | 43     | # 22-655 BYTE (Eddie Bauer) .....       | 65         | Regal Ride (Cosco) .....            | 50         |
| # 02555 (Cosco) .....                 | 43     | # 22100 (Cosco) .....                   | 53         | Touriva (Cosco) .....               | 51, 52, 53 |
| # 02584 (Cosco) .....                 | 52     | # 22100x (Cosco) .....                  | 51         | Touriva (Eddie Bauer) .....         | 66         |
| # 02803 (Cosco) .....                 | 52     | # 22111x (Cosco) .....                  | 51         | <b>Downunder</b>                    |            |
| # 02806 (Cosco) .....                 | 52     | # 22130x (Cosco) .....                  | 51         | ALL MODELS .....                    | 55         |
| # 02821 (Cosco) .....                 | 52     | # 22139MON (Cosco) .....                | 50         | <b>Eddie Bauer</b>                  |            |
| # 02825 (Cosco) .....                 | 52     | # 22150 (Cosco) .....                   | 42         | # 02409 .....                       | 64         |
| # 02870 (Eddie Bauer) .....           | 66     | # 22151 (Safety 1st) .....              | 110        | # 02442 .....                       | 64         |
| # 02871 (Eddie Bauer) .....           | 66     | # 22155 (Cosco) .....                   | 42         | # 02443 .....                       | 64         |
| # 02875 (Eddie Bauer) .....           | 66     | # 22180 (Cosco) .....                   | 42         | # 02445 .....                       | 64         |
| # 02935 (Cosco) .....                 | 52     | # 22269 (Cosco) .....                   | 42         | # 02448 .....                       | 64         |
| # 22-001FSM (Cosco) .....             | 45     | # 22331 BLA (Alpha Elite) .....         | 3, 4       | # 02449 .....                       | 64         |
| # 22-057 CLN (Safety 1st) .....       | 116    | # 22332 RLA (Alpha Elite) .....         | 3, 4       | # 02450 .....                       | 64         |
| # 22-057 DBY (Safety 1st) .....       | 116    | # 22450 (Safety 1st) .....              | 114        | # 02480 .....                       | 64         |
| # 22-057 HRT (Safety 1st) .....       | 116    | # 22451 (Safety 1st) .....              | 114        | # 02495 .....                       | 64         |
| # 22-057 LPH (Safety 1st) .....       | 116    | # 22452 (Safety 1st) .....              | 114        | # 02870 .....                       | 66         |
| # 22-085 DWA (Safety 1st) .....       | 116    | # 22453 (Safety 1st) .....              | 114        | # 02871 .....                       | 66         |
| # 22-085 LYN (Safety 1st) .....       | 116    | # 22455 (Safety 1st) .....              | 110        | # 02875 .....                       | 66         |
| # 22-095 RBK (Safety 1st) .....       | 116    | # 22460 (Safety 1st) .....              | 115        | # 22-625 xxx GB1B .....             | 62         |
| # 22-297 (Cosco) .....                | 48     | # 22480 (Safety 1st) .....              | 114        | # 22-627 CGT .....                  | 65         |
| # 22-298 (Cosco) .....                | 48     | # 22481 (Safety 1st) .....              | 114        | # 22-627 FRK .....                  | 65         |
| # 22-299 (Cosco) .....                | 48     | # 22630xxx (Eddie Bauer) .....          | 58, 59     | # 22-627 KGS .....                  | 65         |
| # 22-300 CSF (Cosco) .....            | 49     | # 22631xxx (Eddie Bauer) .....          | 58, 59     | # 22-627 SNW .....                  | 65         |
| # 22-300 FZN (Cosco) .....            | 49     | # 22740 (Eddie Bauer) .....             | 63         | # 22-627 WPR .....                  | 65         |
| # 22-300 JJV (Cosco) .....            | 49     | # 22750 (Eddie Bauer) .....             | 57         | # 22-655 BYTE .....                 | 65         |
| # 22-300 OSF (Cosco) .....            | 49     | # 22755 (Eddie Bauer) .....             | 57         | # 22630xxx .....                    | 58, 59     |
| # 22-300 THD (Cosco) .....            | 49     | # 22756 (Eddie Bauer) .....             | 57         | # 22631xxx .....                    | 58, 59     |
| # 22-300 TWD (Cosco) .....            | 49     | # 22757 (Eddie Bauer) .....             | 57         | # 22740 .....                       | 63         |
| # 22-300-JOS GB1B (Cosco) .....       | 44     | # 22770 (Eddie Bauer) .....             | 57         | # 22750 .....                       | 57         |
| # 22-305 NAB (Disney) .....           | 54     | # 93084 (Cosco) .....                   | 52         | # 22755 .....                       | 57         |
| # 22-305 PPH (Disney) .....           | 54     | # 93094 (Cosco) .....                   | 52         | # 22756 .....                       | 57         |
| # 22-322 HRR (Safety 1st) .....       | 116    | # 93100x (Cosco) .....                  | 51         | # 22757 .....                       | 57         |
| # 22-322 KDL (Safety 1st) .....       | 116    | # 93111x (Cosco) .....                  | 51         | # 22770 .....                       | 57         |
| # 22-322 KDL (Safety 1st) .....       | 116    | # 93443 (Cosco) .....                   | 47         | 3-in-1 .....                        | 56         |
| # 22-322 LXI (Safety 1st) .....       | 116    | # 93446 (Cosco) .....                   | 53         | Alpha Omega .....                   | 57         |
| # 22-322 MAI (Safety 1st) .....       | 116    | # 93504 (Cosco) .....                   | 53         | Alpha Omega Elite .....             | 57         |
| # 22-322 OLY (Safety 1st) .....       | 116    | # 93514 (Cosco) .....                   | 47, 52     | Comfort Infant Seat .....           | 58, 59     |
| # 22-322 PRS (Safety 1st) .....       | 116    | 3-in-1 (Eddie Bauer) .....              | 56         | Deluxe 3-in-1 .....                 | 60         |
| # 22-322 PTK (Safety 1st) .....       | 116    | Alpha Elite (Safety 1st) .....          | 109        | Deluxe Convertible .....            | 61         |
| # 22-325 COB (Safety 1st) .....       | 116    | Alpha Omega (Cosco) .....               | 41, 42, 43 | Designer 22 .....                   | 62         |
| # 22-325 PAC (Safety 1st) .....       | 116    | Alpha Omega (Eddie Bauer) .....         | 57         | Enspira .....                       | 63         |
| # 22-325 xxx GB1B (Safety 1st) .....  | 113    | Alpha Omega (Safety 1st) .....          | 110        | Hi Back Booster .....               | 64         |
| # 22-355 LBF (Disney) .....           | 54     | Alpha Omega Elite (Cosco) .....         | 42         | Infant Car Seat .....               | 65         |
| # 22-355 PWK (Disney) .....           | 54     | Alpha Omega Elite (Eddie Bauer) .....   | 57         | Touriva .....                       | 66         |
| # 22-371 (Eddie Bauer) .....          | 89     | Alpha Omega Elite (Safety 1st) .....    | 110        | <b>Evenflo</b>                      |            |
| # 22-371 HFL (Maxi-Cosi) .....        | 90     | Alpha Omega Elite (Safety 1st) .....    | 110        | # 264x .....                        | 73, 74     |
| # 22-371 JUC (Maxi-Cosi) .....        | 90     | Alpha Sport (Safety 1st) .....          | 111        | # 272x .....                        | 67         |
| # 22-371 LMD (Maxi-Cosi) .....        | 90     | Comfort Infant Seat (Alpha Elite) ..... | 3, 4       | # 273x .....                        | 67         |
| # 22-371 ORE (Maxi-Cosi) .....        | 90     | Comfort Infant Seat (Eddie Bauer) ..... | 58, 59     | # 3021769Z .....                    | 69         |
| # 22-371 PNG (Maxi-Cosi) .....        | 90     | Designer 22 (Beatrix Potter) .....      | 10         | # 3021854Z .....                    | 69         |
| # 22-372 (Eddie Bauer) .....          | 89     | Designer 22 (Cosco) .....               | 44         | # 317xx .....                       | 70         |
| # 22-372 TTH (Maxi-Cosi) .....        | 90     | Designer 22 (Eddie Bauer) .....         | 62         | # 320xx .....                       | 70         |
| # 22-380 LGA (Safety 1st) .....       | 116    | Designer 22 (Safety 1st) .....          | 112, 113   | # 359x .....                        | 73         |
| # 22-380 MSA (Safety 1st) .....       | 116    | Designer 22 (Safety 1st) .....          | 112, 113   | # 3604098 .....                     | 71         |
| # 22-515 (Eddie Bauer) .....          | 89     | DreamRide (Cosco) .....                 | 45         | # 378x .....                        | 72         |
| # 22-515 BLK (Maxi-Cosi) .....        | 90     | Enspira (Eddie Bauer) .....             | 63         | # 379x .....                        | 72         |
| # 22-625 xxx GB1B (Eddie Bauer) ..... | 62     | Enspira (Safety 1st) .....              | 114        |                                     |            |
| # 22-627 AWF (Disney) .....           | 54     | Hi Back Booster (Cosco) .....           | 46         |                                     |            |
| # 22-627 CGT (Eddie Bauer) .....      | 65     | Hi Back Booster (Eddie Bauer) .....     | 64         |                                     |            |
|                                       |        | High Rise Booster (Cosco) .....         | 48         |                                     |            |
|                                       |        | Infant Car Seat (Cosco) .....           | 49         |                                     |            |

|                                     |        |                      |            |                      |            |
|-------------------------------------|--------|----------------------|------------|----------------------|------------|
| <i>Evenflo (Continued)</i>          |        | # 8446L              | 84         | Lin Lih/MCP          |            |
| # 389x                              | 73     | # 8447               | 84         | ALL MODELS           | 88         |
| # 390                               | 68     | # 8447L              | 84         |                      |            |
| # 391                               | 68     | # 8448               | 84         | <b>Maxi-Cosi</b>     |            |
| # 397xx                             | 70     | # 8448L              | 84         | # 22-371             | 89         |
| # 398xx                             | 70     | # 8457               | 83, 84     | # 22-371 HFL         | 90         |
| # 468x                              | 67     | # 8458               | 83, 84     | # 22-371 JUC         | 90         |
| # 469x                              | 67     | # 8459               | 83, 84     | # 22-371 LMD         | 90         |
| # 476x                              | 67     | # 8460               | 83         | # 22-371 ORE         | 90         |
| # 477x                              | 67     | # 8462               | 83         | # 22-371 PNG         | 90         |
| # 478x                              | 67     | # 8463x              | 84         | # 22-372             | 89         |
| # 480x                              | 67     | # 8464               | 84         | # 22-372 TTH         | 90         |
| # 481x                              | 67     | # 8470               | 84         | # 22-515             | 89         |
| # 534                               | 68     | # 8471               | 83, 84     | # 22-515 BLK         | 90         |
| # 540xx                             | 70     | # 8472               | 83         | Mico                 | 89, 90     |
| # 548xx                             | 70     | # 8473               | 83         |                      |            |
| # 549xx                             | 70     | # 8474               | 83         | <b>Mercedes-Benz</b> |            |
| # 550xx                             | 70     | # 8476               | 83         | # B66868203          | 91         |
| # 552                               | 68     | # 8477               | 83         | # B66868204          | 91         |
| # 556xx                             | 70     | # 8478               | 83, 84     | # B66868209          | 91         |
| # 597xx                             | 70     | # 8487x              | 79         | Kiddy TopSafe        | 91         |
| # 598xx                             | 70     | # 8601               | 84         |                      |            |
| # 599xx                             | 70     | # 8602x              | 84         | <b>Mia Moda</b>      |            |
| Cozy Carry                          | 67     | # 8603M              | 84         | # 5000               | 92, 93     |
| Discovery                           | 68, 69 | # 8605x              | 84         | # 5001               | 92, 93     |
| Embrace                             | 70     | # 8607x              | 84         | # 5050               | 93         |
| First Choice                        | 71     | # 8608D              | 84         | # 5051               | 93         |
| Tribute                             | 72     | # 8609x              | 85         | # 5070               | 93         |
| Triumph                             | 73, 74 | # 8616x              | 85         | # 5071               | 93         |
|                                     |        | # 8629x              | 80         | # 5080               | 93         |
| <b>Fisher Price</b>                 |        | # 8630x              | 80         | # 5081               | 93         |
| ALL MODELS                          | 75     | # 8631x              | 80         | Viva                 | 92, 93     |
|                                     |        | # 8632x              | 80         | Viva Supreme         | 93         |
| <b>Ford [Aftermarket]</b>           |        | # 8635x              | 80         |                      |            |
| ALL MODELS                          | 76     | # 8639x              | 80         | <b>Peg Perego</b>    |            |
|                                     |        | # 8643x              | 85         | # 32MD41KN41         | 97         |
| <b>Ford [Integrated]</b>            |        | # 8645x              | 85         | # 35CR13BU13         | 97         |
| Windstar                            | 134    | # 8646x              | 85         | # 35CR13PL46         | 97         |
|                                     |        | # 8686x              | 79         | # 35CR24BU24         | 97         |
| <b>General Motors [Aftermarket]</b> |        | # 8689x              | 79         | # 35TL49KN53         | 97         |
| ALL MODELS                          | 77     | # 8C00x              | 80         | # 35TL53KN46         | 97         |
|                                     |        | # 8C01x              | 80         | # 61FG13ST53         | 97         |
| <b>Gerry</b>                        |        | # 8C02MRC2           | 81         | # 61FG53ST49         | 97         |
| ALL MODELS                          | 78     | # 8C02x              | 80         | # 61FG53ST64         | 97         |
|                                     |        | # 8C03x              | 80         | # 61ST13IC53         | 97         |
| <b>Graco</b>                        |        | # 8C04FRR            | 82         | # 61ST34IC53         | 97         |
| # 7493                              | 83     | # 8C04FRR2           | 82         | # 61ST48IC53         | 97         |
| # 7497                              | 83     | # 8C04x              | 80         | # AL33USL            | 96         |
| # 7499                              | 83     | # 8D01x              | 79         | # AL33USN            | 96         |
| # 8402                              | 84     | # 8D02x              | 79         | # AL34USL            | 96         |
| # 8402L                             | 84     | # 8D03x              | 79         | # AL34USN            | 96         |
| # 8403x                             | 84     | # 8D04x              | 79         | # CS00MU1            | 95, 96, 97 |
| # 841101                            | 83     | # 8D05x              | 79         | # CS00US1            | 95, 96     |
| # 841102                            | 83     | # 8D10x              | 79         | # CS00US8            | 95, 96     |
| # 841103                            | 83     | # C844342            | 84         | # IMCB00JA57RJ31JU31 | 94         |
| # 8412                              | 84     | CarGo                | 79         | # LN34S09            | 96         |
| # 841203                            | 83     | ComfortSport         | 80, 81, 82 | # LN34S10            | 96         |
| # 8412T02                           | 83     | SnugRide             | 83, 84, 85 | # LV34USL            | 96         |
| # 8433x                             | 80     |                      |            | # LV34USN            | 96         |
| # 8442x                             | 84     | <b>International</b> |            | # ST33USL            | 96         |
| # 8443                              | 84     | ALL MODELS           | 86         | # ST33USN            | 96         |
| # 8443L                             | 84     |                      |            | # ST38USL            | 96         |
| # 8444                              | 84     | <b>Kolcraft</b>      |            | # ST38USN            | 96         |
| # 8444L                             | 84     | ALL MODELS           | 87         | Jacadi               | 94         |
| # 8446                              | 84     |                      |            | Primo Viaggio        | 95, 96     |

|   |                    |   |          |
|---|--------------------|---|----------|
| <b>Peg Perego (Continued)</b>               |                    | Alpha Omega . . . . .                       | 110      |
| Primo Viaggio SIP 30/30 . . . . .           | 97                 | Alpha Omega Elite . . . . .                 | 110      |
| <b>Playskool</b>                            |                    | Alpha Sport . . . . .                       | 111      |
| ALL MODELS . . . . .                        | 98                 | Designer 22 . . . . .                       | 112, 113 |
| <b>Plymouth [Integrated]</b>                |                    | Enspira . . . . .                           | 114      |
| Grand Voyager . . . . .                     | 135, 136, 137, 138 | Infant Car Seat . . . . .                   | 116      |
| Voyager . . . . .                           | 135, 136, 137, 138 | Intera . . . . .                            | 115      |
| <b>Pride Trimble/Virco</b>                  |                    | <b>Snug Seat</b>                            |          |
| ALL MODELS . . . . .                        | 99                 | # 200-1000 . . . . .                        | 117      |
| <b>Questor</b>                              |                    | # 600-1000 . . . . .                        | 118      |
| ALL MODELS . . . . .                        | 100                | # E9L32 . . . . .                           | 119      |
| <b>Recaro</b>                               |                    | Gorilla . . . . .                           | 117      |
| # 330.00.xxx . . . . .                      | 105                | Spelcast . . . . .                          | 118      |
| # 330.01.xxx . . . . .                      | 105                | Traveller Plus . . . . .                    | 119      |
| # 331.00.xxx . . . . .                      | 101, 102, 103, 104 | <b>Strolee</b>                              |          |
| # 331.01.xxx . . . . .                      | 103                | ALL MODELS . . . . .                        | 120      |
| Como . . . . .                              | 101, 102, 103      | <b>Team-Tex</b>                             |          |
| Signo . . . . .                             | 104, 105           | # 374099 . . . . .                          | 121      |
| <b>Renolux (FBS)</b>                        |                    | # 374199 . . . . .                          | 122      |
| ALL MODELS . . . . .                        | 106                | Babyride . . . . .                          | 121, 122 |
| <b>Safeline Kids (see Triple Play also)</b> |                    | <b>Triple Play (see Safeline Kids also)</b> |          |
| # 2003 . . . . .                            | 107                | # 4002 . . . . .                            | 123      |
| # 2240 . . . . .                            | 108                | Sit'n'Stroll . . . . .                      | 123      |
| Sit'n'Stroll . . . . .                      | 107, 108           | <b>TRW</b>                                  |          |
| <b>Safety 1st (Dorel)</b>                   |                    | ALL MODELS . . . . .                        | 124      |
| # 02-620-xxx . . . . .                      | 112                | <b>XSCi</b>                                 |          |
| # 02-621-SAL . . . . .                      | 112                | Pioneered ACIS . . . . .                    | 125      |
| # 22-057 CLN . . . . .                      | 116                |   |          |
| # 22-057 DBY . . . . .                      | 116                |   |          |
| # 22-057 HRT . . . . .                      | 116                |   |          |
| # 22-057 LPH . . . . .                      | 116                |   |          |
| # 22-085 DWA . . . . .                      | 116                |   |          |
| # 22-085 LYN . . . . .                      | 116                |   |          |
| # 22-095 RBK . . . . .                      | 116                |   |          |
| # 22-322 HRR . . . . .                      | 116                |   |          |
| # 22-322 KDL . . . . .                      | 116                |   |          |
| # 22-322 LXI . . . . .                      | 116                |   |          |
| # 22-322 MAI . . . . .                      | 116                |   |          |
| # 22-322 OLY . . . . .                      | 116                |   |          |
| # 22-322 PRS . . . . .                      | 116                |   |          |
| # 22-322 PTK . . . . .                      | 116                |   |          |
| # 22-325 COB . . . . .                      | 116                |   |          |
| # 22-325 PAC . . . . .                      | 116                |   |          |
| # 22-325xxxGB1B . . . . .                   | 113                |   |          |
| # 22-380 LGA . . . . .                      | 116                |   |          |
| # 22-380 MSA . . . . .                      | 116                |   |          |
| # 22-627 WAV . . . . .                      | 116                |   |          |
| # 22151 . . . . .                           | 110                |   |          |
| # 22450 . . . . .                           | 114                |   |          |
| # 22451 . . . . .                           | 114                |   |          |
| # 22452 . . . . .                           | 114                |   |          |
| # 22453 . . . . .                           | 114                |   |          |
| # 22455 . . . . .                           | 110                |   |          |
| # 22460 . . . . .                           | 115                |   |          |
| # 22480 . . . . .                           | 114                |   |          |
| # 22481 . . . . .                           | 114                |   |          |
| Alpha Elite . . . . .                       | 109                |   |          |

| List # | Manufacturer Model Name       | Model # ("X" = more numbers or letters follow) | Customer Assistance   | Mfg Date Problem Type and Consumer Action   |
|--------|-------------------------------|--|---|---|
| 1)     | <b>Alcot (Childcare)</b>      |  | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i> |   |
| 2)     | <b>All Our Kids</b>           |  | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i> |   |
|        | <b>Alpha Elite (Dorel)</b>    |  | <b>Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141<br/>www.djgusa.com</b>  |   |
| 3)     | Comfort Infant Seat           | 22331 BLA,<br>22332 RLA                        | 07/26/05-<br>02/28/06   | Trim screws on handle can loosen resulting in a potential choking hazard. Contact mfg. at 877-229-1374 for free repair kit. Make sure the handle trim screws are tight and continue to use the existing seat while waiting to receive and install the repair kit.   |
| 4)     | Comfort Infant Seat           | 22331 BLA,<br>22332 RLA                        | 07/26/05-<br>02/28/06   | Some consumers have experienced difficulty installing the base in certain vehicles. Dorel will replace the original version of the base at no charge to the customer. Contact mfg. at 877-229-1374 to determine eligibility for a replacement base.   |
| 5)     | <b>American Motors</b>        |  | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i> |   |
|        | <b>Baby Trend</b>             |  | <b>800-328-7363 - www.babytrend.com</b>   |   |
| 6)     | Rigid Latch-Loc               | 6439, 6448, 6481                               | 05/14/07-<br>04/01/08   | Incorrect steel used on the latch connector can crack and allow the child seat base to detach from the vehicle's latch anchors during a severe crash. Contact mfg. for a replacement base. Install with vehicle seat belt until base is replaced.   |
| 7)     | Rigid Latch-Loc Base          | 6400   | 05/14/07-<br>04/01/08   | Incorrect steel used on the latch connector can crack and allow the child seat base to detach from the vehicle's latch anchors during a severe crash. Contact mfg. for a replacement base. Install with vehicle seat belt until base is replaced.   |
| 8)     | <b>Babyhood Industries</b>    |  | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i> |   |
| 9)     | <b>Basic Comfort</b>          |  | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i> |   |
|        | <b>Beatrix Potter (Dorel)</b> |  | <b>Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141<br/>www.djgusa.com</b>  |   |
| 10)    | Designer 22                   | 02-621-SAL, 02-620-xxx                         | 01/03/02-<br>02/13/02   | Plastic handle can unexpectedly release from the carrying position when used as a carrier. Does not affect safety as a child restraint. Contact mfg. for repair kit.  |
| 11)    | <b>Bolform Corp.</b>          |  | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i> |   |
|        | <b>Britax</b>                 |  | <b>888-427-4829 / 704-409-1700 - www.britaxusa.com</b>  |   |
| 12)    | Advantage                     | E902228  | 03/05/01-<br>07/26/01   | One of the tether brackets of affected seats may separate from the tether attachment point. Contact mfg. for repair kit.  |
| 13)    | Boulevard                     | E9L57  | 03/01/06-<br>08/01/06   | Top tether hook can open during a crash allowing the restraint to change from an upright to a reclined position. Owners are being advised to discontinue use of the top tether when the child reaches 50 lbs. Contact mfg. for replacement labels.  |
| 14)    | Companion                     | E9L14  | 10/31/03-<br>06/06/04   | One or both of two tabs on the bottom of the carrier may not be properly seated and may allow the carrier to rotate in the base too far in a crash. Correct/incorrect assembly can be determined by visual examination. Call mfg. for replacement info. Affected units may be installed without the base until receiving a replacement. |

| List # | Manufacturer | Model # ("X" = more numbers or letters follow) | Customer Assistance |                                  |
|--------|--------------|--|---------------------|----------------------------------|
|        | Model Name   |  | Mfg Date            | Problem Type and Consumer Action |

**Britax (continued)**

|     |                |   |                   |   |
|-----|----------------|---|-------------------|---|
| 15) | Companion      | E9L14, E9L20, E9L80                               | Pre-11/01/07      | User Guide Update - NOT A RECALL: Britax has updated instructions regarding adjustment of the buckle strap position and maximum height for infant carrier use. The inner buckle strap position should be used for infants weighing less than 11 pounds. A child has exceeded the height limit for the Companion when the top of the head is less than one inch from the top of the child restraint or the child's height exceeds 30 inches (76 cm). Contact mfg for updated user guide and labels |
| 16) | Companion      | E9L14, E9L20, E9L80                               | All               | Consumer Advisory - NOT A RECALL: Britax advises that the user should adjust the carrier handle so that it is completely down and behind the carrier after installation in the vehicle with or without the base assembly. Contact mfg. for additional info.   |
| 17) | Decathlon      | E9L47   | 02/12/05-07/31/07 | Under certain circumstances the harness adjuster housing may separate from the child restraint shell and allow the adjuster to move out of position. If this happens caregivers may experience difficulty adjusting the harness. Call mfg. for repair info.   |
| 18) | Frontier       | E9L54E7, E9L54H6, E9L54H7, E9L54M6                | 04/01/08-09/14/08 | Harness straps may become detached from the metal yoke on the back of the seat if they are loosened one strap at a time with excessive force. Contact mfg. for repair kit.  |
| 19) | Frontier       | E9L5490   | 04/01/08-09/17/08 | Harness straps may become detached from the metal yoke on the back of the seat if they are loosened one strap at a time with excessive force. Contact mfg. for repair kit.  |
| 20) | Husky          | E9L30   | 08/01/02-12/31/03 | Head excursions higher than allowed by FMVSS 213 could result when installed as instructed with a long/serpentine belt path. Contact mfg. for replacement labels advising the use of an alternative short belt path.  |
| 21) | Husky          | E9L30   | Pre-07/24/04      | The adjuster strap may slip within the metal buckle that controls the tightness of the shoulder harness and may allow the harness to loosen. Contact mfg. for repair kit.   |
| 22) | Marathon       | E9L06   | Pre-07/24/04      | The adjuster strap may slip within the metal buckle that controls the tightness of the shoulder harness and may allow the harness to loosen. Contact mfg. for repair kit.   |
| 23) | Marathon       | E9L06, E9W06, E906 with top tether lot # KGR 01 A | 05/23/06-07/28/06 | The top tether hook may open and have the potential to release from the tether anchor if the child exceeds 50 pounds. Contact mfg. for repair kit.  |
| 24) | Regent Classic | E9L3998   | 12/18/06-01/18/07 | Affected seats were produced with an incorrect airbag warning label attached to the cover. Contact mfg. to receive a free replacement cover.  |
| 25) | Regent         | E9L39x  | 11/10/05-06/18/07 | Consumer Advisory/Product Update - NOT A RECALL: Britax has modified the Regent and revised the installation instructions. Contact mfg. to receive a free product update kit that includes a revised user guide, replacement belt-routing label, a longer LATCH connector strap, and adhesive slip resistant strips.  |
| 26) | Super Elite    | E9031   | 04/25/01-02/15/02 | Harness may allow too much forward head movement. Contact mfg. to receive a free replacement harness system.  |
| 27) | Super Elite    | E9031   | 04/01/01-08/31/02 | Harness adjuster tab may begin to stick after prolonged use. Harness may loosen if it sticks in the open position. Contact mfg. for repair kit and installation instructions.   |
| 28) | Traveller Plus | E9L32 (Mfg. by Britax for Snug Seat)              | Pre-07/24/04      | The adjuster strap may slip within the metal buckle that controls the tightness of the shoulder harness and may allow the harness to loosen. Contact mfg. for repair kit.   |
| 29) | Wizard         | E9L07   | Pre-07/24/04      | The adjuster strap may slip within the metal buckle that controls the tightness of the shoulder harness and may allow the harness to loosen. Contact mfg. for repair kit.   |

**Century Products****800-837-4044 / 216-468-2000 - [www.gracobaby.com](http://www.gracobaby.com)**

|     |        |                            |                   |   |
|-----|--------|----------------------------|-------------------|---|
| 30) | Accel  | 45100, 45200, 45600, 45700 | 04/09/01-05/10/01 | Harness adjustment lock may allow webbing to slip during a serious crash when used in the forward facing mode for some models and lot codes. Call Century at 1-800-575-6097 for replacement info. |
| 31) | Bravo  | 44622, 44630, 44631, 44662 | 04/09/01-05/10/01 | Harness adjustment lock may allow webbing to slip during a serious crash when used in the forward facing mode for some models and lot codes. Call Century at 1-800-575-6097 for replacement info. |
| 32) | Encore | 44612, 4662                | 04/09/01-05/10/01 | Harness adjustment lock may allow webbing to slip during a serious crash when used in the forward facing mode for some models and lot codes. Call Century at 1-800-575-6097 for replacement info. |

| <i>List #</i>     | <i>Manufacturer Model # ("X" = more numbers or letters follow)</i> | <i>Customer Assistance</i>                       |
|-------------------|--|--|
| <i>Model Name</i> | <i>Model #</i>   | <i>Mfg Date Problem Type and Consumer Action</i> |

**Century (continued)**

- 33) Smart Move 44709 04/09/01-05/10/01 Harness adjustment lock may allow webbing to slip during a serious crash when used in the forward facing mode for some models and lot codes. Call Century at 1-800-575-6097 for replacement info.

**Chicco****800-807-8817 / 877-424-4226 - [www.chiccousa.com](http://www.chiccousa.com)**

- 34) Key Fit All 02/26/08-03/17/08 Recall applies only to bases manufactured between 2/26/2008 and 3/17/2008. When installed with LATCH, the webbing used to tighten the base can slip through the adjustment lock. Bases with serial number is between 08 02 26 (February 26, 2008) and 08 03 17 (March 17, 2008) are covered by this recall. Contact mfg. for replacement base. Install the base with the vehicle seat belts until replacement base is obtained.
- Key Fit 30  
Cortina Travel Systems  
BASES ONLY

- 35) **Chrysler** *REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY & REPLACE*

- 36) **Collier-Keyworth** *REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY & REPLACE*

**Combi USA****800-992-6624 / 803-548-6633 - [www.combi-intl.com](http://www.combi-intl.com)**

- 37) Avatar 8100 11/12/03-05/07/04 Lower latch anchorage does not meet dynamic test requirements of FMVSS 213. Contact mfg. for free in-home repair kit and instructions. Affected models should be installed with the vehicle seat belt. Do not use the seat with the latch until repairs are made.
- 38) Centre ST 8065 10/19/05-12/15/07 The car seat could potentially become separated from its base in a crash. Mfg. recommends that the car seat be used without the base until it has been fixed. Contact mfg. for free retrofit kit. Also affected are travel systems (# 4400, 4515, and 4520) that contain the Centre and Shuttle car seats.
- Centre DX 8074  
Centre EX 8086  
Centre ARB 8520
- 39) Shuttle 8087 10/19/05-12/15/07 The car seat could potentially become separated from its base in a crash. Mfg. recommends that the car seat be used without the base until it has been fixed. Contact mfg. for free retrofit kit. Also affected are travel systems (# 4400, 4515, and 4520) that contain the Centre and Shuttle car seats.

**Compass Baby****888-899-2229 - [www.compassbaby.com](http://www.compassbaby.com)**

- 40) Infant Car Seat 1420 ARD 05/07/06, The metal slide crotch anchor can become dislodged allowing excessive movement of the child and cracking of the plastic shell. This problem was discovered during testing by the manufacturer. There have been no reports of injuries and no calls from consumers regarding problems. Contact mfg. for free repair kit.  
1420 FUO  
1420 MAR

**Cosco (Dorel)****Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141 [www.djgusa.com](http://www.djgusa.com)**

- 41) Alpha Omega 02-331, 02-332, 02-531, 02-533, 02-537, 02-555. 11/17/00-01/10/01 Tether webbing could be cut and separate in a crash allowing excessive movement of the child. Contact mfg. for free repair kit.
- 42) Alpha Omega 22150, 22180, 22269 11/01/03-12/31/05 There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  
Alpha Omega 22155  
Elite
- >> 43) Alpha Omega 02332, 02531, 02533, 02537, 02555 01/01/00-09/30/01 Tether webbing does not conform to abrasion requirements of FMVSS 213. Contact mfg. for free repair kit.
- 44) Designer 22 22-300-JOS GB1B 08/19/03-10/20/04 Harness can loosen if not properly tightened. Contact mfg. for free repair kit. Parents should continue to use the seat while waiting to receive/install the repair kit but are advised to make sure that the seat is properly adjusted while in use. NOTE: Models involved were sold only as travel systems (with a stroller) and any line code other than GB1B in the model # is not included in the recall.

| <i>List #</i>                   | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i>  | <i>Customer Assistance</i>  |
|---------------------------------|--------------------------------|--|---|
|                                 |                                |  | <i>Mfg Date Problem Type and Consumer Action</i>  |
| <b><i>Cosco (continued)</i></b> |                                |  |   |
| 45)                             | DreamRide                      | 22-001FSM  | 12/01/03-04/28/04 Failed to meet back support angle requirements of FMVSS 213. Discontinue rear-facing use and use only as a car bed or request free replacement rear-facing child restraint from DJG. Contact mfg. for warning label and information.  |
| >>46)                           | Hi Back Booster                | 02409, 02442, 02443, 02445, 02448, 02449, 02450, 02480, 02495  | 01/01/00-09/30/01 Tether webbing does not conform to abrasion requirements of FMVSS 213. Contact mfg. for free repair kit.  |
| >>47)                           | Hi Back Booster                | 02442, 02443, 02448, 93443, 93514  | 03/15/02-08/01/02 UV stabilizer in harness webbing does not conform to requirements of FMVSS 213. Contact mfg. for free repair kit.   |
| 48)                             | High Rise Booster              | 22-297, 22-298, 22-299   | 10/01/03-10/31/03 Incorrect warning label stating it is for use forward facing for children under one year of age rather than OVER one year of age. Contact mfg. for free replacement label and instructions.   |
| 49)                             | Infant Car Seat                | 22-300 CSF, 22-300 FZN, 22-300 JJV, 22-300 OSF, 22-300 THD, 22-300 TWD   | 01/06/08-04/06/09 The child restraint carry handle can loosen and come off posing a fall hazard to infants. The safety as a child restraint is not affected. Do not use handle until repaired. Contact mfg. for free repair kit. NOTE: Only those models sold as a part of the Spirit and Sprint Travel Systems are affected. |
| 50)                             | Regal Ride                     | 22139MON   | 09/28/04-09/20/07 Elastic straps on padding can come loose and become accessible to the child allowing the child to loop the elastic strap around portions of his/her body. Contact mfg. for repair kit.  |
| 51)                             | Touriva                        | 22100x, 22111x, 22130x, 93100x, 93111x   | 09/28/04-09/20/07 Elastic straps on padding can come loose and become accessible to the child allowing the child to loop the elastic strap around portions of his/her body. Contact mfg. for repair kit.  |
| >>52)                           | Touriva                        | 02014, 02015, 02019, 02084, 02094, 02114, 02504, 02514, 02518, 02519, 02524, 02584, 02803, 02806, 02821, 02825, 02935, 93084, 93094, 93514 | 01/01/00-09/30/01 Tether webbing does not conform to abrasion requirements of FMVSS 213. Contact mfg. for free repair kit.  |
| >>53)                           | Touriva                        | 02514, 02519, 02524, 22100, 93446, 93504   | 03/15/02-08/01/02 UV stabilizer in harness webbing does not conform to requirements of FMVSS 213. Contact mfg. for free repair kit.   |

***Disney (Dorel)***

***Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141  
www.djgusa.com***

|     |                 |  |  |
|-----|-----------------|--|--|
| 54) | Infant Car Seat | 22-305 NAB, 22-305 PPH, 22-355 LBF, 22-355 PWK, 22-627 AWF | 01/06/08-04/06/09 The child restraint carry handle can loosen and come off posing a fall hazard to infants. The safety as a child restraint is not affected. Do not use handle until repaired. Contact mfg. for free repair kit. NOTE: Only those models sold as a part of the Propack Travel System are affected. |
|-----|-----------------|--|--|

***Downunder***

***REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY & REPLACE***

***Eddie Bauer (Dorel)***

***Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141  
www.djgusa.com***

|     |                               |                                   |  |
|-----|-------------------------------|-----------------------------------|--|
| 56) | 3-in-1                        | All Models                        | 11/01/03-12/31/05 There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  |
| 57) | Alpha Omega Alpha Omega Elite | 22750, 22755, 22756, 22757, 22770 | 11/01/03-12/31/05 There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  |
| 58) | Comfort Infant Seat           | 22630xxx, 22631xxx                | 07/26/05-02/28/06 Trim screws on handle can loosen resulting in a potential choking hazard. Contact mfg. at 877-229-1374 for free repair kit. Make sure the handle trim screws are tight and continue to use the existing seat while waiting to receive and install the repair kit. (The 22630 models are part of the 01726 Eddie Bauer Integrated Travel System.) |

| <i>List #</i>                         | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i>                                      | <i>Customer Assistance Mfg Date</i>  | <i>Problem Type and Consumer Action</i>  |
|---------------------------------------|--------------------------------|--|--|--|
| <b><i>Eddie Bauer (continued)</i></b> |                                |  |  |  |
| 59)                                   | Comfort Infant Seat            | 22630xxx, 22631xxx   | 07/26/05-02/28/06  | Some consumers have experienced difficulty installing the base in certain vehicles. Dorel will replace the original version of the base at no charge to the customer. Contact mfg. at 877-229-1374 to determine eligibility for a replacement base.  |
| 60)                                   | Deluxe 3-in-1                  | All Models   | 11/01/03-12/31/05  | There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  |
| 61)                                   | Deluxe Convertible             | All Models   | 11/01/03-12/31/05  | There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  |
| 62)                                   | Designer 22                    | 22-625 xxx GB1B  | 08/19/03-10/20/04  | Harness can loosen if not properly tightened. Contact mfg. for free repair kit. Parents should continue to use the seat while waiting to receive/install the repair kit but are advised to make sure that the seat is properly adjusted while in use. NOTE: Models involved were sold only as travel systems (with a stroller) and any line code other than GB1B in the model # is not included in the recall. |
| 63)                                   | Enspira                        | 22740  | 11/01/03-12/31/05  | There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  |
| >> 64)                                | Hi Back Booster                | 02409, 02442, 02443, 02445, 02448, 02449, 02450, 02480, 02495                              | 01/01/00-09/30/01  | Tether webbing does not conform to abrasion requirements of FMVSS 213. Contact mfg. for free repair kit.   |
| 65)                                   | Infant Car Seat                | 22-627 CGT, 22-627 FRK, 22-627 KGS, 22-627 SNW, 22-627 WPR, 22-655 BYTE                    | 01/06/08-04/06/09  | The child restraint carry handle can loosen and come off posing a fall hazard to infants. The safety as a child restraint is not affected. Do not use handle until repaired. Contact mfg. for free repair kit. NOTE: Only those models sold as a part of the Adventurer and Endeavor Travel Systems are affected.  |
| >> 66)                                | Touriva                        | 02870, 02871, 02875  | 01/01/00-09/30/01  | Tether webbing does not conform to abrasion requirements of FMVSS 213. Contact mfg. for free repair kit.   |
| <b><i>Evenflo</i></b>                 |                                |  | <b><i>800-525-2472 / 800-233-5921 / 800-490-7497 - www.evenflo.com</i></b> |  |
| 67)                                   | Cozy Carry                     | 272x, 273x, 468x, 469x, 476x, 477x, 478x, 480x, 481x                                       | ALL (11/01/01-08/31/02)  | Upgrade Kit - Not a Recall: For owners of Cozy Carry infant car seats to improve the performance of the detachable base in certain types of collisions. The kit is only for detachable bases with the words "Cozy Carry" on them. Visit www.cozycarry.com or call 800-582-6698 for free kit.   |
| 68)                                   | Discovery                      | 390, 391, 534, 552   | Pre-02/01/08   | Voluntary Safety Recall - Testing showed that the car seat could potentially become separated from its base in high impact side collisions. Contact mfg. for free supplemental dual-hook fastener for enhanced safety performance.   |
| 69)                                   | Discovery                      | 3021769Z, 3021854Z   | 02/04/08   | A small number of Discovery car seats may have shipped without complete assembly of the red release handle located on the back of the seat making it possible for the seat to separate from its base. Contact mfg. for replacement seat and base. Affected models can be used without the base while waiting for replacement.  |
| 70)                                   | Embrace                        | Begins with 317, 320, 397, 398, 540, 548, 549, 550, 556, 597, 598, 599                     | Pre-04/08/06   | When used as an infant carrier, the handle can unexpectedly release, causing the seat to rotate forward. Handle should not be used until the repair kit has been installed. Affected restraints can continue to be used as a car seat properly installed in a vehicle. Contact mfg. for a free repair kit.   |
| 71)                                   | First Choice                   | 3604098  | 01/16/09-09/29/09  | A label containing certain contact and certification information was inadvertently left off these car seats. Contact mfg. for a set of replacement labels.   |
| 72)                                   | Tribute                        | 378x, 379x   | 09/08/05-09/22/05  | Certain areas of the plastic shell may be prone to stress fractures. Call mfg. to receive a replacement seat.  |
| 73)                                   | Triumph                        | 264x, 359x, 389x   | 09/06/01-10/31/05  | Portions of the cloth cover can be pulled back exposing the foam liner in an area that is reachable by a child occupant. A child inside the seat may break off and potentially choke on a piece of the foam liner. Contact mfg. for repair kit.  |
| 74)                                   | Triumph                        | 264x   | 10/20/01-01/31/02  | Slide loop connectors in the harness may not be strong enough to fully secure the child in a crash. Call mfg. for repair kit.  |
| 75)                                   | <b><i>Fisher Price</i></b>     | <b><i>REFER TO OLDER MODELS LIST - ALL MODELS WITH RECALLS ARE OLDER THAN 10 YEARS</i></b> |  |  |

| List # | Manufacturer Model Name | Model # ("X" = more numbers or letters follow)  | Customer Assistance Mfg Date | Problem Type and Consumer Action   |
|--------|-------------------------|---|------------------------------|--|
| 76)    | <b>Ford</b>             |   |                              | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i>  |
| 77)    | <b>General Motors</b>   |   |                              | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i>  |
| 78)    | <b>Gerry</b>            |   |                              | <i>REFER TO OLDER MODELS LIST - ALL MODELS WITH RECALLS ARE OLDER THAN 10 YEARS</i>  |
|        | <b>Graco</b>            |   |                              | <b>800-345-4109 - <a href="http://www.gracobaby.com">www.gracobaby.com</a></b>   |
| 79)    | CarGo                   | 8487x, 8686x, 8689x, 8D01x, 8D02x, 8D03x, 8D04x, 8D05x, 8D10x   | 01/09/07-03/03/08            | An incorrect NHTSA Hotline telephone number appears on an information label affixed to the back of the seat. Contact mfg. for a replacement label.   |
| 80)    | ComfortSport            | 8629x, 8630x, 8631x, 8632x, 8635x, 8639x, 8C00x, 8C01x, 8C02x, 8C03x, 8C04x, 8433x  | 01/02/07-07/31/07            | Lower Anchorage belt may have been misrouted during assembly process. Use the vehicle seatbelt instead of LATCH to install affected models in the rear-facing position until it is inspected and, if necessary, corrected. Call mfg. or visit <a href="http://gracobaby.com">gracobaby.com</a> website for additional info.  |
| 81)    | ComfortSport            | 8C02MRC2  | 10/22/07                     | Seats were produced with foam thicker than specified and tested 1" thick foam. It is unclear as to what impact thicker foam will have on child seat safety. Call mfg. for seat replacement information.  |
| 82)    | ComfortSport            | 8C04FRR, 8C04FRR2   | 11/01/06-10/08/07            | Seats were equipped with a large supplemental "body pillow" that partially obscures the child airbag warning label on the seat pad. Graco will instruct users to discard the supplemental pillows since they are provided for comfort only. Contact mfg. for additional information.   |
| 83)    | SnugRide #s             | 7493, 7497, 7499, 841101, 841102, 841103, 841203, 8412T02, 8457, 8458, 8459, 8460, 8462, 8471, 8472, 8473, 8474, 8476, 8477, 8478 <i>See Note</i>   | 08/31/99-02/28/02            | May be missing 1 or 2 metal hooks and their retainer pins on the base of the carrier shell or the "U" shaped bars on the carrier shell that are used to attach the carrier to the base. If the hooks, pins or "U" bars are missing, the carrier may not be securely attached to the base and the carrier could detach from the base in the event of a sudden stop or crash. Call Graco to receive a free replacement seat or base. NOTE: All affected model numbers may also begin with the letter "A" and/or also be followed by letters. |
| 84)    | SnugRide #s             | 8402, 8402L, 8403x, 8412, 8442x, 8443, 8443L, 8444, 8444L, 8446, 8446L, 8447, 8447L, 8448, 8448L, 8457, 8458, 8459, 8463x, 8464, 8470, 8471, 8478, 8601, 8602x, 8603M, 8605x, 8607x, 8608D, C844342 | 03/01/02-03/08/03            | May have missing hardware used to attach the carrier to the base. Contact mfg. at 866-473-0163 or <a href="http://www.gracobaby.com">www.gracobaby.com</a> for inspection and repair information. All models can safely be installed without the base. [NOTE: The initial 03/12/03 recall campaign for this problem included models manufactured through 03/06/03. A recall extension announced 08/13/03 added models manufactured through 03/08/03.]  |
| 85)    | SnugRide                | 8609x, 8616x, 8643x, 8645x, 8646x   | 08/01/06-06/30/07            | The backing of the seat pad may pull away from the seams in an area reachable to the child occupant, exposing the pad filling and posing a potential choking hazard. Contact mfg. For repair kit.  |
| 86)    | <b>International</b>    |   |                              | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i>  |
| 87)    | <b>Kolcraft</b>         |   |                              | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i>  |
| 88)    | <b>Lin Lih/MCP Ent.</b> |   |                              | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i>  |

| <i>List #</i>            | <i>Manufacturer Model # ("X" = more numbers or letters follow)</i>  | <i>Customer Assistance</i>   |
|--------------------------|---|--|
| <i>Model Name</i>        | <i>Model #</i>  | <i>Mfg Date Problem Type and Consumer Action</i>   |
| <b>Maxi-Cosi (Dorel)</b> |   | <b>Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141<br/>www.djgusa.com</b>   |
| 89)                      | Mico 22-371, 22-372<br>Mico (base) 22-515   | 07/01/07-02/17/08 Attachment difficulties between the infant carrier and the base may lead to the carrier being improperly mounted to the base. Contact mfg. for replacement base.   |
| >> 90)                   | Mico 22-371 HFL, 22-371 JUC,<br>22-371 LMD, 22-371 ORE,<br>22-371 PNG, 22-372 TTH<br>Mico (base) 22-515 BLK   | 02/18/08-06/28/08 Attachment difficulties between the infant carrier and the base may lead to the carrier being improperly mounted to the base. Contact mfg. for repair kit. NOTE: This is an extension of an earlier recall.  |
| <b>Mercedes-Benz USA</b> |   | <b>800-367-6372 - www.mbusa.com</b>  |
| 91)                      | Kiddy TopSafe B66868203<br>(mfg. by B66868204<br>Sicartex) B66868209  | 03/01/03-11/30/03 Lower LATCH attachment may not be strong enough to hold in the event of a crash. Immediately replace with another model and return Kiddy Top seat to Mercedes-Benz dealer for refund. Install with vehicle seat belt until replacement is obtained. Contact Mercedes-Benz for further information.   |
| <b>Mia Moda</b>          |   | <b>866-642-6632 - www.miamodainc.com</b>   |
| 92)                      | Viva 5000 (seat), 5001 (base)   | 12/19/06-02/06/07 The lower anchor connector adjuster assembly may interfere with the connection of the infant carrier to the restraint base when installed using LATCH. Installation with seat belt is not affected. In addition, registration cards were not provided with the Viva or separately sold bases. Contact mfg. For repair kit and to register CR with mfg.   |
| 93)                      | Viva 5000 (seat), 5001 (base),<br>5050 (seat), 5051 (base),<br>5070 (seat), 5071 (base)   | 12/01/06-05/31/09 Sharp edges on the harness splitter plate can cut the harness. Also, the base could crack in a crash. Contact mfg. at 877-546-8437 for a full refund. <u>Mia Moda is urging parents/caregivers to discontinue use of the seat until it can be replaced.</u> According to Lerado/Mia Moda, there have been no injuries reported due to these problems and this is a voluntary precaution they are taking. |
|                          | Viva Supreme 5080 (seat), 5081 (base)   |  |
| <b>Peg Perego USA</b>    |   | <b>877-737-3468 / 219-482-8191 - www.perego.com</b>  |
| 94)                      | Jacadi IMCB00JA57RJ31JU31   | 07/01/07-03/14/08 The plastic adjustment cover of affected models could have exposed sharp edges that could cause cuts, scratches, or abrasions on the feet or legs of bare-footed infants. Does not affect safety as car seat. Contact mfg. For a free repair kit.  |
| 95)                      | Primo Viaggio CS00MU1, CS00US1,<br>CS00US8  | 02/01/01-06/10/01 The latch mechanism securing the seat to the base does not completely engage on a small number of seats due to improper positioning of the metal reinforcement bracket. Call mfg. for repair info. Note: Primo Viaggio infant seat sold separately and with strollers as part of Pliko and Primo Viaggio Travel Systems.   |
| 96)                      | Primo Viaggio CS00MU1, CS00US1,<br>CS00US8, LV34USL,<br>LV34USN, LN34S09,<br>LN34S10, ST33USL,<br>ST33USN, ST38USL,<br>ST38USN, AL33USL,<br>AL33USN, AL34USN,<br>AL34USL              | 05/20/01-02/15/02 The harness adjustment/locking mechanism may not fully lock and allow the harness to slip. The strap tension adjuster cover of affected models have a red circle around a dark button. Contact mfg. for full identification and repair information. Note: Primo Viaggio infant seat sold separately and with strollers as a part of Pliko, Primo Viaggio, and Atlantico Travel Systems.                  |
| 97)                      | Primo Viaggio 32MD41KN41, 35CR13BU13,<br>SIP 30/30 35CR13PL46, 35CR24BU24,<br>35TL49KN53, 35TL53KN46,<br>61FG13ST53, 61FG53ST49,<br>61FG53ST64, 61ST13IC53,<br>61ST34IC53, 61ST48IC53 | 07/01/07-03/14/08 The plastic adjustment cover of affected models could have exposed sharp edges that could cause cuts, scratches, or abrasions on the feet or legs of bare-footed infants. Does not affect safety as car seat. Contact mfg. For a free repair kit. Note: Affected model numbers begin with IMUN00US.  |
| 98)                      | <b>Playskool</b>  | <b>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</b>  |

| <i>List #</i>  | <i>Manufacturer Model # ("X" = more numbers or letters follow)</i> | <i>Customer Assistance</i>   |
|--|--|--|
| <i>Model Name</i>  | <i>Model #</i>   | <i>Mfg Date Problem Type and Consumer Action</i>   |
| 99)  | <i>Pride Trimble/Virco</i>   | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i>  |
| 100)   | <i>Questor</i>   | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i>  |
| <b>Recaro</b>  |  | <b>800-873-2276 / 248-364-3818 - <a href="http://www.recaro-nao.com">www.recaro-nao.com</a></b>  |
| 101)   | Como 331.00.xxx  | Pre-09/17/07 Consumer Advisory - Not a Recall: Lap and shoulder belt guide (previously referred to as "lock-off") may not hold belt webbing snugly enough to prevent belt from loosening. Contact mfg. for locking clip and instructions included as a part of the consumer advisory.  |
| 102)   | Como 331.00.xxx  | Pre-12/18/07 The harness may become disconnected from the harness connector when a child is placed in or removed from the child seat. Contact mfg. for repair kit.   |
| 103)   | Como 331.00.xxx, 331.01.xxx  | 11/01/07-02/16/09 The front harness adjuster strap may slip within the adjuster/lock that controls tightness of the harness and may prevent the harness from staying properly tight. Contact mfg. for free replacement seat. NOTE: Models with a green dot above the bar code on the model # sticker are OK to use.  |
| 104)   | Signo 331.00.xxx   | Pre-12/18/07 The harness may become disconnected from the harness connector when a child is placed in or removed from the child seat. Contact mfg. for repair kit.   |
| 105)   | Signo 330.00.xxx, 330.01.xxx                                       | 11/01/07-02/16/09 The front harness adjuster strap may slip within the adjuster/lock that controls tightness of the harness and may prevent the harness from staying properly tight. Contact mfg. for free replacement seat. NOTES: This date range is an expansion of the initial date range (02/01/08-09/30/08) for this recall. Models with a green dot above the bar code on the model # sticker are OK to use.              |
| 106)   | <i>Renolux (FBS)</i>   | <i>REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</i>  |
| <b>Safeline Kids<br/>(See Triple Play Products also)</b> |  | <b>800-829-1625 - <a href="http://www.tripleplayproducts.com">www.tripleplayproducts.com</a></b>   |
| 107)   | Sit'n'Stroll 2003  | 09/01/02-10/21/03 Child's head may move too far forward in a crash when lower forward-facing belt path or shoulder and buckle pads are used. Remove and discard shoulder and buckle pads and use upper forward-facing belt path only. Contact mfg. for revised instructions and labels.  |
| 108)   | Sit'n'Stroll 2240  | 04/01/01-10/01/01 The FAA certification statement on label is in yellow lettering instead of the required RED lettering. Flight attendants may not allow its use on an airplane. Contact mfg. for replacement label.   |
| <b>Safety 1<sup>st</sup> (Dorel)</b>                     |  | <b>Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141<br/><a href="http://www.djgusa.com">www.djgusa.com</a></b>   |
| 109)   | Alpha Elite All Models   | 11/01/03-12/31/05 There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  |
| 110)   | Alpha Omega 22151<br>Alpha Omega 22455<br>Elite                    | 11/01/03-12/31/05 There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  |
| 111)   | Alpha Sport All Models   | 11/01/03-12/31/05 There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit.  |
| 112)   | Designer 22 02-621-SAL, 02-620-xxx                                 | 01/03/02-02/13/02 Plastic handle can unexpectedly release from the carrying position when used as a carrier. Does not affect safety as a child restraint. Contact mfg. for repair kit.   |
| 113)   | Designer 22 22-325 xxx GB1B  | 08/19/03-10/20/04 Harness can loosen if not properly tightened. Contact mfg. for free repair kit. Parents should continue to use the seat while waiting to receive/install the repair kit but are advised to make sure that the seat is properly adjusted while in use. NOTE: Models involved were sold only as travel systems (with a stroller) and any line code other than GB1B in the model # is not included in the recall. |

| <i>List #</i>     | <i>Manufacturer Model # ("X" = more numbers or letters follow)</i> | <i>Customer Assistance</i>                       |
|-------------------|--|--|
| <i>Model Name</i> | <i>Model #</i>   | <i>Mfg Date Problem Type and Consumer Action</i> |

**Safety 1st (continued)**

|      |         |   |                       |   |
|------|---------|---|-----------------------|---|
| 114) | Enspira | 22450, 22451, 22452,<br>22453, 22480, 22481 | 11/01/03-<br>12/31/05 | There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit. |
| 115) | Intera  | 22460                                       | 11/01/03-<br>12/31/05 | There is a potential for the harness adjustment strap to loosen during use. Contact mfg. for free repair kit. |

**Safety 1st (continued)**

|         |                 |   |                       |  |
|---------|-----------------|---|-----------------------|--|
| >> 116) | Infant Car Seat | 22-057 CLN, 22-057 DBY,<br>22-057 HRT, 22-057 LPH,<br>22-085 DWA, 22-085 LYN,<br>22-095 RBK, 22-322 HRR,<br>22-322 KDL, 22-322 LXI,<br>22-322 MAI, 22-322 OLY,<br>22-322 PRS, 22-322 PTK,<br>22-325 COB, 22-325 PAC,<br>22-380 LGA, 22-380 MSA,<br>22-627 WAV | 01/06/08-<br>04/06/09 | The child restraint carry handle can loosen and come off posing a fall hazard to infants. The safety as a child restraint is not affected. Do not use handle until repaired. Contact mfg. for free repair kit. NOTE: Only those models sold as a part of the Eurostar, Explorer, Lite Wave, Sojourn, and Vector Travel Systems are affected. |
|---------|-----------------|---|-----------------------|--|

**Snug Seat****800-336-7684 - [www.snugseat.com](http://www.snugseat.com)**

|      |   |          |                       |   |
|------|---|----------|-----------------------|---|
| 117) | Gorilla   | 200-1000 | 07/26/02-<br>01/15/03 | A washer in tether anchor kit does not meet corrosion requirements of FMVSS 213. Contact mfg. for replacement kit # FW-50250-12-ZY  |
| 118) | Spelcast  | 600-1000 | 07/26/02-<br>01/15/03 | A washer in tether anchor kit does not meet corrosion requirements of FMVSS 213. Contact mfg. for replacement kit # FW-50250-12-ZY  |
| 119) | Traveller Plus<br>(Mfg. by Britax<br>for Snug Seat) | E9L32    | Pre-<br>07/24/04      | The adjuster strap may slip within the metal buckle that controls the tightness of the shoulder harness and may allow the harness to loosen. Contact Britax at 800-683-2045 or 704-409-1700 for repair kit. |

120) **Strolee****REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY & REPLACE****Team-Tex America****877-912-1313**

|      |          |        |                       |  |
|------|----------|--------|-----------------------|--|
| 121) | Babyride | 374099 | 08/31/06-<br>10/23/06 | Belt routing label with "horizontal reference line" was incorrectly placed on the CR. Contact mfg. for a correct label and placement instructions. NOTE: According to Team-Tex America, all seats that were affected by this recall were caught and corrected before being purchased by consumers and thus should not be found in use. |
| 122) | Babyride | 374199 | 12/18/08              | The belt routing label with the "horizontal reference line" for determining the correct recline angle is incorrectly placed on the child restraint. Contact mfg. for replacement label and instructions.   |

**TriplePlay Products  
(See Safeline Kids also)****800-829-1625 - [www.tripleplayproducts.com](http://www.tripleplayproducts.com)**

|      |              |      |          |   |
|------|--------------|------|----------|---|
| 123) | Sit'n'Stroll | 4002 | 05/05/08 | The webbing used in the center adjuster for the harness fails to comply with the initial breaking strength requirements of FMVSS 213. Contact mfg. for repair kit and instructions. NOTE: According to TriplePlay, the only units affected were a small number of seats manufactured on May 5, 2008 and sold through their website. All purchasers are being contacted and notified of this recall. |
|------|--------------|------|----------|---|

124) **TRW****REFER TO OLDER MODELS LIST - ALL MODELS ARE OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY & REPLACE**

| <i>List #</i> | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i> | <i>Customer Assistance</i>                       |
|---------------|--------------------------------|---|--|
|               |                                |   | <i>Mfg Date Problem Type and Consumer Action</i> |

*XSCi**800-630-6850 / 719-593-8881*125) Pioneered  
ACIS

None\*

02/01/02- Exceeds the maximum head excursion criteria of FMVSS 213. In a crash, the cradle  
03/07/02 can detach from the deflector base. Contact mfg for replacement information  
(replacements produced by an alternate mfg.) \*No model number is associated, but  
affects serial numbers 01C-000000002 to 01C-000000108. [NHTSA No.: 02E-024]  
\*\*NOTE: According to XSCi, all seats that were affected by this recall have been  
returned (as of May 8, 2002) and thus should not be found in use.\*\*

*Integrated (built-into the vehicle) seats*

|      | <i>Manufacturer</i>      | <i>Model Year</i> | <i>Customer Assistance</i>  |
|------|--------------------------|-------------------|---|
|      | <b><i>Chrysler</i></b>   |                   | <b><i>800-853-1403 / 800-992-1997</i></b>   |
| 126) | Town and Country         | 1996              | Bolts securing seat to frame can break. Contact Chrysler Corp. or dealer for repair   |
| 127) | Town and Country         | 1988              | Harness restraint webbing incorrectly routed around the metal reinforcement bar on these seats. Child may not be properly restrained in the event of a crash. Dealers will inspect and correct improperly routed webbing.                         |
| 128) | Town and Country         | 1996, 1997        | Safety improvement campaign: The latch plate can remain in the locked position due to food or other items. Owners are being provided with decals/instructions describing the operation of the buckle and the latch plate                          |
| 129) | Town and Country         | 1996, 1997        | The harness on the integrated child seat can become difficult to release when the safety belt latch plate gets dirty. Dealers will clean the latch, modify the emergency release anchor, and provide additional instructions.                     |
|      | <b><i>Dodge</i></b>      |                   | <b><i>800-853-1403 / 800-992-1997</i></b>   |
| 130) | Caravan<br>Grand Caravan | 1996              | Bolts securing seat to frame can break. Contact Chrysler Corp. or dealer for repair   |
| 131) | Caravan<br>Grand Caravan | 1988              | Harness restraint webbing incorrectly routed around the metal reinforcement bar on these seats. Child may not be properly restrained in the event of a crash. Dealers will inspect and correct improperly routed webbing.                         |
| 132) | Caravan<br>Grand Caravan | 1996, 1997        | Safety improvement campaign: The latch plate can remain in the locked position due to food or other items. Owners are being provided with decals/instructions describing the operation of the buckle and the latch plate                          |
| 133) | Caravan<br>Grand Caravan | 1996, 1997        | The harness on the integrated child seat can become difficult to release when the safety belt latch plate gets dirty. Dealers will clean the latch, modify the emergency release anchor, and provide additional instructions.                     |
|      | <b><i>Ford</i></b>       |                   | <b><i>800-392-3673</i></b>  |
| 134) | Windstar                 | 1998              | The headrest lockout mechanism on the integrated child seats may not engage and lock the headrest in the "down" position, as intended. Replace bench seats with integrated child seats with seats built with revised headrest lockout mechanisms. |
|      | <b><i>Plymouth</i></b>   |                   | <b><i>800-853-1403 / 800-992-1997</i></b>   |
| 135) | Voyager<br>Grand Voyager | 1996              | Bolts securing seat to frame can break. Contact Chrysler Corp. or dealer for repair   |
| 136) | Voyager<br>Grand Voyager | 1988              | Harness restraint webbing incorrectly routed around the metal reinforcement bar on these seats. Child may not be properly restrained in the event of a crash. Dealers will inspect and correct improperly routed webbing.                         |
| 137) | Voyager<br>Grand Voyager | 1996, 1997        | Safety improvement campaign: The latch plate can remain in the locked position due to food or other items. Owners are being provided with decals/instructions describing the operation of the buckle and the latch plate                          |
| 138) | Voyager<br>Grand Voyager | 1996, 1997        | The harness on the integrated child seat can become difficult to release when the safety belt latch plate gets dirty. Dealers will clean the latch, modify the emergency release anchor, and provide additional instructions.                     |

Child restraints (CRs) manufactured before 1981 were not required to be crash tested and must not be used. Most child passenger safety advocates recommend that CRs older than ten years should be replaced by a new one. Note that some manufacturers and safety advocates recommend replacing CRs before 10 years. **Following are recalls and safety notifications that were issued for models where all or most models sold are at least 10 years old as of December 22, 2009.** Updated versions of this list and a listing of recalls on models less than 10 years old are posted on-line at [www.hsrb.unc.edu](http://www.hsrb.unc.edu).

## CHILD RESTRAINTS AT LEAST 10 YEARS OLD

### Index of Recalls and Safety Notifications

Model numbers (noted by a "#") and model names for child restraints under recall are followed by their list number (that corresponds to the "List #" for each listing). Model numbers followed by an "x" should be read as "model numbers beginning with." If the model # is not found, check the model name also. Model #'s are not available for all model names. **Note:** Dorel Juvenile Group products are indexed under each individual product line (e.g., Cosco) as well as under "Dorel."

|                            |          |                         |          |                         |
|----------------------------|----------|-------------------------|----------|-------------------------|
| <b>Alcot (Childcare)</b>   | # 11-600 | 229, 230                | # 4500   | 247                     |
| Child Love Seat            | # 11-650 | 229                     | # 4510   | 247                     |
|                            | # 12-565 | 246                     | # 4513   | 246                     |
| <b>All Our Kids</b>        | # 4100   | 212, 213                | # 4515   | 246                     |
| # 600                      | # 4153   | 214                     | # 4516   | 246                     |
| # 602                      | # 4163   | 214                     | # 4518   | 246                     |
| Little Cargo Vest          | # 4180   | 214                     | # 4520   | 247                     |
|                            | # 4200   | 215, 216, 217, 218      | # 4525   | 248                     |
| <b>American Motors</b>     | # 4210   | 215, 216, 217, 218      | # 4535   | 245                     |
| Child Love Seat            | # 4214   | 215, 216, 217, 218      | # 4551   | 246                     |
| Infant Love Seat           | # 4223   | 215, 216, 217, 218      | # 4557   | 246                     |
|                            | # 4235   | 215, 216, 217, 218      | # 4558   | 246                     |
| <b>Babyhood Industries</b> | # 4253   | 219, 220, 221           | # 4559   | 246                     |
| # 810                      | # 4261   | 220, 221                | # 4560   | 245                     |
| # 8200                     | # 4263   | 219, 220, 221           | # 4564   | 246                     |
| Baby-Sitter                | # 4265   | 219, 220, 221           | # 4565   | 245, 246                |
| Wonda Chair                | # 4266   | 220, 221                | # 4566   | 246                     |
|                            | # 4300   | 222                     | # 4568   | 246                     |
| <b>Basic Comfort</b>       | # 4302   | 222                     | # 4569   | 246                     |
| # 960                      | # 4303   | 222                     | # 4575   | 241, 246                |
| # 961                      | # 4310   | 222                     | # 4576   | 246                     |
| Galaxy 2000                | # 4323   | 222                     | # 4580   | 240                     |
|                            | # 4334   | 222                     | # 4581   | 239, 240                |
| <b>Bolform Corp.</b>       | # 4335   | 222                     | # 4583   | 239, 240                |
| # 84E-019                  | # 4353   | 224, 225, 227           | # 4585   | 239, 240                |
| Buckle-Up Harness          | # 4365   | 224, 225, 226, 227      | # 4589   | 246                     |
|                            | # 4365DT | 223                     | # 4590   | 245                     |
| <b>Britax</b>              | # 4366   | 223, 224, 225, 226, 227 | # 4591   | 246                     |
| # 101                      | # 4367   | 226, 227                | # 4593   | 246                     |
| # 161                      | # 4368   | 224, 225, 226, 227      | # 4594   | 246                     |
| Freeway                    | # 4369   | 226, 227                | # 4595   | 246                     |
| Roundabout                 | # 4380   | 226, 228                | # 4597   | 246                     |
|                            | # 4381   | 226                     | # 4600   | 244                     |
| <b>Century</b>             | # 4400   | 231, 232                | # 4750   | 249                     |
| # 11-564                   | # 4434   | 231, 232                | # 4875   | 242                     |
| # 11-565                   | # 4436   | 231, 232                | # 4885   | 243                     |
| # 11-570                   | # 4446   | 231, 232                | 100      | 212, 213                |
| # 11-575                   | # 4450   | 233, 234, 236, 237      | 1000 STE | 214                     |
| # 11-576                   | # 4460   | 233, 234, 235, 236, 237 | 200      | 215, 216, 217, 218      |
| # 11-578                   | # 4470   | 234, 235, 236, 237      | 2000 STE | 219, 220, 221           |
| # 11-595                   | # 4475   | 233, 234, 235, 236, 237 | 300      | 222                     |
| # 11-597                   | # 4476   | 235, 236                | 3000 STE | 223, 224, 225, 226, 227 |
| # 11-598                   | # 4480   | 235, 238                | 3500 STE | 228                     |
| # 11-599                   | # 4490   | 235, 238                | 4-In-1   | 229, 230                |

**Century (continued)**

|                   |                         |
|-------------------|-------------------------|
| 400XL             | 231, 232                |
| 5000 STE          | 233, 234, 235, 236, 237 |
| 5500 STE          | 238                     |
| 580               | 239, 240                |
| Affinity          | 241                     |
| Breverra Contour  | 242                     |
| Breverra Premiere | 243                     |
| Child Love Seat   | 244                     |
| Infant Car Seat   | 245, 246                |
| Infant Love seat  | 247                     |
| Smart Fit         | 248                     |
| Smart Move        | 249                     |

**Chrysler**

|                 |     |
|-----------------|-----|
| Child Love Seat | 250 |
|-----------------|-----|

**Collier-Keyworth**

|                   |     |
|-------------------|-----|
| Co-Pilot          | 251 |
| Commuter          | 253 |
| Safe and Sound II | 252 |

**Cosco**

|              |          |
|--------------|----------|
| # 02-014-EMF | 269      |
| # 02-014-GDM | 269      |
| # 02-015-PDL | 269      |
| # 02-084     | 268, 271 |
| # 02-086     | 257      |
| # 02-090     | 265      |
| # 02-094     | 271      |
| # 02-096     | 271      |
| # 02-190     | 267      |
| # 02-290     | 266      |
| # 02-404     | 271      |
| # 02-514-BWE | 270      |
| # 02-518-NDF | 270      |
| # 02-584-OXF | 270      |
| # 02-665     | 256      |
| # 02-667     | 273      |
| # 02-719 ARQ | 258      |
| # 02-727     | 256      |
| # 02-728     | 256      |
| # 02-729     | 256      |
| # 02-729 TED | 255      |
| # 02-731     | 256      |
| # 02-732     | 256      |
| # 02-733     | 256      |
| # 02-750     | 256      |
| # 02-751     | 254, 256 |
| # 02-753     | 273      |
| # 02-755     | 256      |
| # 02-756     | 256, 273 |
| # 02-757     | 256      |
| # 02-758     | 273      |
| # 02-759     | 273      |
| # 02-760     | 273      |
| # 02-761     | 273      |
| # 02-762     | 273      |
| # 02-763     | 273      |
| # 02-764     | 273      |
| # 02-765     | 273      |
| # 02-770     | 273      |

|                         |                    |
|-------------------------|--------------------|
| # 02-771                | 273                |
| # 02-772                | 273                |
| # 02-774                | 256                |
| # 02-790                | 259                |
| # 02-821                | 271                |
| # 02-890                | 259                |
| # 181A                  | 260                |
| # 181B                  | 260                |
| # 313                   | 262                |
| # 323                   | 263                |
| # 423                   | 263                |
| # 81A                   | 260                |
| # 81B                   | 260                |
| Arriva                  | 254, 255, 256      |
| Commuter                | 257                |
| Dream Ride              | 258                |
| Lxry Sft Shld Auto Trac | 259                |
| Safe and Easy           | 262                |
| Safe and Snug           | 263                |
| Safe-T Mate             | 261                |
| Safe-T-Shield           | 260                |
| Sft Shld Auto Trac      | 266                |
| Soft Shield             | 265                |
| Soft Shield Deluxe      | 267                |
| Touriva                 | 268, 269, 270, 271 |
| Turnabout               | 273                |
| Voyager Inf/Stroller    | 274                |

**Dorel**

|                        |          |
|------------------------|----------|
| # 02-014-EMF (Cosco)   | 269      |
| # 02-014-GDM (Cosco)   | 269      |
| # 02-015-PDL (Cosco)   | 269      |
| # 02-084 (Cosco)       | 268, 271 |
| # 02-086 (Cosco)       | 257      |
| # 02-090 (Cosco)       | 265, 266 |
| # 02-094 (Cosco)       | 271      |
| # 02-096 (Cosco)       | 271      |
| # 02-190 (Cosco)       | 267      |
| # 02-331 (Eddie Bauer) | 276      |
| # 02-332 (Eddie Bauer) | 276      |
| # 02-404 (Cosco)       | 271      |
| # 02-514-BWE (Cosco)   | 270      |
| # 02-518-NDF (Cosco)   | 270      |
| # 02-531 (Eddie Bauer) | 276      |
| # 02-533 (Eddie Bauer) | 276      |
| # 02-537 (Eddie Bauer) | 276      |
| # 02-555 (Eddie Bauer) | 276      |
| # 02-584-OXF (Cosco)   | 270      |
| # 02-665 (Cosco)       | 256      |
| # 02-667 (Cosco)       | 273      |
| # 02-719 ARQ (Cosco)   | 258      |
| # 02-727 (Cosco)       | 256      |
| # 02-728 (Cosco)       | 256      |
| # 02-729 (Cosco)       | 256      |
| # 02-729 TED (Cosco)   | 255      |
| # 02-731 (Cosco)       | 256      |
| # 02-732 (Cosco)       | 256      |
| # 02-733 (Cosco)       | 256      |
| # 02-750 (Cosco)       | 256      |
| # 02-751 (Cosco)       | 254, 256 |
| # 02-753 (Cosco)       | 273      |
| # 02-755 (Cosco)       | 256      |

|                                 |               |
|---------------------------------|---------------|
| # 02-756 (Cosco)                | 256, 273      |
| # 02-757 (Cosco)                | 256           |
| # 02-758 (Cosco)                | 273           |
| # 02-759 (Cosco)                | 273           |
| # 02-760 (Cosco)                | 273           |
| # 02-761 (Cosco)                | 273           |
| # 02-762 (Cosco)                | 273           |
| # 02-763 (Cosco)                | 273           |
| # 02-764 (Cosco)                | 273           |
| # 02-765 (Cosco)                | 273           |
| # 02-770 (Cosco)                | 273           |
| # 02-771 (Cosco)                | 273           |
| # 02-772 (Cosco)                | 273           |
| # 02-774 (Cosco)                | 256           |
| # 02-790 (Cosco)                | 259           |
| # 02-821 (Cosco)                | 271           |
| # 02-890 (Cosco)                | 259           |
| # 181A (Cosco)                  | 260           |
| # 181B (Cosco)                  | 260           |
| # 219x (Cosco)                  | 272           |
| # 224x (Cosco)                  | 272           |
| # 225x (Cosco)                  | 272           |
| # 229x (Cosco)                  | 272           |
| # 244x (Cosco)                  | 264           |
| # 313 (Cosco)                   | 262           |
| # 323 (Cosco)                   | 263           |
| # 423 (Cosco)                   | 263           |
| # 81A (Cosco)                   | 260           |
| # 81B (Cosco)                   | 260           |
| 3-in-1 (Eddie Bauer)            | 276           |
| Arriva (Cosco)                  | 254, 255, 256 |
| Commuter (Cosco)                | 257           |
| Dream Ride (Cosco)              | 258           |
| Lxry Sft Shld Auto Trac (Cosco) | 259           |
| Safe and Easy (Cosco)           | 262           |
| Safe and Snug (Cosco)           | 263           |
| Safe-T-Mate (Cosco)             | 261           |
| Safe-T-Shield (Cosco)           | 260           |
| Sft Shld Auto Trac (Cosco)      | 266           |
| Sidekick Booster (Cosco)        | 264           |
| Soft Shield (Cosco)             | 265           |
| Soft Shield Deluxe (Cosco)      | 267           |
| Touriva (Cosco)                 | 268           |
| Touriva 5-point (Cosco)         | 270           |
| Touriva Shield (Cosco)          | 269           |
| Touriva T-Shield (Cosco)        | 271           |
| Trooper (Cosco)                 | 272           |
| Turnabout (Cosco)               | 273           |
| Voyager Inf/Stroller (Cosco)    | 274           |

**Downunder**

|                  |     |
|------------------|-----|
| Kangaroo Booster | 275 |
|------------------|-----|

**Eddie Bauer**

|          |     |
|----------|-----|
| # 02-331 | 276 |
| # 02-332 | 276 |
| # 02-531 | 276 |
| # 02-533 | 276 |
| # 02-537 | 276 |
| # 02-555 | 276 |
| 3-in-1   | 276 |

|                    |                         |                              |   |                            |                                   |
|--------------------|-------------------------|------------------------------|---|----------------------------|-----------------------------------|
| <b>Evenflo</b>     |                         | # 493x . . . . .             | 289   | # 13123 . . . . .          | 354                               |
| # 200x . . . . .   | 292                     | # 499x . . . . .             | 292   | # 1312x . . . . .          | 338                               |
| # 201 . . . . .    | 288                     | # 636x . . . . .             | 303   | # 1382x . . . . .          | 338, 350, 353, 360                |
| # 202 . . . . .    | 286, 288                | # 637x . . . . .             | 303   | # 13833 . . . . .          | 331, 352, 359                     |
| # 203x . . . . .   | 289                     | # 639001 . . . . .           | 293   | # 1383x . . . . .          | 335, 338, 350, 353, 360           |
| # 205x . . . . .   | 289, 300, 301           | # 639002 . . . . .           | 293   | # 13842 . . . . .          | 331, 352, 359                     |
| # 206 . . . . .    | 290                     | 410 . . . . .                | 277   | # 1384x . . . . .          | 350, 353, 360                     |
| # 207x . . . . .   | 291                     | Bobby Mac Champion . . . . . | 278   | # 13852 . . . . .          | 331, 352, 359                     |
| # 210x . . . . .   | 289, 301                | Bobby Mac Deluxe . . . . .   | 279   | # 1385x . . . . .          | 353, 360                          |
| # 211x . . . . .   | 292                     | Booster Seat . . . . .       | 280, 281                                    | # 138xx . . . . .          | 337, 349, 351, 358                |
| # 219164 . . . . . | 302                     | Champion . . . . .           | 282, 283, 284                               | # 140-155 . . . . .        | 346                               |
| # 219180 . . . . . | 302                     | Dyn-O-Mite . . . . .         | 285, 286                                    | # 150-100 . . . . .        | 362                               |
| # 219186 . . . . . | 302                     | Infant Car Seat . . . . .    | 287, 288                                    | # 180-100 . . . . .        | 341                               |
| # 219188 . . . . . | 302                     | Joyride . . . . .            | 289   | # 180-150 . . . . .        | 341, 342                          |
| # 21940 . . . . .  | 302                     | On My Way . . . . .          | 290, 291, 292                               | # 180-200 . . . . .        | 332, 333, 342, 343                |
| # 219x . . . . .   | 272, 284, 297           | On My Way base . . . . .     | 293   | # 180-300 . . . . .        | 332, 333                          |
| # 221 . . . . .    | 294                     | One-Step . . . . .           | 294   | # 180-400 . . . . .        | 346                               |
| # 222 . . . . .    | 295                     | One-Step Deluxe . . . . .    | 295   | # 180-600 . . . . .        | 330, 334                          |
| # 223 . . . . .    | 295                     | Scout . . . . .              | 296, 297                                    | # 180-601 . . . . .        | 330                               |
| # 224x . . . . .   | 272, 282, 283, 284, 297 | Seven Year Seat . . . . .    | 298, 299                                    | # 19127 . . . . .          | 339, 340                          |
| # 225x . . . . .   | 272, 284, 297           | Sidekick . . . . .           | 264   | # 19128 . . . . .          | 339                               |
| # 227 . . . . .    | 306                     | Travel Tandem . . . . .      | 300, 301                                    | # 19129 . . . . .          | 339                               |
| # 228 . . . . .    | 299                     | Trooper . . . . .            | 272, 302                                    | # 19130 . . . . .          | 339                               |
| # 229x . . . . .   | 272, 284, 296, 297      | Two-in-One . . . . .         | 303   | # 368xx . . . . .          | 337, 338, 349, 350, 351, 353, 358 |
| # 231 . . . . .    | 305                     | Ultara 1 . . . . .           | 304, 305                                    | # 43xxx . . . . .          | 336, 356                          |
| # 232 . . . . .    | 307                     | Ultara II . . . . .          | 306, 307                                    | # 77001 . . . . .          | 347                               |
| # 242 . . . . .    | 281                     |                              |   | # 77002 . . . . .          | 347                               |
| # 244x . . . . .   | 264                     | <b>Fisher Price</b>          |   | # 77005 . . . . .          | 348                               |
| # 401 . . . . .    | 294                     | # 79700 . . . . .            | 322   | # 77007 . . . . .          | 348                               |
| # 402 . . . . .    | 294                     | # 9100 . . . . .             | 308, 309, 310, 311, 312, 313, 314, 315, 316 | Automate . . . . .         | 330                               |
| # 403 . . . . .    | 294                     | # 9101 . . . . .             | 309, 310, 312, 313, 314, 315, 316           | Carter Travel 5 . . . . .  | 331                               |
| # 404 . . . . .    | 294                     | # 9104 . . . . .             | 317, 320, 321                               | Dial-A-Fit . . . . .       | 332, 333                          |
| # 405 . . . . .    | 294                     | # 9149 . . . . .             | 318   | Dial-A-Fit II . . . . .    | 334                               |
| # 406 . . . . .    | 294                     | # 9173 . . . . .             | 319   | Flip 'N' Go . . . . .      | 339                               |
| # 407 . . . . .    | 294                     | Booster . . . . .            | 320, 321                                    | Flip 'N' Go II . . . . .   | 340                               |
| # 408 . . . . .    | 294                     | Car Seat . . . . .           | 308, 309, 310, 311, 312, 313, 314, 315, 316 | Infant Car Seat . . . . .  | 335                               |
| # 409 . . . . .    | 294                     | Delux Car Seat . . . . .     | 317   | Infant Restraint . . . . . | 336                               |
| # 410 . . . . .    | 277                     | Infant Seat . . . . .        | 318, 319                                    | Infant Rider . . . . .     | 337, 338                          |
| # 411 . . . . .    | 278                     | Safe Embrace . . . . .       | 322   | Perfect Fitt . . . . .     | 341, 342, 343                     |
| # 412 . . . . .    | 279                     |                              |   | Performa . . . . .         | 344, 345                          |
| # 414 . . . . .    | 279                     | <b>Ford</b>                  |   | Playskool . . . . .        | 346, 347                          |
| # 415 . . . . .    | 279                     | Infant Love Seat . . . . .   | 323   | Playskool Infant . . . . . | 348                               |
| # 416 . . . . .    | 279                     |                              |   | Plus 4 . . . . .           | 349, 350                          |
| # 4176 . . . . .   | 295                     | <b>General Motors</b>        |   | Plus 5 . . . . .           | 351, 352, 353                     |
| # 420 . . . . .    | 304                     | Child Love Seat . . . . .    | 325   | Rock 'N' Ride . . . . .    | 354, 355                          |
| # 435x . . . . .   | 289                     | Infant Love Seat . . . . .   | 324   | Secura . . . . .           | 356                               |
| # 441 . . . . .    | 285, 286, 288           |                              |   | Secure Fit . . . . .       | 357                               |
| # 442 . . . . .    | 285, 286, 288           | <b>Gerry</b>                 |   | Travel About . . . . .     | 358, 359                          |
| # 443 . . . . .    | 285, 286, 288           | # 626 . . . . .              | 327   | Travel-About . . . . .     | 360                               |
| # 444 . . . . .    | 285, 286, 288           | Guardian . . . . .           | 326   | Traveler 700 . . . . .     | 361, 362, 363                     |
| # 445 . . . . .    | 285, 286, 288           | Secure Ride . . . . .        | 327   |                            |                                   |
| # 446 . . . . .    | 285, 286, 288           |                              |   | <b>Lin Lih/MCP</b>         |                                   |
| # 447 . . . . .    | 285, 286                | <b>Graco</b>                 |   | # 180-200 . . . . .        | 365                               |
| # 447x . . . . .   | 292                     | GT 1000 . . . . .            | 328   | # 180-300 . . . . .        | 365                               |
| # 448 . . . . .    | 285, 286, 288           |                              |   | Lin Lih . . . . .          | 364, 365                          |
| # 453 . . . . .    | 298, 299                | <b>International</b>         |   |                            |                                   |
| # 454 . . . . .    | 298, 299                | Astroseat . . . . .          | 329   |                            |                                   |
| # 456 . . . . .    | 287, 288                |                              |   | <b>Mercedes-Benz</b>       |                                   |
| # 458 . . . . .    | 287, 288                |                              |   | # BQ6910155 . . . . .      | 367                               |
| # 470 . . . . .    | 280, 281                | <b>Kolcraft</b>              |   | # BQ6910157 . . . . .      | 366                               |
| # 471 . . . . .    | 280, 281                | # 131-101 . . . . .          | 355   | # BQ691063 . . . . .       | 366                               |
| # 492x . . . . .   | 291                     |                              |   | Booster Seat . . . . .     | 366                               |
|                    |                         |                              |   | Infant Restraint . . . . . | 367                               |

**Playskool**

|                       |          |
|-----------------------|----------|
| # 140-155 .....       | 368      |
| # 180-400 .....       | 368      |
| # 77001 .....         | 369      |
| # 77002 .....         | 369      |
| # 77005 .....         | 370      |
| # 77007 .....         | 370      |
| Car Seat .....        | 368, 369 |
| Infant Car Seat ..... | 370      |

**Pride Trimble/Virco**

|                  |          |
|------------------|----------|
| # 832 .....      | 373      |
| # 890 .....      | 371, 372 |
| # 891 .....      | 371, 372 |
| # 892 .....      | 371, 372 |
| Click-n-Go ..... | 371, 372 |
| Pride Ride ..... | 373      |

**Questor**

|                        |     |
|------------------------|-----|
| Kantwet Car Seat ..... | 374 |
|------------------------|-----|

**Renolux (FBS)**

|                          |               |
|--------------------------|---------------|
| GT 1000 .....            | 375           |
| GT 2000 .....            | 376, 377, 378 |
| GT 4000 .....            | 379, 380      |
| GT 5000 .....            | 381, 382      |
| GT 5000 Turn A Tot ..... | 383, 384, 385 |
| GT 5500 .....            | 386, 387      |
| GT 7000 .....            | 388, 389, 390 |

**Safeline Kids**

|                    |     |
|--------------------|-----|
| # 3240 .....       | 391 |
| Sit'n'Stroll ..... | 391 |

**Safeline Kids (see Triple Play also)**

|                    |     |
|--------------------|-----|
| # 3240 .....       | 392 |
| Sit'n'Stroll ..... | 392 |

**Strolee**

|                   |               |
|-------------------|---------------|
| # 599 .....       | 394           |
| # 605 .....       | 396           |
| # 609 .....       | 395           |
| # 610 .....       | 395           |
| GT 3000 .....     | 397           |
| Quick Click ..... | 396           |
| Wee Care .....    | 393, 394, 395 |

**TRW**

|                        |     |
|------------------------|-----|
| Child Love Seat .....  | 399 |
| Infant Love Seat ..... | 398 |

**Volvo**

|           |     |
|-----------|-----|
| All ..... | 400 |
|-----------|-----|

| <i>List #</i>              | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i>  | <i>Customer assistance Mfg Date</i> | <i>Problem Type and Consumer Action</i>  |
|----------------------------|--------------------------------|--|-------------------------------------|--|
| <b>Alcot (Childcare)</b>   |                                | <b>ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</b> |                                     |  |
| 200)                       | Child Love Seat                |  | 3/84-11/84                          | Plastic shell may develop cracks. Destroy & replace seat.  |
| <b>All Our Kids</b>        |                                | <b>ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</b> |                                     |  |
| 201)                       | Little Cargo Vest              | 600  | 4/93-3/94                           | Flammability of upholstery. Call mfg. for repair info.   |
| 202)                       | Little Cargo Vest              | 602  | 3/94-9/94                           | Flammability of upholstery. Call mfg. for repair info.   |
| <b>American Motors</b>     |                                | <b>ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</b> |                                     |  |
| 203)                       | Infant Love Seat               | All  | 1/81-12/82                          | Plastic shell may develop cracks. Destroy & replace seat.  |
| 204)                       | Child Love Seat                | All  | 3/84-11/84                          | Plastic shell may develop cracks. Destroy & replace seat.  |
| <b>Babyhood Industries</b> |                                | <b>ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</b> |                                     |  |
| 205)                       | Wonda Chair                    | 810  | Pre 12/82                           | Harness may be misrouted. Call mfg. for instructions.  |
| 206)                       | Baby-Sitter                    | 8200   | 1/92-6/93                           | Buckle. Call mfg. for repair info.   |
| <b>Basic Comfort</b>       |                                | <b>ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</b> |                                     |  |
| 207)                       | Galaxy 2000                    | 960, 961   | ALL                                 | Crash test failure. Call mfg. for repair info.   |
| 208)                       | Galaxy 2000                    | 960, 961   | 11/98-1/99                          | Faulty molding of foam backs and cushions may allow separation of part of the booster seat. Call mfg. for repair info. |
| <b>Bolform Corp.</b>       |                                | <b>ALL MODELS OLDER THAN 10 YEARS - NO LONGER IN BUSINESS - DESTROY &amp; REPLACE</b>            |                                     |  |
| 209)                       | Buckle-Up Harness              | 84E-019  | ALL                                 | Crash test failure. Destroy & replace.   |
| <b>Britax</b>              |                                | <b>888-427-4829 / 704-409-1700<br/>www.britaxusa.com</b>   |                                     |  |
| 210)                       | Freeway                        | 101  | 6/96-4/97                           | Buckle. Call mfg. for repair info.   |
| 211)                       | Roundabout                     | 161  | 1/99-3/99                           | Possible faulty molding of shell can allow excessive head excursion. Call mfg. for repair info.                        |
| <b>Century Products</b>    |                                | <b>800-837-4044 / 216-468-2000</b>   |                                     |  |
| 212)                       | 100                            | 4100   | 1/81-4/81                           | Upholstery buttons. Call mfg. for repair info.   |
| 213)                       | 100                            | 4100   | 4/85-2/86                           | Plastic shell may crack in crash. Call mfg. for repair info.   |
| 214)                       | 1000 STE                       | 4153, 4163, 4180   | 12/90-10/91                         | Incorrect labels on seat. Call mfg. for corrections  |
| 215)                       | 200                            | 4200, 4210, 4235, 4214, 4223   | 1/81-4/81                           | Upholstery buttons. Call mfg. for repair info.   |
| 216)                       | 200                            | 4200, 4210, 4235, 4214, 4223   | June 81                             | Washers on frame. Call mfg. for repair info.   |
| 217)                       | 200                            | 4200, 4210, 4235, 4214, 4223   | 1/81-1/83                           | Buckle. Call mfg. for repair info.   |

| <i>List #</i>                       | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i>                                  | <i>Customer assistance Mfg Date</i> | <i>Problem Type and Consumer Action</i>  |
|-------------------------------------|--------------------------------|--|-------------------------------------|--|
| <i>Century Products (continued)</i> |                                |  |                                     |  |
| 218)                                | 200                            | 4200, 4210, 4235, 4214, 4223   | 4/85-2/86                           | Plastic shell may crack in crash. Call mfg. for repair info.   |
| 219)                                | 2000 STE                       | 4253, 4263, 4265   | 4/84-6/89                           | Harness. Call mfg. for repair info.  |
| 220)                                | 2000 STE                       | 4253, 4261, 4263, 4265, 4266   | 12/90-10/91                         | Incorrect labels on seat. Call mfg. for corrections  |
| 221)                                | 2000 STE                       | 4253, 4261, 4263, 4265, 4266   | 12/91-4/92                          | Buckle. Call mfg. for repair info.   |
| 222)                                | 300                            | 4300, 4302, 4303, 4323, 4310, 4334, 4335   | 4/85-2/86                           | Plastic shell may crack in crash. Call mfg. for repair info.   |
| 223)                                | 3000 STE                       | 4365DT, 4366   | 3/89-10/89                          | Upholstery. Call mfg. for repair info.   |
| 224)                                | 3000 STE                       | 4353, 4365, 4366, 4368   | 5/90-6/90                           | Crash test failure of buckle. Call mfg. for repair info.   |
| 225)                                | 3000 STE                       | 4353, 4365, 4366, 4368   | Pre 91                              | Buckle instructions. Call mfg. for corrections   |
| 226)                                | 3000 STE                       | 4365, 4366, 4367, 4368, 4369, 4380, 4381   | 12/90-10/91                         | Incorrect labels on seat. Call mfg. for corrections  |
| 227)                                | 3000 STE                       | 4353, 4365, 4366, 4367, 4368, 4369   | 10/89-4/92                          | Buckle. Call mfg. for repair info.   |
| 228)                                | 3500 STE                       | 4380   | 12/90-4/92                          | Buckle. Call mfg. for repair info.   |
| 229)                                | 4-In-1 Travel System           | 11-570, 11-597, 11-600, 11-650   | 9/95-5/96                           | Buckle. Call mfg. for repair info.   |
| 230)                                | 4-In-1 Travel System           | 11-564, 11-565, 11-570, 11-575, 11-576, 11-578, 11-595, 11-597, 11-598, 11-599, 11-600 | 01/01/91-07/31/97                   | Handle can break when the seat is used as an infant carrier causing the infant to fall to the ground be injured. Does not affect safety as car seat. Call 800-865-1419 for replacement handle. |
| 231)                                | 400XL                          | 4400, 4434, 4436, 4446   | 4/85-2/86                           | Plastic shell may crack in crash. Call mfg. for repair info.   |
| 232)                                | 400XL                          | 4400, 4434, 4436, 4446   | 11/84-4/86                          | Shield. Call mfg. for repair info.   |
| 233)                                | 5000 STE                       | 4450, 4460, 4475   | 12/88-11/89                         | Buckle. Call mfg. for repair info.   |
| 234)                                | 5000 STE                       | 4450, 4460, 4470, 4475   | 5/90-6/90                           | Crash test failure of buckle. Call mfg. for repair info.   |
| 235)                                | 5000 STE                       | 4460, 4470, 4475, 4476, 4480, 4490   | 12/90-10/91                         | Incorrect labels on seat. Call mfg. for corrections  |
| 236)                                | 5000 STE                       | 4450, 4460, 4470, 4475, 4476   | 09/89-4/92                          | Buckle. Call mfg. for repair info.   |
| 237)                                | 5000 STE                       | 4450, 4460, 4470, 4475,  | Pre 91                              | Buckle instructions. Call mfg. for corrections.  |
| 238)                                | 5500 STE                       | 4480, 4490   | 01/91-4/92                          | Buckle. Call mfg. for repair info.   |
| 239)                                | 580                            | 4581, 4583, 4585   | 6/86-10/89                          | Screws for carry handle. Call mfg. for repair info.  |
| 240)                                | 580                            | 4580, 4581, 4583, 4585   | 7/86-12/89                          | Incorrect instructions. Call mfg. for corrections.   |
| 241)                                | Affinity Infant Seat           | 4575   | 9/95-5/96                           | Buckle. Call mfg. for repair info.   |
| 242)                                | Breverra Contour               | 4875   | 2/95-7/98                           | Product improvement campaign: Buckle for the harness can crack or break. Call mfg. for replacement information.  |
| 243)                                | Breverra Premiere              | 4885   | 2/95-7/98                           | Product improvement campaign: Buckle for the harness can crack or break. Call mfg. for replacement information.  |
| 244)                                | Child Love Seat                | 4600   | 3/84-11/84                          | Plastic shell may develop cracks. Destroy & replace seat.  |
| 245)                                | Infant Car Seat                | 4535, 4560, 4565, 4590   | 9/95-5/96                           | Buckle. Call mfg. for repair info.   |

| <i>List #</i> | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i> | <i>Customer assistance Mfg Date</i> | <i>Problem Type and Consumer Action</i> |
|---------------|--------------------------------|---|-------------------------------------|---|
|---------------|--------------------------------|---|-------------------------------------|---|

**Century Products (continued)**

|      |                  |  |                   |  |
|------|------------------|--|-------------------|--|
| 246) | Infant Car Seat  | 12-565, 4513, 4515, 4516, 4518, 4551, 4557, 4558, 4559, 4564, 4565, 4566, 4568, 4569, 4575, 4576, 4589, 4591, 4593, 4594, 4595, 4597 | 01/01/91-07/31/97 | Handle can break when the seat is used as an infant carrier causing the infant to fall to the ground be injured. Does not affect safety as car seat. Call 800-865-1419 for replacement handle. |
| 247) | Infant Love seat | 4500, 4510, 4520   | 1/81-12/82        | Plastic shell may develop cracks. Destroy & replace seat.  |
| 248) | Smart Fit        | 4525   | 9/95-5/96         | Buckle. Call mfg. for repair info.   |
| 249) | Smart Move       | 4750   | 11/95-2/96        | Buckle. Call mfg. for repair info.   |

**Chrysler****ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY & REPLACE**

|      |                 |     |            |   |
|------|-----------------|-----|------------|---|
| 250) | Child Love Seat | All | 3/84-11/84 | Plastic shell may develop cracks. Destroy & replace seat. |
|------|-----------------|-----|------------|---|

**Collier-Keyworth****800-544-1108**

|      |                   |     |             |                                     |
|------|-------------------|-----|-------------|-------------------------------------|
| 251) | Co-Pilot          | All | 82-83       | Shield. Call mfg. for repair info.  |
| 252) | Safe and Sound II | All | 12/84-4/85  | Buckle. Call mfg. for repair info.  |
| 253) | Commuter          | All | 10/87-02/88 | Padding. Call mfg. for repair info. |

**Cosco (Dorel)****Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141**

|      |                              |  |                    |  |
|------|------------------------------|--|--------------------|--|
| 254) | Arriva                       | 02-751   | 03/95-05/95        | Buckle. Call mfg. for repair info.   |
| 255) | Arriva                       | 02-729 TED   | 03/31/99- 04/07/99 | Airbag warning label is missing on seat pad. Fabric color noted by "TED" is only one affected. Call mfg. for replacement pad.  |
| 256) | Arriva                       | 02-665, 02-727, 02-728, 02-729, 02-731, 02-732, 02-733, 02-750, 02-751, 02-755, 02-756, 02-757, 02-774 | 03/01/95-01/31/00  | Handle locks can unexpectedly release when used as a carrier, causing the seat to flip forward. Does not affect safety as car seat. Call mfg. for repair info. [Note: a recall campaign initiated 06/25/03 added models made through 01/31/00 to a previous recall of those made through 09/97.] |
| 257) | Commuter                     | 02-086   | 11/87-2/88         | Upholstery/padding. Call mfg. for repair info.   |
| 258) | Dream Ride                   | 02-719 ARQ   | 01/89-01/94        | Upholstery flammability. Call mfg. for repair info.  |
| 259) | Luxury Soft Shield Auto Trac | 02-790, 02-890   | 10/89-6/90         | Crash test failure. Call mfg. for repair info.   |
| 260) | Safe-T-Shield                | 81A or B, 181A or B  | 10/80-6/83         | Shield. Call mfg. to replace seat.   |
| 261) | Safe-T-Mate                  |  | 1984               | Wrong instructions. Call mfg. for repair info.   |
| 262) | Safe and Easy                | 313  | 1/84-6/85          | Plastic shell. Call mfg. for repair info.  |
| 263) | Safe and Snug                | 323, 423   | 1/84-6/85          | Plastic shell. Call mfg. for repair info.  |
| 264) | Sidekick Booster             | 244x   | 04/96-5/97         | Crash test failure of shield. Use only as belt-positioning booster. Call mfg. for refund info.   |
| 265) | Soft Shield                  | 02-090   | 10/89-6/90         | Crash test failure. Call mfg. for repair info.   |
| 266) | Soft Shield Auto Trac        | 02-290   | 10/89-6/90         | Crash test failure. Call mfg. for repair info.   |
| 267) | Soft Shield Deluxe           | 02-190   | 10/89-6/90         | Crash test failure. Call mfg. for repair info.   |
| 268) | Touriva                      | 02-084   | 5/94-8/94          | Buckle. Call mfg. for repair info.   |

| <i>List #</i> | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i> | <i>Customer assistance Mfg Date</i> | <i>Problem Type and Consumer Action</i> |
|---------------|--------------------------------|---|-------------------------------------|---|
|---------------|--------------------------------|---|-------------------------------------|---|

***Cosco (continued)***

|      |                              |  |                   |  |
|------|------------------------------|--|-------------------|--|
| 269) | Touriva Shield               | 02-014-EMF,<br>02-014-GDM,<br>02-015-PDL   | 8/97<br>(Mold #3) | Crash test failure of shell in front-facing recline position. Call mfg. for repair info.   |
| 270) | Touriva 5-point              | 02-514-BWE,<br>02-584-OXF,<br>02-518-NDF   | 8/97<br>(Mold #3) | Crash test failure of shell in front-facing recline position. Call mfg. for repair info.   |
| 271) | Touriva T-Shield             | 02-084, 02-094,<br>02-096, 02-404,<br>02-821   | 5/96-11/97        | Crash test failure of post-test release pressure standard for the buckle. Call mfg. for repair info.   |
| 272) | Trooper                      | 219x, 224x,<br>225x, 229x  | 10/96-2/97        | Crash test failure. Call mfg. for repair info.   |
| 273) | Turnabout                    | 02-667, 02-753, 02-756,<br>02-758, 02-759, 02-760,<br>02-761, 02-762, 02-763,<br>02-764, 02-765, 02-770,<br>02-771, 02-772 | 03/01/95-01/31/00 | Handle locks can unexpectedly release when used as a carrier, causing the seat to flip forward. Does not affect safety as car seat. Call mfg. for repair info. [Note: a recall campaign initiated 06/25/03 added models made through 01/31/00 to a previous recall of those made through 09/97.] |
| 274) | Voyager Infant Seat/Stroller | All  | 9/97-10/97        | Potential dislodgement from stroller. Does not affect safety as car seat. Call mfg. for repair info.   |

***Downunder******No longer in business***

|      |                       |                 |  |  |
|------|-----------------------|-----------------|--|--|
| 275) | Kangaroo Booster Seat | All (Pre- 1/98) |  | Safety improvement campaign: The shoulder belts may not be properly located when the child is placed in the restraint. The shoulder belt guides may not help achieve correct seat belt placement. Do not use this booster if the shoulder belt does not touch the child's chest. |
|------|-----------------------|-----------------|--|--|

***Eddie Bauer (Dorel)******Dorel Juvenile Group: 800-219-0509 / 866-611-3022 / 812-372-0141  
www.djgusa.com***

|      |        |   |                   |   |
|------|--------|---|-------------------|---|
| 276) | 3-in-1 | 02-331, 02-332, 02-531,<br>02-533, 02-537, 02-555 | 11/17/00-01/10/01 | Tether webbing could be cut and separate in a crash allowing excessive movement of the child. Contact mfg. for free repair kit. |
|------|--------|---|-------------------|---|

***Evenflo******800-525-2472 / 800-233-5921***

|      |                    |  |             |  |
|------|--------------------|--|-------------|--|
| 277) | 410                | 410                                      | 6/88-4/89   | Harness/shield. Call mfg. for repair info.     |
| 278) | Bobby Mac Champion | 411                                      | 4/85-4/90   | Buckle. Call mfg. for repair info.             |
| 279) | Bobby Mac Deluxe   | 412, 414, 415, 416                       | 4/85-4/90   | Buckle. Call mfg. for repair info.             |
| 280) | Booster Seat       | 470, 471                                 | 2/87-8/88   | Upholstery buttons. Call mfg. for repair info. |
| 281) | Booster Seat       | 242, 470, 471                            | 4/85-4/90   | Buckle. Call mfg. for repair info.             |
| 282) | Champion           | 224x                                     | 06/93-11/96 | Crash test failure. Call mfg. for repair info. |
| 283) | Champion           | 224x                                     | 06/93-11/96 | Crash test failure. Call mfg. for repair info. |
| 284) | Champion           | 219x, 224x,<br>225x, 229x                | 10/96-2/97  | Crash test failure. Call mfg. for repair info. |
| 285) | Dyn-O-Mite         | 441 thru 448                             | 1/85-1/89   | Crash test failure. Call mfg. for repair info. |
| 286) | Dyn-O-Mite         | 202, 441 thru 448                        | 4/85-4/90   | Buckle. Call mfg. for repair info.             |
| 287) | Infant Car Seat    | 456, 458                                 | Pre 4/89    | Crash test failure. Call mfg. for repair info. |
| 288) | Infant Car Seat    | 201, 202, 441 thru 446,<br>448, 456, 458 | 4/85-4/90   | Buckle. Call mfg. for repair info.             |

| <i>List #</i> | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i> | <i>Customer assistance Mfg Date</i> | <i>Problem Type and Consumer Action</i> |
|---------------|--------------------------------|---|-------------------------------------|---|
|---------------|--------------------------------|---|-------------------------------------|---|

**Evenflo (continued)**

|      |                                |                                       |               |   |
|------|--------------------------------|---------------------------------------|---------------|---|
| 289) | Joyride                        | Begins with 203, 205, 210, 435, 493   | 01/88-12/98   | When used as an infant carrier, the carry handle can unexpectedly release, cause the seat to flip forward, and cause infant to fall to the ground. Call mfg. for repair info. |
| 290) | On My Way                      | Begins with 206                       | 05/94-05/95   | Crash test failure. Call mfg. for repair info.  |
| 291) | On My Way                      | Begins with 207, 492                  | 12/95-07/97   | When used as a carrier, the locking mechanism on the handle can slip, flipping the seat forward and tossing the baby on the ground. Call mfg. for repair info.                |
| 292) | On My Way                      | Begins with 200, 211, 447, 499        | Pre- 02/10/00 | Safety Notification: Alignment posts in base can become bent after repeated use. Contact mfg. for free upgrade kit.   |
| 293) | On My Way base                 | 639001, 639002                        | Pre- 02/10/00 | Safety Notification: Alignment posts in base can become bent after repeated use. Contact mfg. for free upgrade kit.   |
| 294) | One-Step                       | 221, 401 thru 409                     | 04/85-04/90   | Buckle. Call mfg. for repair info.  |
| 295) | One-Step Deluxe                | 222, 223, 4176                        | 04/85-04/90   | Buckle. Call mfg. for repair info.  |
| 296) | Scout                          | 229x                                  | 06/93-12/96   | Crash test failure. Call mfg. for repair info.  |
| 297) | Scout                          | 219x, 224x, 225x, 229x                | 10/96-02/97   | Crash test failure. Call mfg. for repair info.  |
| 298) | Seven Year Seat                | 453, 454                              | 02/87-08/88   | Upholstery buttons. Call mfg. for repair info.  |
| 299) | Seven Year Seat                | 228, 453, 454                         | 04/85-04/90   | Buckle. Call mfg. for repair info.  |
| 300) | Travel Tandem (Joyride + base) | 205x                                  | 01/88-03/96   | Test failure with base. Use without base and call mfg. for repair info.   |
| 301) | Travel Tandem (Joyride + base) | 205x, 210x                            | 01/88-12/98   | When used as an infant carrier, the carry handle can unexpectedly release, cause the seat to flip forward, and cause infant to fall to the ground. Call mfg. for repair info. |
| 302) | Trooper (shield)               | 21940, 219164, 219180, 219186, 219188 | 11/95-1/96    | Instructions. Call mfg. for new instructions  |
| 303) | Two-in-One                     | 636x, 637x                            | 1/98-3/98     | In crash tests, the seat's backrest and base have separated when 5-point harness was being used. Call mfg. for information and replacement seat.                              |
| 304) | Ultara 1                       | 420                                   | 9/88-7/89     | Buckle. Call mfg. for repair info.  |
| 305) | Ultara 1                       | 231                                   | 2/93-8/93     | Plastic sleeve on harness. Call mfg. for repair info.   |
| 306) | Ultara II                      | 227                                   | 1/90-6/90     | Crash test failure. Call mfg. for repair info.  |
| 307) | Ultara II                      | 232                                   | 2/93-8/93     | Plastic sleeve on harness. Call mfg. for repair info.   |

**Fisher Price****ALL MODELS OLDER THAN 10 YEARS - DESTROY & REPLACE**

|      |                |            |            |   |
|------|----------------|------------|------------|---|
| 308) | Car Seat       | 9100       | Pre-1987   | Harness/shield. Call mfg. for repair info.              |
| 309) | Car Seat       | 9100, 9101 | 4/85-1/89  | Upholstery. Call mfg. for repair info.                  |
| 310) | Car Seat       | 9100, 9101 | 2/90-3/90  | Buckle. Call mfg. for repair info.                      |
| 311) | Car Seat       | 9100       | 4/85-8/85  | Shield. Call mfg. for repair info.                      |
| 312) | Car Seat       | 9100, 9101 | 5/87-1/89  | Buckle. Call mfg. for repair info.                      |
| 313) | Car Seat       | 9100, 9101 | 2/89-11/89 | Buckle (extended 5/87-1/89). Call mfg. for repair info. |
| 314) | Car Seat       | 9100, 9101 | Pre 91     | Loose button. Call mfg. for repair info.                |
| 315) | Car Seat       | 9100, 9101 | 2/91-1/92  | Harness/shield. Call mfg. for repair info.              |
| 316) | Car Seat       | 9100, 9101 | Pre 7/89   | Label on shield. Call mfg. for repair info.             |
| 317) | Delux Car Seat | 9104       | 6/15-9/92  | Buckle. Call mfg. for repair info.                      |
| 318) | Infant Seat    | 9149       | 1/91-2/91  | Shield. Call mfg. for repair info.                      |

| <i>List #</i>  | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i> | <i>Mfg Date</i> | <i>Customer assistance Problem Type and Consumer Action</i>   |
|--|--------------------------------|---|-----------------|---|
| <b>Fisher Price (continued)</b>  |                                |   |                 |   |
| 319)   | Infant Seat                    | 9173  | 9/94-10-94      | Air bag label. Call mfg. for repair info.   |
| 320)   | Booster                        | 9104  | 4/92-9/92       | Buckle. Call mfg. for repair info.  |
| 321)   | Booster                        | 9104  | 4/92-9/92       | Buckle. Call mfg. for repair info.  |
| 322)   | Safe Embrace                   | 79700   | 5/97-3/98       | Harness adjuster. Call mfg. for repair info.  |
| <b>Ford</b>  |                                |   |                 |   |
| <b>ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</b> |                                |   |                 |   |
| 323)   | Infant Love Seat               | All   | 81/82           | Plastic shell may develop cracks. Destroy & replace seat.   |
| <b>General Motors</b>  |                                |   |                 |   |
| <b>ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY &amp; REPLACE</b> |                                |   |                 |   |
| 324)   | Infant Love Seat               | All   | 81/82           | Plastic shell may develop cracks. Destroy & replace seat.   |
| 325)   | Child Love Seat                | All   | 3/84-11/84      | Plastic shell may develop cracks. Destroy & replace seat.   |
| <b>Gerry</b>   |                                |   |                 |   |
| <b>Contact Evenflo: 800-525-2472 / 800-233-5921</b>  |                                |   |                 |   |
| 326)   | Guardian                       | All   | 01/90-05/90     | Buckle. Call mfg. for repair info.  |
| 327)   | Secure Ride                    | 626   | 08/94-03-95     | Air bag label. Call mfg. for new label  |
| <b>Graco</b>   |                                |   |                 |   |
| <b>800-345-4109 / www.gracobaby.com</b>  |                                |   |                 |   |
| 328)   | GT 1000                        | All   | 1/85-1/86       | Crash test failure. Call mfg. for repair info.  |
| <b>International</b>   |                                |   |                 |   |
| <b>ALL MODELS OLDER THAN 10 YEARS - NO LONGER IN BUSINESS - DESTROY &amp; REPLACE</b>            |                                |   |                 |   |
| 329)   | Astroseat                      | All   | 12/80-7/81      | Buckle. Destroy & replace seat.   |
| <b>Kolcraft</b>  |                                |   |                 |   |
| <b>ALL MODELS OLDER THAN 10 YEARS - NO LONGER IN BUSINESS - DESTROY &amp; REPLACE</b>            |                                |   |                 |   |
| 330)   | Automate                       | 180-600, 180-601                                      | Pre 4/93        | Buckle. Call mfg. for repair info.  |
| 331)   | Carter Travel 5                | 13833, 13842, 13852                                   | 5/96-9/96       | Crash test failure of buckle. Call mfg. for repair info.  |
| 332)   | Dial-A-Fit                     | 180-200, 180-300                                      | 1/87-8/89       | Upholstery clips. Call mfg. for repair info.  |
| 333)   | Dial-A-Fit                     | 180-200, 180-300                                      | 10/88-8/89      | Crash test failure. Call mfg. for repair info.  |
| 334)   | Dial-A-Fit II                  | 180-600   | 11/90-8/91      | Crash test failure. Call mfg. for repair info.  |
| 335)   | Infant Car Seat                | 1383x   | 1/93-6/99       | Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info. |
| 336)   | Infant Restraint               | 43xxx   | 1/93-6/99       | Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info. |
| 337)   | Infant Rider                   | 138xx, 368xx  | 3/96-8/96       | Crash test failure of buckle. Call mfg. for repair info.  |
| 338)   | Infant Rider                   | 1312x, 1382x, 1383x, 368xx                            | 1/93-6/99       | Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info. |
| 339)   | Flip 'N' Go                    | 19127 thru 19130                                      | 1/85-3/87       | Shield. Call mfg. for repair info.  |
| 340)   | Flip 'N' Go II                 | 19127   | 1/85-3/88       | Shield. Call mfg. for repair info.  |
| 341)   | Perfect Fitt                   | 180-100, 180-150                                      | Pre 4/90        | Upholstery clips. Call mfg. for repair info.  |
| 342)   | Perfect Fitt                   | 180-150, 180-200                                      | 3/89-10/90      | Crash test failure. Call mfg. for repair info.  |

| <i>List #</i> | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i> | <i>Customer assistance Mfg Date</i> | <i>Problem Type and Consumer Action</i> |
|---------------|--------------------------------|---|-------------------------------------|---|
|---------------|--------------------------------|---|-------------------------------------|---|

**Kolcraft (continued)**

|      |                           |                                   |                   |   |
|------|---------------------------|-----------------------------------|-------------------|---|
| 343) | Perfect Fitt              | 180-200                           | Pre 10/90         | Upholstery. Call mfg. for repair info.  |
| 344) | Performa                  | All                               | 3/96-10-96        | Upholstery. Call mfg. for repair info.  |
| 345) | Performa                  | All                               | 1/96-7/97         | Buckle release force. Call mfg. for repair info.  |
| 346) | Playskool Car Seat        | 140-155, 180-400                  | 12/89-8/90        | Upholstery. Call mfg. for repair info.  |
| 347) | Playskool Car Seat        | 77001, 77002                      | 1/91-6/93         | Buckle. Call mfg. for repair info.  |
| 348) | Playskool Infant Car Seat | 77005, 77007                      | 1/93-6/99         | Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info. |
| 349) | Plus 4                    | 138xx, 368xx                      | 3/96-8/96         | Crash test failure of buckle. Call mfg. for repair info.  |
| 350) | Plus 4                    | 1382x, 1383x, 1384x, 368xx        | 1/93-6/99         | Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info. |
| 351) | Plus 5                    | 138xx, 368xx                      | 3/96-8/96         | Crash test failure of buckle. Call mfg. for repair info.  |
| 352) | Plus 5                    | 13833, 13842, 13852               | 5/96-9/96         | Crash test failure of buckle. Call mfg. for repair info.  |
| 353) | Plus 5                    | 1382x, 1383x, 1384x, 1385x, 368xx | 1/93-6/99         | Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info. |
| 354) | Rock 'N' Ride             | 13123                             | 2/85-6/85         | Plastic shell. Call mfg. to replace seat.   |
| 355) | Rock 'N' Ride             | 131-101                           | Pre 3/90          | Upholstery clips. Call mfg. for repair info.  |
| 356) | Secura                    | 43xxx                             | 1/93-6/99         | Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info. |
| 357) | Secure Fit                | All                               | 1/96-7/97         | Buckle release force. Call mfg. for repair info.  |
| 358) | Travel About              | 138xx, 368xx                      | 3/96-8/96         | Crash test failure of buckle. Call mfg. for repair info.  |
| 359) | Travel About              | 13833, 13842, 13852               | 5/96-9/96         | Crash test failure of buckle. Call mfg. for repair info.  |
| 360) | Travel-About              | 1382x, 1383x, 1384x, 1385x        | 1/93-6/99         | Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info. |
| 361) | Traveler 700              | All                               | 11/01/94-12/31/95 | Voluntary action: Buckle concerns. Call mfg. for repair info.   |
| 362) | Traveler 700              | 150-100                           | 1/91-8/91         | Cracks in plastic. Call mfg. to replace seat.   |
| 363) | Traveler 700              | All                               | 1/91-6/93         | Rusting of buckle. Call mfg. for repair info.   |

**Lin Lih/MCP Ent.****ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY & REPLACE**

|      |         |                  |            |  |
|------|---------|------------------|------------|--|
| 364) | Lin Lih | All              | ALL        | Counterfeit seat. Call NHTSA: 800-424-9393   |
| 365) | Lin Lih | 180-200, 180-300 | 10/88-8/89 | Crash test failure. Call NHTSA: 800-424-9394 |

**Mercedes-Benz USA****800-367-6372 - www.mbusa.com**

|      |                  |                      |                   |   |
|------|------------------|----------------------|-------------------|---|
| 366) | Booster          | BQ6910157, BQ6910163 | 02/01/97-07/31/99 | BabySmart airbag deactivation device may not automatically deactivate the passenger airbag. Contact mfg. for free replacement seat and instructional video. |
| 367) | Infant Restraint | BQ6910155            | 02/01/97-07/31/99 | BabySmart airbag deactivation device may not automatically deactivate the passenger airbag. Contact mfg. for free replacement seat and instructional video. |

**Playskool****Contact Kolcraft: 800-453-7673**

|      |          |                  |            |                           |
|------|----------|------------------|------------|---------------------------|
| 368) | Car Seat | 140-155, 180-400 | 12/89-8/90 | Upholstery. Call Kolcraft |
| 369) | Car Seat | 77001, 77002     | 1/91-6/93  | Buckle. Call Kolcraft     |

| <i>List #</i> | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i> | <i>Customer assistance Mfg Date</i> | <i>Problem Type and Consumer Action</i> |
|---------------|--------------------------------|---|-------------------------------------|---|
|---------------|--------------------------------|---|-------------------------------------|---|

**Playskool (continued)**

370) Infant Car Seat 77005, 77007 1/93-6/99 Carrier handle can release and allow the seat to rotate. Does not affect safety as car seat. Call mfg. for repair info.

**Pride Trimble/Virco****800-521-5198**

371) Click-n-Go 890, 891, 892 2/86-10/87 Crash test failure. Call mfg. to replace seat.

372) Click-n-Go 890, 891, 892 1/88-4/89 Crash test failure. Call mfg. to replace seat.

373) Pride Ride 832 1/88-4/89 Crash test failure. Call mfg. to replace seat.

**Questor****Contact Evenflo: 800-233-5921**

374) Kantwet Car Seat All 5/69-3/73 May pinch child's fingers. Call mfg. for repair info.

**Renolux (FBS)****ALL MODELS OLDER THAN 10 YEARS - NO LONGER IN BUSINESS - DESTROY & REPLACE**

375) GT 1000 All 8/88-10/88 Buckle/recline angle. Destroy & replace seat.

376) GT 2000 All 8/88-10/88 Buckle/recline angle. Destroy & replace seat.

377) GT 2000 All 1/92-1/93 Foam padding failed HIC (head injury) limits. Destroy & replace seat.

378) GT 2000 All 5/89-6/93 Flammability of upholstery. Destroy & replace seat.

379) GT 4000 All 1/92-1/93 Foam padding failed HIC (head injury) limits. Destroy & replace seat.

380) GT 4000 All 5/89-6-93 Flammability of upholstery. Destroy & replace seat.

381) GT 5000 All 1/92-1/93 Foam padding failed HIC (head injury) limits. Destroy & replace seat.

382) GT 5000 All 5/89-6-93 Flammability of upholstery. Destroy & replace seat.

383) GT 5000 All 2/90-4/91 Test failure/upholstery. Destroy & replace seat.

384) GT 5000 Turn A Tot All 1/92-1/93 Foam padding failed HIC (head injury) limits. Destroy & replace seat.

385) GT 5000 Turn A Tot All 5/89-6-93 Flammability of upholstery. Destroy & replace seat.

386) GT 5500 All 1/92-1/93 Foam padding failed HIC (head injury) limits. Destroy & replace seat.

387) GT 5500 All 5/89-6-93 Flammability of upholstery. Destroy & replace seat.

388) GT 7000 All All Remote may overheat/ fire hazard. Destroy & replace seat.

389) GT 7000 All 1/92-1/93 Foam padding failed HIC (head injury) limits. Destroy & replace seat.

390) GT 7000 All 5/89-6-93 Flammability of upholstery. Destroy & replace seat.

**Safeline Kids****800-829-1625****[www.tripleplayproducts.com](http://www.tripleplayproducts.com)**

391) Sit'n'Stroll 3240 6/9/97-8/9/97 Air bag labels. The air bag warning label was omitted from the seat cover. Contact Mfg. for new seat cover that has the required air bag warning label.

392) Sit'n'Stroll 3240 11/1/96-6/30/99 Labels recommend use rear-facing for children up to 25 pounds. Contact Mfg. for new labels to be placed over the existing labels. New labels recommend use rear-facing for children up to 22 pounds.

**Strolee****ALL MODELS OLDER THAN 10 YEARS - NO LONGER IN BUSINESS - DESTROY & REPLACE**

393) Wee Care All Pre 4/80 Crash test failure. Destroy & replace seat.

| <i>List #</i> | <i>Manufacturer Model Name</i> | <i>Model # ("X" = more numbers or letters follow)</i> | <i>Mfg Date</i> | <i>Customer assistance Problem Type and Consumer Action</i> |
|---------------|--------------------------------|---|-----------------|---|
|---------------|--------------------------------|---|-----------------|---|

***Strolee (continued)***

|      |             |          |            |   |
|------|-------------|----------|------------|---|
| 394) | Wee Care    | 599      | 12/80-5/81 | Upholstery. Destroy & replace seat.         |
| 395) | Wee Care    | 609, 610 | ALL        | Plastic shell. Destroy & replace seat.      |
| 396) | Quick Click | 605      | ALL        | Plastic shell. Destroy & replace seat.      |
| 397) | GT 3000     | All      | 87/88      | Crash test failure. Destroy & replace seat. |

***TRW******ALL MODELS OLDER THAN 10 YEARS - REPLACEMENT PROGRAM DISCONTINUED - DESTROY & REPLACE***

|      |                  |     |            |   |
|------|------------------|-----|------------|---|
| 398) | Infant Love Seat | All | 81/82      | Plastic shell may develop cracks. Destroy & replace seat. |
| 399) | Child Love Seat  | All | 3/84-11/84 | Plastic shell may develop cracks. Destroy & replace seat. |

***Volvo******800-458-1552 / 800-221-9136 / 201-768-7300***

|      |           |     |            |                                    |
|------|-----------|-----|------------|------------------------------------|
| 400) | ALL SEATS | All | Thru 12/88 | Buckle. Call mfg. for refund info. |
|------|-----------|-----|------------|------------------------------------|