Highw

Welcome

North Carolina Department of Transportation Highway Safety Barrier Installation Training

Instructor: Bill Fitzgerald, PE KLS Engineering, LLC (703) 858 1356

March 4 – 5, 2020







Guidance Presented



Ground Rules

- Be on time
- Participate
- Restrict sidebar conversations
- Turn off cellphones



Objectives of Course

This 1 $\frac{1}{2}$ - day course will help you to:

- Evaluate if a traffic barrier MAY be the best treatment to use at a specific site.
- Understand the principles of good barrier system design
- Identify installations that may not adequately shield all the significant hazards or secondary hazards.
- Recognize good installations and common errors for barriers and terminals and know how to avoid them.
- Understand when damaged barrier and/or terminal may no longer be functional.



Session 1:

Roadside Safety Problem, Clear Zone and Warrants for Barrier



Session 1





Session 1 Learning Outcomes

At the end of this session, you will be able to:

- Describe the primary Roadside Safety Concerns in North Carolina.
- \succ Identify the need for training.
- Define clear zone and barrier warrants.



National Roadway Departure Fatalities



North Carolina Crash Data Trend

North Carolina Total Fatalities vs. Roadway Departure Fatalities



Ref: FARS Data - 2018



Real World Crashes

NORTH CAROLIN



Session 1



Real World Crashes



Potential consequences of poorly Designed/Installed barrier systems include:

- Systems may not function as designed.
- Crash severities may be increased.



Must have a strong connection between systems



Session 1





Examples of improper installation of systems:



Session 1



1-13

Examples of improper installation of systems:





Clear Zone: A Definition



The unobstructed, traversable area provided beyond the edge of the through traveled way for the recovery of errant vehicles. The clear zone includes shoulders, bike lanes, and auxiliary lanes, except those auxiliary lanes that function like through lanes. Ref: AASHTO Roadside Design Guide, 4th Edition, Glossary



Clear Zone Principle



Session 1



As Wide as Practical

Do not compromise available clear zone

Session 1

Welcom To NORTH CAROLIN



1-17

Clear Zone Factors

Slope Type and Steepness

- Design Speed
- Traffic Volume
- Horizontal Curvature



Clear Zone



L. L. Sets



NCDOT Design Clear Zone Table

Design Speed	Design ADT	Foreslopes			Backslopes		
		1V:6H	1V:5H to	1V:3H	1V:3H	1V:5H to	1V:6H or
		or flatter	1V:4H			1V:4H	flatter
40 mph	UNDER 750	7-10	7-10	**	7-10	7-10	7-10
or less	750-1500	10-12	12-14	**	10-12	10-12	10-12
	1500-6000	12-14	14-16	**	12-14	12-14	12-14
	OVER 6000	14-16	16-18	**	14-16	14-16	14-16
45-50 mph	UNDER 750	10-12	12-14	**	8-10	8-10	10-12
	750-1500	14-16	16-20	**	10-12	12-14	14-16
	1500-6000	16-18	20-26	**	12-14	14-16	16-18
	OVER 6000	20-22	24-28	**	14-16	18-20	20-22
55 mph	UNDER 750	12-14	14-18	**	8-10	10-12	10-12
	750-1500	16-18	20-24	**	10-12	14-16	16-18
	1500-6000	20-22	24-30	**	14-16	16-18	20-22
	OVER 6000	22-24*	26-32*	**	16-18	20-22	22-24
60 mph	UNDER 750	16-18	20-24	**	10-12	12-14	14-16
	750-1500	20-24	26-32 [*]	**	12-14	16-18	20-22
	1500-6000	26-30	32-40 [*]	**	14-18	18-22	24-26
	OVER 6000	30-32*	36-44*	**	20-22	24-26	26-28
65-70 mph	UNDER 750	18-20	20-26	**	10-12	14-16	14-16
	750-1500	24-26	28-36 [*]	**	12-16	18-20	20-22
	1500-6000	28-32 [*]	34-42*	**	16-20	22-24	26-28
	OVER 6000	30-34*	38-46*	**	22-24	26-30	28-30

Session 1

* Clear zone distances can be limited to 30 feet unless in a high accident rate areas

Ref: Roadway Design Manual, Part I. Clear Zone Distances, 1-4N

Order of Preference

- 1. Remove hazard
- 2. Redesign hazard (make traversable)
- 3. Relocate hazard (move away from traffic)
- 4. Reduce Impact Severity (use breakaway design)
- 5. SHIELD hazard
- 6. Delineate hazard so motorist can avoid

Ref: AASHTO Roadside Design Guide, 4th Edition – Pg. 1-4





Barriers Must Be Less of a Hazard

Session 1





Potential Hazards

- Bridge Piers / Abutments / Railing Ends
- Drainage Structures / Ditches
- Sign and Luminaire Supports
- Permanent Bodies of Water
- Steep Embankments



NC Embankment Warrants



Ref: NCDOT Roadway Design Manual, Part 1, Chapter 3













Review Learning Outcomes

- Describe the primary Roadside Safety Concerns in North Carolina.
- Identify the need for training.
- Define clear zone and barrier warrants.



North Carolina Department of Transportation Highway Safety Barrier Installation Training

Session 2:

Testing Requirements and Performance Characteristics of Common Barrier Systems



Session 2 Learning Outcomes

At the end of this session, you will be able to:

- Understand how barriers are tested for crashworthiness
- Identify common barrier systems
- Explain how these barrier systems function
- Define the key components of a transition design



Crash Testing Guidelines

- In 1993, crash testing and evaluation criteria were published as NCHRP Report 350
- In 2009, the Manual for Assessing Safety Hardware (MASH) was published by AASHTO. It was used by FHWA as the testing standard for all new products
- In 2016, an update to MASH was adopted and a timetable for implementation of new installations complying with this edition was signed between FHWA and AASHTO



MASH Implementation Timeline

(AASHTO/FHWA Joint MASH Implementation Agreement Issued January 7, 2016)



MASH Test Conditions

Selection of a performance level is based on speed and traffic mix.

TL-1, TL-2, and TL-3: crash tests with small car and pickup truck with a 25° impact angle at 31, 44, and 62 mph, respectively.



NCHRP 350 comparison with MASH Crew Cab Truck





MASH Test Conditions (cont'd)

TL- 4: TL-3 + 15° impact angle, 56 mph Single-Unit Truck
TL- 5: TL-3 + 15° impact angle, 50 mph Tractor-Van Trailer
TL- 6: TL-3 + 15° impact angle, 50 mph Tractor-Tank Trailer



22,000 lbs.





80,000 lbs.

80,000 lbs.



Standard Barrier Systems

- Rigid Systems
- Semi-Rigid Systems
- Flexible Systems
- Median Barrier Systems


Barrier Systems: Rigid Barriers

Rigid Barrier Systems have little (between 0 to 1 ft.) deflection under the TL-3 pickup impact. They are generally anchored by some acceptable means.

Examples include:

- New Jersey Safety Shape Concrete Barrier
- F-shape Concrete Barrier
- Single or Slope Concrete Barrier
- Vertical Wall



Rigid Barrier



New Jersey Shape

F-Shape

Single Shape



MASH Testing of 32" New Jersey Shaped Concrete Barrier

Rigid Barrier – New Jersey Shape



TYPE IV - NO GLARE SCREEN PERMITTED

Type IV typically used

Types II & III for bifurcated crosssections

2" min Embedment minimizes Deflection

When large trucks are not an issue



Rigid Barrier – New Jersey Shape



2" min Embedment minimizes Deflection

Considered TL-5

For use when conditions warrant (typical urban, high truck volume

2-13



Rigid Barrier



Session 2

2-14

Note – No national criteria for when to use TL-4, 5, or 6



Rigid Barrier – New Jersey Shape



Session 2



2-15

Rigid Barrier: TL-5





Concrete Barrier - MASH – Free Standing







Session 2

an iter

Barrier Systems: Semi-Rigid

Semi-Rigid Barrier Systems have deflections of a few feet (between 2 to 5 ft.) under the TL-3 pickup impact.

Typically consist of beam and post elements.

TERMINOLOGY: Call it 31" (shows 2'-1" to bolt on standards)



Barrier Systems: Semi-Rigid

- W-Beam Steel Guardrail 350 Guardrail (29")
 - 12" wide W-beam rail section (12-gauge thickness).
 - Posts are spaced at 6'-3" centers, and the nominal rail height is 27" – 30"

Session 2

Rail splice at the post.

NCDOT

- Steel posts: W6 x 8.5/9.0 x 6'-0" long.
- Blocks: 6" x 8" wood or plastic.



2-20

SPWB with Steel Post & Steel Block-Out 27 5/8" Height







Guardrail with Wood Post & Wood Block-Out 27 5/8" Height







Guardrail with Steel Post & Wood Block-Out 27 5/8" Height







2-23

Barrier Systems: Semi-Rigid

> **31**" (shown in standards as 2'-1")

- 31" Height to Top of Rail
- Rail Splice mid-span.
- Post spacing 6'-3"
- Steel posts, W6 x 8.5/9.0 x 6'
- Offset Block: 8" recycled plastic or composite



31" Guardrail

Rail Splice Mid-Span





Session 2

8″



31" MASH Test 3-11







Session 2

H LITT





Session 2



2-27

H LIFE

Barrier Systems: Flexible Barriers

Flexible Barrier Systems typically have relatively <u>large deflections</u> Examples of Flexible Barriers include:

- Weak post W-beam
- Low tension cable
- High tension cable

No longer in standards To be removed from standards when MASH available



Barrier Systems: Flexible Barriers

Advantages of cable systems include:

- Low initial cost
- Lower deceleration forces
- Effective vehicle
 containment and redirection
- Installation conditions
 flexibility
- SNOW





Barrier Systems: Flexible Barriers

- High Tensioned Cable Barrier
 - Five different proprietary designs available
 - Each requires a unique proprietary terminal
 - Somewhat reduced deflections
 - Generally easier maintenance
 - Can retain effectiveness after most impacts



High-Tension Cable Systems

- Brifen
- Safence
- CASS (Trinity Steel)
- Nucor
- Gibraltar ★

Currently, NO system has passed all MASH 2016 testing

= APL



Four Cable System



Session 2



Welcome To NORTH CAROLINA



I LIGHT

Post Foundation and Typical Terminal









HTC On 4:1 Slope







Session 2

LISt

Barriers in the Median

Used to separate opposing traffic on a divided highway or to separate through traffic from local traffic.

Session 2

- Many barriers approved for roadside applications can be modified for use in the median.
- Width of the median is an important consideration.
- Also must consider the dynamic deflection of the barrier to avoid intrusion into opposing traffic.
- There are terminals designed specifically to shield the ends of median barriers.



2 - 35



MASH 27" W-Beam Median Barrier Test







MASH 31" Median Barrier Test











MASH 31" Median Barrier



Flexible Median Barriers

Session 2

Advantage of high tension cable is it may remain effective after impact.





Flexible Median Barriers

Annora Hanni Hanni







Transition Sections

When a softer (more flexible) barrier precedes a stiffer barrier, a gradual stiffening must occur between the two systems.

> An effective transition must provide the following:

- Adequate connection (TENSION continuity)
- Adequate length to gradually increase stiffness.







Inadequate Transition







Session 2

and L'Inter

Transition Sections

Successfully crash-tested transitions include the following essential elements (in addition to a structural connection):

- Additional and/or Larger Posts
- Nested rail (w-beam or Thrie-beam)
- Curbs (only as crash-tested transition unit), Rub Rails, and/or Flared Parapet Wall to Prevent Snagging


NCDOT Transition – Thrie-beam



ELEVATION





NCDOT Transition – Previous Standard



Session 2

2-46







LIGHT

8	ROADWAY STANDARD DRAWING FOR	1-18 STATE OF
SHEET 4 OF 7 862-03	STRUCTURE ANCHOR UNIT	NORTH CAROLINA DEPT. OF TRANSPORTATION
- 0F	GUARDRAIL ANCHOR UNIT TYPE B-77	DIVISION OF HIGHWAYS
ĭω	FOR F-SHAPE BARRIER	RALEIGH, N.C.



NCDOT Transition – With Curb







31" Transition







Session 2

W LIFE

Transition – 31", TL-2





Sincod Velcome To North Carolina State Line State Line

Connections to Low Parapets or Combination Rails

If the concrete parapet or portion of a combination rail is less than the transition height (31"), a steel plate may be applicable to adjust the height.





Transition: HTC to Guardrail (Spatial)



Review Learning Outcomes

- Understand how barriers are tested for crashworthiness
- Identify common barrier systems
- Explain how these barrier systems function
- Define the key components of a transition design



North Carolina Department of Transportation Highway Safety Barrier Installation Training

Session 3:

Testing Requirements and Performance Characteristics of End Treatments and Impact Attenuators



Session 3 Learning Outcomes

At the end of this session, you will be able to:

- Understand how end treatments and impact attenuators are tested for crashworthiness
- Identify common end treatments and impact attenuators
- Understand how these systems function
- Choose the appropriate system for a specific site



Guardrail End Treatments

A barrier end treatment must serve two functions:

- Provide the necessary TENSION of the guardrail system for downstream impacts
- > Be crashworthy when impacted end-on.



End Anchor – Historical







Session 3

End Anchor











L. L. Cott





TRAILING END UNIT ASSEMBLY

C.A.T.-1 SYSTEM

Session 3

NCDOT

Cable Guiderail Anchor Unit Placement



End Treatment MASH Test Matrix



Guardrail End Treatments

Types of End Treatments

- Buried-in-Cut (Detail, not in Standards)
- Tangent terminals terminal is parallel to the roadway or has a straight flare with a "slight" offset; all are Energy-absorbing
- Flared terminals terminal is placed on a flare to the roadway typically 3' or 4'; both non-energy- and energy-absorbing



Buried in Cut End Treatment

- Key design considerations:
 - For slopes steeper than 10:1, keep the height of the w-beam rail constant relative to the roadway grade until the barrier crosses the ditch flow line (but a max height of 47")
 - Use a flare rate, either 13:1 or appropriate for the design speed,
 - Add a w-beam rubrail when the distance between the bottom of the w-beam rail and the ground exceeds ~19",
 - Use an anchor of steel posts capable of developing the full tensile strength of the w-beam rail and <u>buried</u> 1' below ground



MASH Buried in Cut End Treatment







Session 3

I LITE

Buried in Cut (350 – to be Updated)



BIC Looking Across Roadway









Session 3

Single Rail BIC



Session 3

3-14



BIC Considerations – 10:1 Slope for Single



Session 3



Welcome To NORTH CAROLINA



BIC Considerations - LON

Any concerns with this installation?

Session 3



3-16

End Treatments - Terminology

CAT-1 – Cable Anchor Terminal – non-crashworthy device to develop Tension where there is no opportunity for end-on impacts (AT-1 – Anchor Terminal – no cable)

GREA – Guardrail End Anchor – crashworthy Pre-MASH devices

GREU – Guardrail End Unit – crashworthy MASH approved devices



End Treatments



Flared End Treatments

Historically used, most recently the SRT and FLEAT

Product ID (ex. NPYY-x	xxx):						
Company N							
Product N	A CONTRACT OF A						
		Delineators (862)(108	38)	7			
	gory: End Treatmen	nts •	-				
Product St	atus:						
Product ID Plant ID	Company Name	Product Group	Product Category	Product Name	Model Number	Product Status	Description
IP11-5773	Road Systems, Inc.	Guardrail and Delineators (862) (1088)	End Treatments	MFLEAT	1	Approved	MASH tested, Guardrail End Terminal
	the dealers	e and a firmed					
IP18-8095	Transportation Solutions	Delineators (862) (1088)	End Treatments	Guardrail Terminal	A	Approved	absorbing coupler that features a cutting tooth design.
1 <u>P17-7848</u> GR44	Lindsay Transportation Solutions	Guardrail and Delineators (862) (1088)	End Treatments	Max-Tension End Treatment	1	pproved	MASH tested; Telescoping, tension-based guardrail end terminal with an energy absorbing coupler that feature a cutting tooth design.
https	·//əni	ns ncd		lvond	or/an	nrov	edproducts/
Inceps	<u>.//ap</u>	<u>55.11Cu</u>	<u> 01.901</u>		01/42		

Flared End Treatment: Energy Absorbing

MFLEAT MASH Version of FLEAT (MASH 16)

- Curls the rail (by kinking) tightly towards the roadway.
- Steel post system; BLON at 4th Post
- TL-3 at 39' 7" straight flared length. 3-ft. offset.
- Cable-anchored, compression system



BLON – Beginning Length of Need

Ref: FHWA Eligibility Letter CC-143 dated 04/10/19



MASH MFLEAT





Flared End Treatment: Non-energy-Absorbing

> MASH SRT (Slotted Rail Terminal)

 W-Beam rails on a straight line and horizontal slots in rail

Session 3

- Offset 4'; 31" Height
- 37'-6" long, BLON at Post 4
- Cable-anchored system
 Not currently on APL

Ref: FHWA Eligibility Letter CC-140 dated 12/19/17



3-22



MASH Test 3-31: SRT



Because of the non-energy absorption, no hazard should exist within 150' downstream of post #1







Flared End Treatments on Flared Standard Run

The flare of the end treatment is measured from a line parallel to the ROADWAY:

For Energy Absorbing (MFLEAT) which has a 13:1 flare, there may need to be a "kink" either toward or away from the roadway, depending on the flare of the standard guardrail

For the SRT MASH, the offsets are measured from a line parallel to the roadway.

NCDOT guidance is to provide 25' of parallel guardrail in advance of any end treatment requiring a kink.




Flared End Treatments on Flared Standard Run SRT MASH - Schematic



Flared End Treatment Selection

- The contractor may choose any system on the Approved Product List meeting the design requirements
 - One is energy absorbing (currently MFLEAT)
 - One could be non-energy absorbing (SRT)

CDOT

What is **important** is to understand how the system works –a **FLARED** system should only be allowed if criteria have been met (LON and grading)

Session 3

3-28

Tangent End Treatment

.....

	Approved Resourc	oes	Business » Approve	ed Produc	Business	DMV	Newsroon		ograms
	Product Listing Seeds Producer/Supplier Technician Certification Minimum Sampling Guide		Product ID (ex. NPYY-xxxx): Company Name: Product Name: Product Group: Product Category: Product Status:						
									•
					End Treatments, Type MASH-16				
						Reset			
duct ID Plant	ID <u>Company Name</u>	e Product Grou	p Product Categor	y Product Name	Model Number P	roduct Statu	is <u>Description</u>		
<u>7-7819</u>	Trinity Highway Products	Guardrail and Delineators (862)(1088)	End Treatments, Type MASH-16	Approved				gent end terminal for use	
7-7851	Road Systems, Inc.	Guardrail and Delineators (862)(1088)	End Treatments, Type MASH-16	MSKT	Ą	pproved	MASH tested;Guardra	il End Terminal	
<u>8-8257</u>	SPIG Industry, LLC	Guardrail and Delineators (862)(1088)	End Treatments, Type MASH-16	SGET	Ą	pproved	terminal system in wheed to move down t	n <mark>ich an impact u</mark> he guardrail and	I) is a gating guardrail end upon the head causes the d dissipate the energy of t ts vehicles back onto the

Tangent End Treatment: Energy Absorbing

Section 24 Notes and Section 25 Notes (MASH 16)

- Kinks Guardrail when hit head-on or at a shallow angle
- Steel post system; BLON at 3rd Post
- TL-3 at 47' long; attachment to 31" Guardrail
- Cable-anchored system, Compression system





 PROVIDE A MINIMUM OF 12'-6" OF 31" W-BEAM GUARDRAIL BETWEEN THE GUARDRAIL TERMINAL AND A GUARDRAIL TRANSITION.





MASH MSKT



Session 3



NORTH CAROLINA



LIGHT

Tangent End Treatment: Energy Absorbing

Soft Stop (MASH 16)

- Impact head slides along panels, crushing them vertically, absorbing the energy of the vehicle in shallow angle impacts – works in tension
- TL-3 at 51' long; BLON at 16'-6"; 31" only





MASH Soft Stop







Session 3

TEH



MASH SGET



Session 3

3-35



NORTH CAROLINA

Tangent End Treatment: Energy Absorbing

MAX-Tension (MASH 16)

- The MAX system utilizes tensioned cables, telescoping panels, and a cutting tooth to absorb the kinetic energy and safely contain or redirect impacting – works primarily in tension
- TL-3 at 50' long; BLON at 9'-4 ½"; 31" only



Also on APL under a different category – End Treatments





MASH MAX-Tension







Tangent End Treatments on Flared Standard Run

The offset of the end treatment is measured from a line parallel to the ROADWAY:

If the standard flare is 25:1 or flatter, the end treatment may be placed on the standard flare line extended

If the standard flare is sharper than 25:1, a kink in the run must be provided so the end treatment is no sharper than 25:1

NCDOT guidance is to provide 25' of parallel guardrail in advance of any end treatment requiring a kink.



Tangent End Treatments on Flared Standard Run Schematic







MUST HAVE MANUFACTURER'S SHOP DRAWINGS AND **INSTALLATION MANUAL TO INSTALL / INSPECT ANY OF** THE PROPRIETARY END TREATMENTS



End Treatment Grading

- Special grading requirements for guardrail end treatments:
 - Flat terrain (10:1 or flatter) is required in ADVANCE of all end treatments so that vehicles are relatively stable on approach
 - Flat grading must extend *behind* post 1 (ADJACENT) so vehicle is stable at impact <u>and</u> stub height criteria is satisfied

Ref: FHWA Memorandum, Roadside Safety Hardware, May 26, 2015 with attachment and Ref: AASHTO Roadside Design Guide, 4th Edition, Section 8.3.3.



Stub Height Criteria



RDG Figure 4.1

Ref: AASHTO Roadside Design Guide, 4th Edition – Figure 4.1



End Treatment Grading Requirements

- Runout Distance Grading refers to the area into which a vehicle may travel after impacting a terminal ahead of its length-of-need point.
 - The lateral runout distance directly behind a terminal ideally should be at least as wide as the roadside clear distance immediately upstream of terminal.
 - The minimum recovery obstacle-free area behind and beyond a terminal should be approximately 75 ft. long.

Ref: AASHTO Roadside Design Guide, 4th Edition, Section 8.3.3.





a – Extend out to clear zone when practical; if not, it should be at least as wide as area upstream of the end treatment.

Session 3

b – LON Required; when LON cannot be provided due to site conditions, a minimum of 75' from post 1 may be acceptable



Flared End Treatment Grading - AASHTO





End Treatments (Anchorages, Terminals, and Crash Cushions) 8-5

Must have this full grading if a flared end treatment is used







Tangent End Treatment Grading - NCDOT



Need special Borrow bid item for 3R projects

Need Special Provision for Density



Tangent End Treatment Offset - NCDOT







Thing to Remember about End Treatments

Non-Energy Absorbing End Treatments will not shield objects directly behind and within End Treatment limits







Thing to Remember about End Treatments

Even Energy Absorbing End Treatment will not shield objects directly behind and within End Treatment limits











EXISTING END TREATMENTS



Tangent Guardrail End Treatment Energy Absorbing

SKT 350 (Sequential Kinking Terminal)(NCHRP 350)

Kinks panels when hit head-on or at a shallow angle

Session 3

- Wood or Steel post system (many options)
- TL-3 at 50' long; BLON at 3rd Post
- Cable-anchored, Compression system



Ref: FHWA Eligibility Letter CC-88 dated 3/8/05

CDOT



3-52

Tangent Guardrail End Treatment Energy Absorbing

- ET Plus (Guardrail Extruder Terminal)(NCHRP 350)
 - Flattens the rail element when hit head-on
 - Weakened wood or steel posts (several options available)
 - 50' long; attaches to either height w-beam system
 - BLON at 3rd Post
 - Cable-anchored, compression system

Ref: FHWA Eligibility Letter CC-12Q dated 3/15/10







Turndown



3-54

Non-crashworthy End Treatment

BCT Terminal

NCDOT

Breakaway Cable Terminal (BCT) NCHRP 230

Session 3

- W-Beam rail with a parabolic curve and 4-ft offset.
- No impact head or ground strut between the two end posts.
- Only two breakaway posts.
- Rail bolted to all posts.



Identification

Only

3-55

Non-crashworthy End Treatment

BCT Terminal



ALL THE ALL

Failed Test! Resulted in spearing





Guardrail End Treatments: W-Beam Median

					Busine	ss Di	Ne Ne	ewsroom	Programs	
	Approved Resources Product Listing Seeds Producer/Supplier Technician Certification		Business » Approved Products List							
						_			÷	
			Product ID (ex. NPYY-xxxx): Company Name: Product Name: Product Group: Product Category: Product Status:		-		-			
					End Treatments				•	
	Minimum Samplin	ig Guide	Produc	t Status;					Search Reset	
Product ID Plant	t ID <u>Company Name</u>	Product Group	Product Category	Product I	<u>Vame</u>	Model Number	Product Status	Description		
<u>NP11-5773</u>	Road Systems, Inc,	Guardrail and Delineators (862) (1088)	End Treatments	MFLEAT			Approved	MASH tested,	Guardrail End Terminal	
NP17-7848 GR44	Lindsay Transportation Solutions	Guardrail and Delineators (862) (1088)	End Treatments	Max-Tensi Treatment	210 0010		Approved	MASH tested;Telescoping, tension-base terminal with an energy absorbing coup a cutting tooth design.		
NP18-8095	Lindsay Transportation Solutions	Guardrail and Delineators (862) (1088)	End Treatments	MAX-Tensi Guardrall	ion Median Terminal		Approved		ension-based terminal wit pler that features a cuttin	

Guardrail End Treatments: W-Beam Median

MAX-Tension Median (MASH 16)

- The MAX system utilizes tensioned cables, telescoping panels, and a cutting tooth to absorb the kinetic energy and safely contain or redirect impacting – works primarily in tension
- TL-3 at ~50' long; BLON at Post 3 (~13'-4"); 31" only

Session 3

3-58





MASH MAX-Tension Median





Impact Attenuator

Crash test with blunt end:

Welcom To NORTH CAROLIN



Session 3



3-60

Impact Attenuator

Crash test with ramped end:

Welcome To NORTH CAROLINA







Impact Attenuator Theory



Harder back section to bring a pick-up truck to a controlled stop


Impact Attenuator, Sacrificial - Water Filled

Water-filled Barriers

Absorb M (MASH) / Sled(MASH) / ACZ 350 / TRITON CET

- Individual crash cushion designs vary by manufacturer, but they all function in a similar manner.
- Vehicles impacting the nose at an angle will not be redirected.
- No appreciable re-directive capability under most impact conditions.
- Typically used in work zones to shield temporary concrete barrier.



Impact Attenuator, Sacrificial - Water Filled

ts List	
WZTC - Category III	
	WZTC - Category III

<u>NP11-5771</u>	Lindsay Transportation Solutions	Work Zone Traffic Control	WZTC - Category III	Absorb 350		Approved for Provisional Use	*Must be approved by Steve Kite (919-814-4937) prior to use on NCDOT project.* The ABSORB 350 is a non-redirective, gating water filled crash cushion that has been successfully tested to NCHRP Report 350 TL-2&3.
<u>NP11-5884</u>	TrafFix Devices, Inc.	Work Zone Traffic Control	WZTC - Category III	SLED	Series 45044	Approved	PE Water Filled Crash Cushion w/Galvanized Steel Cables molded inside.NCHRP-350 for Test Level 1,2or3.Use as end treatment/crash cushion.
<u>NP16-7335</u>	Trinity Highway Products	Work Zone Traffic Control	WZTC - Category III	ACZ-350 Water Filled Crash Cushion	ACZ-350	Approved for Provisional Use	The ACZ-350 is a narrow, non-redirecting TL-2 and TL-3 impact attenuator
<u>NP99-3106</u> GR10	Energy Absorption Systems, Inc.	Work Zone Traffic Control	WZTC - Category III	Triton Barrier	Triton Barrier	Approved	The Triton Barrier® is a highly portable, water-filled barrier. Performance meets the FHWA NCHRP 350 TL-2 or TL-3 (with TL-3 kit) standard for longitudinal re-directive barrier. The Triton Barrier is certified as its own end treatment.



Impact Attenuator, Sacrificial - Water Filled

Session 3



Absorb M (MASH)



Sled (MASH)

NORTH CAROLINA





ACZ-350



TRITON barrier CET

3-65

Water Filled







Session 3

(100000)

LIGHT

Impact Attenuator, Sacrificial – Sand Barrel

Non-Redirective and Gating

- Individual barrel designs vary in shape by manufacturer, but they all function the same
- Arrays of sand barrels may be designed to shield any shape hazard
- Impacting vehicles will not be redirected.
- Since no re-directive capability, the corner of the hazard must be reasonably shielded.



Impact Attenuator, Sacrificial – Sand Barrel

Sand Barrels:







Energite

TrafFix Big Sandy (MASH)

Not Normally Used

CrashGard



Sand Barrels – Good Application







Sand-Filled Array





"For median width less than or equal to 40' use NON-GATING IAU's. For median width greater than 40' may use GATING or NON-GATING IAU's"



Impact Attenuators, Non-Gating

Non-gating as follows:

- Contains and redirects vehicles impacting along the sides of the device essentially its entire length
- Contains vehicles impacting the nose either headon or at a 15° angle.
- Approved for TL-2 (350) & TL-3 systems.
- Designed to shield a point hazard; either attached or stand alone.



Impact Attenuators, Non-Gating

Approved Products List

Product ID (ex. NPYY-xxxx):		
Company Name:		
Product Name:		
Product Group:		•
Product Category:	Impact Attenuators, Non-Gating	•

<u>NP19-8389</u>	Lindsay Transportation Solutions	Guardrail and Delineators (862)(1088)	Impact Attenuators, Non- Gating	Universal TAU- M	Approved	MASH compliant re-directive, non-gating anchored, partially reusable compression-based crash cushion
------------------	--	---	---------------------------------------	---------------------	----------	--

NCHRP 350 - Allowed if Conditions Mandate

<u>NP02-1527</u>	Lindsay Transportation Solutions	Guardrail and Delineators (862)(1088)	Impact Attenuators, Non- Gating	Universal TAU- II		Approved	The Universal TAU-II is a redirective, non-gating crash cushion. The system is available in lengths and capacities for both low and high speed applications
NP03-4111	Trinity Highway Products	Guardrail and Delineators (862)(1088)	Impact Attenuators, Non- Gating	WIDE TRACC	N/A	Approved for Provisional Use	the WideTRACC is test level 3 crash cushion and is avaliable in varying lengths and widths. can be configured for any appropriate width application.

Impact Attenuators, Non-Gating

TAU-M (MASH) and TAU IIR Systems (NCHRP 350)

- Can be attached directly to a W-beam or Thrie-beam median barrier as well as to a concrete safety shape.
- Designed to attach to a median barrier.
- Common set of parts for 36" to 102" widths in 6" increments (350)
- Consists of Thrie-beam panels, expendable or self-restoring (R) absorbing cartridges, steel diaphragms and two cables at the bottom to provide redirection.



Impact Attenuators, Non-Gating - Typical

QuadGuard M10 Tests CC-112



Impact Attenuators, Life Cycle

Approved Products List

SNCDOT

Product ID (ex. NPYY-xxxx):		
Company Name:		
Product Name:		
Product Group:		. *
Product Category:	Impact Attenuators, Life Cycle	•

<u>NP16-7403</u>	Energy Absorption Systems, Inc.	Guardrail and Delineators (862)(1088)	Impact Attenuators, Life Cycle	MAS Quadguard Elite		Approved for Provisional Use	**Contact NCDOT Mobility and Safety Field Operations prior to use at 919-773-2800**The QuadGuard Elite System offers the added value of reusable cylinders for applications with above average impact frequency. After a typical design impact, the system is
<u>NP16-7404</u>	Hill and Smith	Guardrail and Delineators (862)(1088)	Impact Attenuators, Life Cycle	Smart Cushion Innovations Crash Cushion	SCI100GM	Approved	Test Level III Crash Attenuator
<u>NP16-7405</u>	Hill and Smith	Guardrail and Delineators (862)(1088)	Impact Attenuators, Life Cycle	Smart Cushion Innovations Crash Cushion	SCI70GM	Approved	Test Level II Crash Attenuator
<u>NP16-7406</u>	TrafFix Devices, Inc.	Guardrail and Delineators (862)(1088)	Impact Attenuators, Life Cycle	Compressor System Crash Cushion	55000 Series	Approved	Low Maintenance, Severe-Duty, Self-Restoring, Re-Directive Impact Attenuator. NCHRP-350 approved as TL-3. Designed for repeated impacts with no need for repair. For use in Uni- directional or Bi-Directional applications up to 96 wide



Impact Attenuators, Life Cycle

- SCI Smart Cushion (MASH)
 - Variable Reaction Force
 - Re-usable with minimal component replacement
 - Needs repair before next hit







Example – Low Cost







Session 3

and Literate

Impact Attenuators, Life Cycle

- QuadGuard Elite (MASH)
 - Uses High Density Polyethylene cylinders to absorb energy
 - Essentially for use in locations where a high number of hits is anticipated.



REF: FHWA Eligibility Letter CC-57E dated 12/18/15



Example - Self Restoring

NORTH CAROLINA







Review Learning Outcomes

- Understand how end treatments and impact attenuators are tested for crashworthiness
- Identify common end treatments and impact attenuators
- Understand how these systems function
- Choose the appropriate system for a specific site



North Carolina Department of Transportation Highway Safety Barrier Installation Training

Session 4: Guardrail Design, Length of Need, and Site-specific Installation Considerations



Session 4 Learning Outcomes

At the end of this session, you will be able to:

- Understand the design principles affecting an optimal barrier installation
- Apply a field procedure to check Length of Need
- Be familiar with special designs to address sitespecific installation considerations



Guardrail Placement

Place AS FAR AWAY as Possible

without affecting function



Barrier Design Principles

- 1. Deflection
- 2. Slope in Front of Barrier
- 3. Guardrail and Curb
- 4. Soil Backing for Fill Locations
- 5. Flare Rate



Deflection





Results of Inadequate Deflection Distance



Deflection Distance - NCDOT



NOTE: WHEN OFFSET DISTANCE FROM FACE OF OBSTRUCTION TO FACE OF GUARDRAIL IS BETWEEN 3'-6" AND 5'-6", BEGIN 3'-1½" POST SPACING AT A POINT 25' BEFORE REACHING THE OBSTRUCTION AND CARRY THROUGHOUT ITS LENGTH. IF THE OFFSET IS LESS THAN 3'-6" USE CONCRETE BARRIER.

DETAIL OF RIGHT SIDE GUARDRAIL AT UNDERPASS

Session 4

4-7

Ref: NCDOT Standard Drawing 862.01, Sht 1

ICDOT



Successfully tested to MASH

Deflection distance = 19"; therefore offset from face of rail is 3'

Must start stiffening at 50' before hard point: 25' of half (3'- $1\frac{1}{2}$ ") post guardrail; 25' of quarter post guardrail



Principle 2: Slope in Front of Barrier



Any barrier may be placed anywhere on a 10H:1V or flatter slope.





Guardrail on Slopes

- Any barrier may be placed anywhere on a 10H:1V or flatter slope.
- Cable barrier may be placed on slopes of 6H:1V or flatter, but restrictions apply when placed in a swale. Special HTCB designs are available for placement on 4:1 slopes.



Principle 2: Slope in Front of Barrier



Session 4



4-11





Vehicle is contained and redirected but shows instability







Slope in Front of Barrier



Barrier in Sloped Median - Old System (29") ONLY -



Slope in Front of Cable Barrier

- Cable barrier may be placed anywhere on a 10:1 or flatter slope.
- Cable barrier may be placed on slopes of 6:1, but not in the area from 1 ft. to 8 ft. from the ditch bottom.



Location of Cable in Swales

MASH 2016 requires testing with a mid-sized vehicle because of this problem (NC experience)



CABLE SHOULD NOT BE PLACED BETWEEN 1' AND 8' BEYOND THE BOTTOM OF A DITCH

Session 4

Ref: AASHTO ROADSIDE DESIGN GUIDE, 4th EDITION - 6.6.1.1, Pg. 6-18



Barrier in Sloped Median

Which Side of the Median Should the Cable Barrier be Placed?




Principle 3: Guardrail and Curbs







Guardrail and Curbs







4-19

NCDOT Guardrail and Curbs







Session 4

4-20

Ref: NCDOT Standard Drawings, 862.01 Sht. 11

NCDOT

31" and Curbs

Successfully tested to MASH placed 6" behind a 6" high curb at TL-3



MASH TL-3 31" Placed 6" behind 6" high Curb



Session 4

4-22





MASH Tested – TL-2

Session 4



Welcome To NORTH CAROLINA



MASH TL-2 31" 6 ft. behind curb



End Treatments and Curbs

CURRENTLY UNDER STUDY – DO NOT BURY BEARING PLATE

Session 4

2" maximum height recommended





End Treatments and Curbs - NCDOT



GUARDRAIL AT FACE OF CURB



Careful with Breakaway Cable Anchorage Terminals – Don't let Bearing Plate be buried

Ref: NCDOT Standard Drawings, 862.01 Sht. 11



Principle 4: Soil Backing For Fill Locations









Soil Backing Recommendation



- 1. Slope can be as steep as 2:1 with 2-ft. backing in strong soil with 6 ft. posts.
- Backing can be less than 2 ft. with 2:1 slope in strong soil with 7 ft. posts. NCHRP 350 requires half post spacing – ONLY applies to 29" system

Ref: AASHTO Roadside Design Guide, 4th Edition – Figure 5.33, Pg. 5-41



Soil Backing – NCDOT



Soil Backing – NCDOT



In IT're



Soil Backing – NCDOT



H STA



31" with Posts on a 2:1 Slope

31" with face of rail at slope break point of 2:1 slope

Posts

- 8' long W6x9 posts ested
- Not recommended with Wood posts at this time
- 6'-3" post spacing

Blocks

- 8" block tested
- Not recommended without blocks at this time





31" with Posts on a 2:1 Slope

MASH Testing of MGS adjacent to a 2:1 Slope 8" blockout 8' long posts at 6'-3" spacing

Session 4

Working Width – 55.2" Eligibility Letter B-261



Principle 5: Flare Rate



Session 4

4-34





Flare Rate

Flared barriers are those that are not parallel to the edge of the traveled way. They are used to:

- Locate end treatments farther from the roadway.
- Lessen driver reaction to a roadside obstacle.
- Reduce total length of rail needed.
- Reduce nuisance hits.
- When tying to a bridge rail from a farther offset (in advance of transition)



Suggested Flare Rates

Table 5-9. Suggested Flare Rates for Barrier Design

Design	Design Speed		Flare Rate for Barrier at or Beyond Shy Line		
km/h	[mph]	Barrier Inside Shy Line	Rigid Barrier	Semi -Rigid Barrier	
110	[70]	30:1	20:1	15:1	
100	[60]	26:1	18:1	14:1	
90	[55]	24:1	16:1	12:1	
80	[50]	21:1	14:1	11:1	
70	[45]	18:1	12:1	10:1	
60	[40]	16:1	10:1	8:1	
50	[30]	13:1	8:1	7:1	

Notes:

A = Suggested maximum flare rate for rigid barrier system.

B = Suggested maximum flare rate for semi-rigid barrier system.

The MGS has been tested in accordance with NCHRP Report 350 TL-3 at 5:1 flare.

Flatter flare rates for the MGS installations also are acceptable. The MGS should be installed using the flare rates shown or flatter for semi-rigid barriers beyond the shy line when installed in rock formations.



Example of Benefit of Flare









Possibly Excessive Flare and Slope Steeper than 10:1





Tangent End Treatments on Flared Standard Run - <u>Repeat</u>

The offset of the end treatment is measured from a line parallel to the ROADWAY:

If the standard flare is 25:1 or flatter, the end treatment may be placed on the standard flare line extended

If the standard flare is sharper than 25:1, a kink in the run must be provided so the end treatment is no sharper than 25:1

NCDOT guidance is to provide 25' of parallel guardrail in advance of any end treatment requiring a kink.



Length of Need (LON) Definition

AASHTO

The length of effective barrier needed IN ADVANCE OF the hazard to intercept and redirect an encroaching vehicle.







LON Design Procedure for

Approach Barrier Layout



Ref: AASHTO Roadside Design Guide, 4th Edition, Figure 5.39, Pg. 5-49



Length of Need - AASHTO

- Calculating the length of need (X) for straight or nearly straight sections of roadway:
 - For <u>flared</u> guardrail installations:

$$X = \frac{L_{A} + (b/a) (L_{1}) - L_{2}}{(b/a) + (L_{A}/L_{R})}$$

Session 4

• For parallel guardrail installations:

$$X = \frac{L_A - L_2}{L_A/L_R}$$

DOT

Ref: AASHTO Roadside Design Guide, 4th Edition, Equation 5-1 and 5-2, Pg 5-51

Quick Field Check of LON

- 1. Stand on roadway edgeline opposite the upstream edge of the hazard.
- Beginning at the upstream face of hazard, walk upstream along the edge of traveled way a distance 300' (High Speed, 200' Low)
- 3. From this position, sight to the upstream, back edge of hazard (limit to 30' offset)
- 4. End treatment of barrier should lie near (± 20') the line of sight.



Beginning of BIG hole

POOR LON

Session 4

Welcome To NORTH CAROLINA





Length of Need – Adequate?









Length of Need – Adequate?



Session 4

4-47



Welcom To NORTH CAROLINA

Length of Need for Fill Slope



"L" OR LENGTH OF NEED ON THE APPROACH SIDE OF THE GUARDRAIL FOR A FILL SLOPE WARRANT FOR ANY CLASSIFICATION OF ROADWAY

DESIGN SPEED (MPH)	70	60	50	40
*L (FT.)	150'	125'	100′	75'

These are quite short compared to AASHTO

The LEAST

DETAIL 3 - 2C



Guardrail Placement in Special Situations

- Turnout Conflict (Side Access)
- Long Span (Omitted Post{s})
- Gaps between runs of barrier
- Extra Blocks
- Leaveouts (Blockouts) for Posts in Structural Pavement
- Guardrail Post in Rock



Guardrail Placement at Intersections



Session 4

4-50







Guardrail Placement at Driveways



Ref: NCDOT Standard 862.01, Sht 9

GUARDRAIL TREATMENT AT DRIVEWAYS


Omitting posts – old 29" guardrail



Session 4

4-54



31" – Omitting 3 posts



31" – Omitting 3 posts



Openings in Barriers



Check with maintenance, ROW, etc





Session 4

4-57

Openings in Barriers - NCDOT

ROADWAY DESIGN MANUAL

PART 1

4-58

DETERMINING GUARDRAIL LENGTHS OF NEED	3-2

NOTE: A space of less than 300' should not be left between guardrail installations. If less than 300' remains between installations, the guardrail should be extended through the area. Again, be sure there are no conditions that would preclude closure NCDOT

Extra Blocks – National Guidance

- Two block-outs (up to 16" deep) may be used at any time, for any number of posts.
- Three block-outs may be used at one or two posts in a section of guardrail.

Ref: AASHTO Roadside Design Guide – 3rd Edition, Section 5.4.1.6



Leaveouts in Structural Pavement



Ref: AASHTO Roadside Design Guide – 4th Edition, Figure 5-52



Guardrail Posts in Rock - AASHTO



≥18" 8" 2" For overlying soil depths (A) ranging from 460 to the embedment depth of th post, depth of required drilling (B) is equal to either 305 mm or the desired

4-61

Guardrail Posts in Rock - NCDOT

SECTION 862 GUARDRAIL

862-3 CONSTRUCTION METHODS

Where rock interferes with the proper installation of the post, excavate a shaft in the rock at least 9 inches wide, parallel to the roadway, by 23 inches long, perpendicular to the roadway and 24 inches deep. Place the post against the roadside edge of the shaft and fill in behind the post with Class VI select material, up to the top elevation of the rock. Fill the remainder of









TRANSITION FROM OR 1'-11" TO 2'-1" W-BEAM GUARDRAIL MOUNTING HEIGHT

HEET 4 OF 8	ROADWAY STANDARD DRAWING FOR GUARDRAIL INSTALLATION	DEPT. OF TRANSPORTATION DIVISION OF HIGHWAYS RALEIGH, N.C.
-------------	--	--



Review Learning Outcomes

- Understand the design principles affecting
 an optimal barrier installation
- Apply a field procedure to check Length of Need
- Be familiar with special designs to address site-specific installation considerations



North Carolina Department of Transportation Highway Safety Barrier Installation Training

Session 5: Installation/Common Errors of System



Session 5 Learning Outcomes

At the end of this session, you will be able to:

- Describe key components of barrier systems
- Identify common installation errors



Barrier Components



Figure 5-4. Definition of Roadside Barriers

REF: AASHTO Roadside Design Guide, 4th Edition, Figure 5-4



Key Components of Barrier Systems

- 1. Standard Run of Barrier
- 2. Transition to a Stiffer System
- 3. End Treatment
- 4. Impact Attenuator



1. Standard Run of Barrier

- a. Barrier Design Principles
- b. Height Measurement
- c. Tension Continuity
- d. Other Considerations
- e. Barriers in Work Zones



a. Barrier Design Principles

Deflection

Soil Backing

Session 5

Barriers and Curbs

NORTH CAROLIN



Slope in Front of Barrier

Flare Rate

Concrete Barrier Standards

 Roadside & Median Barrier - 32" Jersey shape from Finished Grade (46" for Type T)





> High Tension Cable Barrier

Dependent on Manufactured System





> High Tension Cable Barrier

• If the agency uses foundations, insure top is at proper height. This will effect the height of the cable.









High Tension Cable Systems

- The installation requirements are specific to the manufacturer. Referral to the manufacturer's installation manual is essential.
- The next slide shows an example of a installation checklist from a manufacturer's manual.



INSTALLATION CHECKLISTS



Cable Checklist

- Is there anything in front of the cable barrier that might cause a vehicle to vault the barrier or make the barrier ineffective? Items to look for include vegetation, rough ground, debris, or hard packed snow. These items should be removed if present.
- Has the roadside grading been completed correctly?
- Is there enough clearance between the barrier and the hazard for the expected barrier deflection. Human clearance is dependent upon post

acing.

Is the cable barrier the correct height?

Cable heights measured to the middle of the cable are as follows:

	Тор	Middle	Bottom	
Median & Roadside	29.5 in	25.5 in	21.5 in	
	[750 mm]	[650 mm]	[545 mm]	

- Are the cables properly tensioned?
- Are there irregular curves or joints where an errant vehicle might snag?
 Is there evidence of corrosion or damage to the cable? The cable should be scheduled for repair if either of these circumstances exist.
- Check to see that nuts are installed on the special locking hook bolts.

Post Checklist

Is there sufficient soil behind the posts to prevent them from being pushed out when the barrier is hit? Eroded or disturbed soil should be replaced and recompacted.

- Is the post spacing correct?
- Is there evidence of corrosion or damage to the posts? The posts should be replaced if either of these circumstances exist.





NUCORU.8. High Tension Cable Barrier System

Revised Jan-08 V.4.2 Page 22

Old Guardrail - Height Measurement

For slopes 10:1 or flatter, the height is measured from the ground directly beneath the rail

Only for the 27 3/4" Guardrail



PLACEMENT ON SLOPE



31" W-Beam Height Measurement







Rail too high

Rail too low



b. Height Transition Measurement



ELEVATION VIEW

NOTE: IF EXISTING GUARDRAIL IS LOWER THAN 1'-11", USE AN ADDITIONAL 12'-6" LONG SECTION OF GUARDRAIL,

862

02

FOR EVERY 1" OF HEIGHT DIFFERENCE, TO TRANSITION FROM EXISTING GUARDRAIL TO PROPOSED 2'-1" GUARDRAIL.

ROADWAY STANDARD DRAWING FOR GUARDRAIL INSTALLATION



Concrete Barrier

- Continuous reinforcement and/or anchored to/in the pavement, and for PCB, the connection pin and loops
- ➤ W-Beam
 - Splices with 8 bolts tying panels together, and some type of end anchor or structural tie to a rigid object/bridge rail (transition)
- High Tension Cable
 - Proprietary systems typically use a type of turn buckle between successive cables and end terminal anchors.



Cast In Place Concrete Barrier



Horizontal bars maintain continuity for cast in place barrier

Precast Concrete Barrier



Missing connection pin NO TENSION

5-17



- ➢ W-Beam
 - 8 bolts tying panels together
 - structural connection to a rigid barrier with 4 (min) thru bolts





Thrie Beam Connection

 5 bolts required for a structural connection to a rigid barrier







Temporary Barrier – Need for Tension

Session 5



Traffic Management Plan

Liters

5-21

COMPUTED BY: KIN MASHINGTON DATE: 05/26/2015 CHECKED BY: T.F. DUNCAN, PE BATE: 06/2/2005

STATE OF NORTH CAROLINA DIVISION OF HIGHWAYS

SUMMARY OF EARTHWORK

Name .	Status	Euse.	Embook. +%	Series (Wate
	A				
19-000309	27-84/4		1,148	1,124	
(新算論	38+48.63	12	1,332	1300	_
-34	¥	-			
19-00308	.22-51.00		33,417	21,942	-
54.874	TALS	186	35,681	35,481	_
-DET-10	MOVAL	16.40	-		18,445
PROJECT	TOTALS	18.552	35.407	26381	18.417
	EPLACE TOP			1,325	
IST. SECTIO	R MATERIAL		672	832	
GRAND	OTALS:	18351	17,279	28,416	DLAC .
54	¥1	18460111		BARCY	

UNRERCUT EXCAVATION = 500 CV SELECT GRAVILAR MATERIAL = 5000 CV FARRIC FOR SOIL STABILIZATION = 1500 SY

W - DISTANCE FROM EDGE OF LANE TO FACE OF GUARDRAD

SNCDOT

SUMMARY OF EXISTING ASPHALT

PAVEMENT REMOVAL

LINE	Station	Station	LOC LT/RTICL	AREA
4.	17-48.89	18+14.90	- a -	- 245
40	19-20.0)	39+38.00	a.	243
.167.	14-73.86	22181.55	a	2,391
-	_	-		
-				_
-				
				_
-				_
-				
-			100%	199
-			100.92	1,810
-		-	8431	Loon S

APPROXIMATE QUANTITIES ONLY. UNCLASSIFIED EXCAVATION, FINE GRADING, CLEARING AND GRUBBING, AND REMOVAL OF EXISTING PAYEMENT WILL HE PAID FOR AT THE LIMP SUM PRICE FOR "GRADING".

ROUECT N

B-1303

SHEET NO

3-8

セン 11 セン 12 セン 12 セン 19 セン 19 セン 19 セン 19 セン 19 セン 19	BEG, STA. 13+82.94 13+82.94 19+84.06 19+84.08 16+80.08 14+44.15 15+87.50	EN 174 1754) 14 1747 15 2340 15 21400 21400 21400 24.15 24.00	RT LT RT RT RT RT RT RT LT	8TRAIGHT 475.08 475.08 325.08 380.08	TEMP STRAIGHT 875.00	FACED	APPR. END 13+65.00 17+77.94 19+84.06 21+58.00	TRAIL. END 17+77.54 13+00.00 23+50.00 19+84.06		SHLOR WIDTH 13 13 13			APPR. END		TYPE II 1	0RAU 360	TEMP GRAU 350		-	EA	G N	6 6RI		GR WARRANTED ALONG ENTE OR WARRANTED ALONG ENTE
42 11 42 12 42 12 42 13 42 42 42 42 42 42 42 42 11 11 11 11 11 11 11 11 11 11 11 11 11	13+12:94 19+84.06 19+84.08 16+80.00 14+44.19	23+0 22+8 5 21/ 80 7 A15	LT RT LT RT HT RT	475.08 325.08			13+65.00 17+77.94 19+84.06	13+77.54 13+00.00 21+50.00	10 10 10	13 13 13	50	90	1		1	1				-		12	.50	
42 19 42 19 42 19 42 19 42 43 43 43 43 43 43 43 43 43 43 43 43 43	19+84.06 19+84.08 16+80.00 14+44.19	23+0 22+8 5 21/ 80 7 A15	RT LT RT HT RT	325.00	83.00		19+84.06	21+50.00	10	13	-			1	 1	1					_	13	.50	
4. 19 4. 10 4. 10	19+\$4.06 16+80.00 14+44.19	23+09-5 22+9-05 2100 74.15 -54.00	LT RT HT RT		\$35.00					13	80	50		1										
-DET- -DET- -DET- EUTOTAL:	16+80.08	22+9 05 21/ 80 7 415 54.00	RT HT RT	390.08	875.00		21+90,00	19+84.96	10	13	800					1					_	13	.50	
-DET- 1 -DET- 1 -DET- 1 BITOTAL:	14+44,19	217 - 80 37 - 615 - 54.90	HT R7		#35.00				10				1		1	1					_	17	1.50	
-DET- -DET- BITOTAL:		217 - 30 37 - 4.15 - 58.00	RT		\$25.00					10	50		1				1							REQUESTED BY TRAI
-DET- E BTOTAL:		7 A.15 58.00			\$25.60				10	13		90		1			1						_	REQUESTED BY TRA
BIOTAL:	15+87.50	58.00	1.7				15+00.00	23+00.00	6	8	50	- 50	1	1			2							REMOVE -DET-
			1 1.1		562,50		30+50.00	17+00.80	6	8	50	50	1	1			2							REMOVE-DET-
ACTIONS DUD				1,515.0	1,437,5										- 4	4								
DOMESTIC: NOT																		· · · · ·						
	III COMPANY																							
RAUSS			50,08	-200.00																				
YPE DE	4		18,75	-75.00		-													_	_	_	_		
SIP-GRAU	4		50,08	<u> </u>	-200.00															_	_	_		
NCHOR TOTALS:				-275.00	-300.00										 					_	_	_		
			-			-	-			-		_								_	_			
RAND TOTAL:				1,300.001.8	1,237.501.F										 4	4				_	_	556	IO L.F	
							-		-		-									-	-			
en:				1,380.00 LF	1,237,501.8	-				-					4	4				_	_	554	0 LF	
					<u> </u>	-														_	_	_	_	
DDITIONAL GUAR	ADRAIL POST:			5.EA																	_			

Session 5

Quantity Summary Sheet

And LITERS

5-22

Quantity Summary Sheet – blow-up



	V	7/05			
APPR. END	TRAIL. END	TYPE III	GRAU 350	TEMP GRAU 350	
1		1	1		
	1	1	1		
	1	1	1		
1		1	1		
1				1	
	1			1	
1	1			2	
1	1			2	
		4	4	6	

Need to re-establish tension in any altered guardrail – include in plan sheets

 Placement of GRAU (GREU) must abide by standard application criteria (Deflection and LON)



d. Other Considerations

≻Lapping

- For one-way traffic, all guardrail panels should be lapped in the direction of traffic with the upstream panel lapping the downstream panel including terminal elements and end sections. (Some exceptions, i.e. CAT)
- For two-way traffic always mount guardrail going with adjacent traffic, meaning rail laps will be opposite on each side of the road.

Structural Anchor Standards reference "LAP"



d. Other Considerations



Correctly Lapped


Typically NO WASHERS Unless called for in the plans



Session 5

5-26



Welcome To NORTH CAROLINA



Valley delineators could impede the bolt head pulling thru rail





Drilling of holes into the rail FOR THE RAIL TO POST CONNECTION is not recommended.

Session 5



NCDOT



Cutting a slot, hole or a rail section with a torch is NOT PERMISSIBLE



Using a torch on the rail element may compromise the strength of the rail.

Tests results have shown this becomes a weak point in the rail and can cause ripping and rupturing.



e. Barriers in Work Zones

Barrier should be in GOOD condition





5-30



e. Barriers in Work Zones

Flare rate appears to be too excessive here





2. Transition



LTEL

Old 29" Guardrail Standard



31 Inch Transition Design



Transition

Structural Connection

Welcome To NORTH CAROLINA



Session 5





Liber

Special Barrier Design – at Access



Session 5



5-35

- a. Manufacturers Manuals
- b. Post types
- c. Panel requirements
- d. Grading
- e. Breakaway Cable Anchorage
- f. Other Common Errors
- g. Delineation



3. End Treatment – Non-proprietary



Although the Buried-in-Cut (BIC) is the preferred (and best) end treatment, it can be constructed incorrectly





5-37

3. End Treatment – Non-proprietary



The point where the BIC crosses the toe of the backslope must be far enough upstream of the hazard. Top rail must capture vehicle



Welcome To NORTH CAROLINA

Session 5

RULE #1: Follow manufacturers instructions and standard plans.





5-39

and LIGHT

a. Manufacturers Manuals

Must follow manufacturer's installation instructions and State standards.



TAKE ADVANTAGE OF MANUFACTURER TRAINING FOR DETAILED INSTRUCTION **ON INSTALLING ANY OF THE PROPRIETARY END TREATMENTS**



Additional Resources

- Manufacturers website online training, installation manuals, etc.
- Maine DOT's Guardrail Inspection Series videos <u>http://www.dot.state.mn.us/design/roadsidesafety/links.html</u>



FLEAT and SRT videos are also available



BEAT and BEAT-2 a Installation Inspection Checklist



- The 6"x 6" end tube section is the special 1/8" thickness tube as supplied by the manufacturer with the corners cut at the approach end where the impact head is placed.
- Both the Roadside BEAT terminal and Median BEAT-MT terminal have at least one 18"-0" long 6"x 6" x 3/16" standard tube section joining with the special 12'-0" long end tube section.
- The end tube section is bolted to the standard tube section with the special rail tie splice.
- The height of the 6"x 6" box beam tubing is in accordance with the plans:
 -Roadside BEAT rail height = 2'-4"
 -Median BEAT-MT rail height = 2'-4"
- The 6"x 6" box beam tubing is attached to rail support brackets with proper hardware: -Roadside BEAT post bolt = 5/16" x 7 ½" hex bolt -Median BEAT-MT post bolt = 5/16" x 7 ½" hex bolt
- The rail support brackets are attached to posts with proper hardware:
 -Roadside BEAT posts #1 & #2 support bracket bolts = ½"x 2" hex bolt
 -Median BEAT-MT posts #2 through #5 support bracket bolts = ½"x 1 ½" hex bolt
 -Median BEAT-MT post #1 support bracket bolt = ½"x 2" hex bolt
- The upper and lower sections of post #1 are properly connected with a 5/8"x 8" hex bolt.
- The 3" weak posts have the soil plate positioned the same direction as the rail. -Roadside BEAT has a 3" weak post at post location #2 plus at least three more 3" weak posts spaced at 6'-0" within the standard downstream 6"x 6" box beam barrier. -Median BEAT-MT has a 3" weak post at post locations #2 through #5.
- The impact head is properly inserted into the end tube section with the large triangular gusset plates facing down. The bottom of the impact head is approx 12" above ground.
- The post breaker is installed on the proper side of post #1 and stabilized with two bolts.
- The 8" x 8" bearing plate at post 1 is correctly positioned with the 5" dimension up & the 3" dimension down. The anchor cable is taut and correctly installed.
- The Median BEAT-MT has a tether cable properly attached to restrain the impact head.
- If the posts were suggred, be sure the backfill material around the posts is compacted.





Additional notes:



INSTALLING THE RAIL PANEL TO THE POST WITHOUT OFFSET BLOCK AT POST 2

Complete the following steps to attach the rail panel to the post without offset block at Post 2:

Step	Actions	
1.	Select the Option A, Option B, or Option C to install the rail panel without offset block at Post 2:	
	Option A For Wood Post	 Insert a ⁵/₈" (16 mm) diameter x 10" (255 mm) HGR Post Bolt (PN-3500G) through the rail and the wood post at location 2. Place a ⁵/₈" (16 mm) Round Washer (PN- 3300G) under a ⁵/₈" (16 mm) HGR Nut (PN- 3340G) on the inserted bolt. Tighten the bolts. (There is no torque requirement for these bolts.)
	Option B For SYTP™	 Insert a ⁵/₅" (16 mm) diameter x 1¹/₄" (31 mm) HGR Blot (PN-3360G) through the rail panel and the hole in the SYTP™. Note: For SYTP stubs, use the hole in the SYTP™ that will place the rail at the correct height. (If there are two (2) sets of holes in the SYTP™ stub for attaching the rail.)
	Option	 Place a ⁵/₈" (16 mm) Round Washer (PN-3300G) under a ⁵/₈" (16 mm) HOR Not (PN-3340G) on the inserted bolt.
	C For HBAT Post	Do NOT bolt the rail panel to the HBA™ post at location 2.
		WARNING: Do NOT bolt the rail to the HBA™ post at location 2. Failure to follow this warning could result in serious injury or death in the event of a collision.

b. Post Types

Each manufacturer may have several different types of post, even for the same system - both currently approved and previously used.

Must consult with the installation manual of the specific model being worked with for proper post type.

Only one generic special post for terminals – the CRT post with large holes to weaken it.



Controlled Release Terminal (CRT) Post





c. Panel Types

Each system may have one or more different rail panels.

Must consult with the installation manual of the specific system for proper panel type



c. Panel Types SRT Rail with a FLEAT impact head



d. Grading

Check grading compliance with Standard Drawing (or plan details).

Check grading material for proper density. (Material must be compacted so it won't erode.)

CDOT











Tangent Terminal Grading - NCDOT ROADWAY STANDARD DRAWING FOR 862

GUARDRAIL PLACEMENT



Need special Borrow bid item for 3R projects

Need Special Provision for Density



d. Grading

Improper Grading

NCDOT



5-52

A common error with all end treatment types.

Welcom To NORTH CAROLINA

d. Grading



Telltales of poor grading

- Soil tubes/foundation posts installed too high
- Soil plate showing
- Strut too high

(Also bearing plate misaligned)

Common Error applies to both energy absorbing and non energy absorbing terminals



Substandard Grading – DOCUMENT



e. Breakaway Cable Anchorage (BCA) Assembly

Bearing Plate & Strut

- Should be in up position and secured to post.
- Strut secured at posts required locations.



Secure bearing plate

Strut secured at breakaway posts 1 & 2



e. Breakaway Cable Anchorage Assembly





Missing Bearing Plate

Wrong Bearing Plate



e. Breakaway Cable Anchorage Assembly

Buried and upside down bearing plate – won't release

> Welcome To NORTH CAROLINA

Session 5



5-57



Welcome To NORTH CAROLINA

e. Breakaway Cable Anchorage Assembly

Session 5

Upside down bearing plate – may not release



5-58



e. Breakaway Cable Anchorage Assembly

Most systems require an anchor bracket and anchor cable.

- Anchor block must release from rail if system has impact head
- Non-energy absorbing system does not have to release from rail.



Energy absorbing



Non-energy absorbing



e. Breakaway Cable Anchorage Assembly

- Check the type and combination of breakaway posts against the State standards and the manufacturer's instructions.
- Not all posts in all terminals use a block-out.
- Check to see that the correct cable anchor bracket is used and it is properly attached to the rail.



e. Breakaway Cable Anchorage Assembly

Anchor Cable

- Should be taut, lift up 1" or less
- Tightened by holding cable at bottom, not allowing cable twist.






f. Other Common Errors

Terminals with an impact head: the end of the first W-beam rail section should be pushed against the throat area of the impact head so the end of the rail cannot be seen.

CDOT





f. Other Common Errors **Post Installed Backwards**



Welcome To NORTH CAROLINA





f. Other Common Errors

End treatments with an impact head should be parallel* with the top of the rail.



* For Softstop see manufacturers manual



f. Other Common Errors

Energy Absorbing (compression based) Terminals MUST be installed on a straight line

Manufacturers of Tension-based systems also require straight line

ICDOT



f. Other Common Errors



f. Other Common Errors (video)

Welcome To NORTH CAROLINA



Session 5



f. Other Common Errors

FLEAT head on SRT rail - HORRIBLE

NORTH CAROLIN



f. Other Common Errors



Whether construction or maintenance, never would have THREE slotted rails.



f. Other Common Errors





f. Other Common Errors



Session 5

It's easy to tell if it's wrong – the slot guards must be on the same end of the slots for the first (can't get it wrong) and second rail panels



f. Other Common Errors



Welcome To NORTH CAROLINA Cable does NOT go through slot guard.



f. Other Common Errors



Unrestrained bearing plate





f. Other Common Errors

Bolt only impact head to post #1, NOT rail panel.

- Wood Post Lag Screws (screwed in only)
- Steel Post Hex Bolts

NORTH CAROLINA





5-74

Refer to manufacturer's installation instructions.



f. Other Common Errors

NO rail to post connection at post 1 of systems with impact heads.

Note the WRONG rail for this terminal.

NCDOT



f. Other Common Errors

DO NOT place any washers or delineators on the face of a guardrail terminal unless specifically called for or allowed in manufacturer's installation instructions

SNCDOT



f. Other Common Errors

Improper bolt @ post 2





Refer to manufacturer's installation instructions.

Session 5



Welcome To NORTH CAROLINA

f. Other Common Errors



Session 5



f. Other Common Errors



f. Other Common Errors

Excessive flare on a end treatment.





f. Other Common Errors



Improper Application – Hazard within terminal length





NORTH CAROLINA

f. Other Common Errors



Improper Application – no runout for a non-energy absorbing terminal...LON (as well as grading)





f. Other Common Errors

NORTH CAROLINA



Improper Application – Terminals should have 7' separation (and the sign should be beyond the terminal system)





g. Delineation







- a. Manufacturers Manuals
- b. Grading





a. Manufacturers Manuals

NCDOT

Must follow manufacturer's installation instructions and State standards.



Session 5

a. Manufacturers Manuals

Construct concrete pad if called for per manufacturer's requirements or state standards.

Clean out drilled holes WELL!!

NCDOT



5-87

a. Manufacturers Manuals

- Anchor bolts are required to secure the system to concrete pad. Number of bolts and length of bolts vary with systems.
- Bolts are typically required to be epoxied into concrete pad.
- Bolts may have a torque value.

Cutting bolt prohibited

Full bolt depth required





Must follow manufacturer's installation instructions.





a. Manufacturers Manuals

- Backup varies among systems.
- May be connected to a barrier or may be a stand alone





Must follow manufacturer's installation instructions.





a. Manufacturers Manuals

NORTH CAROLINA

• When system is placed in a bidirectional application a transition is required to prevent back side snagging



Must follow manufacturer's installation instructions.

Session 5



a. Manufacturers Manuals

• Place appropriate delineation on front of system







Must follow manufacturer's installation instructions and state guidance





Welcome To North Carolina

b. Grading

Grading should be so an errant vehicle impacts the system in a stabled condition – same as end treatments



Suspect Grading

Must follow manufacturer's installation instructions.





Ex: results of improper torque values applied to fender panels.



Must follow manufacturer's installation instructions.





Session 5



- Describe key components of barrier systems
- Identify common installation errors



North Carolina Department of Transportation Highway Safety Barrier Installation Training

Session 6: Maintenance of Systems



Session 6 Learning Outcomes

At the end of this session, you will be able to:

- Recognize how damaged barrier MAY BE assessed for maintenance response.
- Understand when a damaged barrier end treatment MAY no longer function.
- Effectively delineate/treatment of damaged hardware prior to repair.



Introduction

- Barriers should be routinely observed.
- Barrier may need to be repaired after crashes or long term exposure.



Session 6


Need To Repair

Welcome To NORTH CAROLINA



Session 6





LIGHT



Available for purchase

Available online



NCDOT Policies

g.D. Doins

JAMES B. HUNT. JR.

GOVERNOR



STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION DIVISION OF HIGHWAYS

Sam Hunt Secretary 1

C

patte.

December 15, 1993

P.O. BOX 25201, RALEIGH, N.C. 27611-5201

MEMORANDUM TO:	Division Engineers
FROM:	C. A. Gardner, Jr., P.E. C A. Gardner, Jr., P.E. C Maintenan

SUBJECT: Guardrail/Attenuator Maintenance Policy

Attached for your immediate implementation is the maintenance policy for repairing or replacing accident damaged guardrail and attenuators on the State Highway System. Please insure that all your personnel are made aware of the policy.

This replaces all existing policies for guardrail repairs and maintenance. Revision to the Interstate Maintenance Manual will be sent in the near future.

If additional information is needed, please advise.

CAG/bj



STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION

MICHAEL F. EASLEY

LYNDO TIPPETT SECRETARY

Median Barrier Inspection and Maintenance Policy

The median guardrail program in North Carolina has been saving lives since its implementation in the late 1990s. There has been a 90 percent reduction in fatal and severe injuries in acrossmedian crashes. Though the end of 2005, more than 150 lives have been saved and countless injuries have been avoided.

NCDOT is very concerned with the maintenance and operation of its entire transportation system. A recent report to the N.C. General Assembly shows that guardrails statewide are being maintained at an acceptable level.

The recent tragic event where a family was killed by a vehicle that crossed the median has placed an additional emphasis on median barrier maintenance. While our history with the median barrier program shows that a vehicle passing through a damaged section of barrier is very rare, NCDOT will implement a more in-depth review of our median barriers throughout the state.

We will continue to work with the N.C. Highway Patrol, local law enforcement and emergency responders to improve the notification process following crashes into the barriers. Effective immediately, all 14 highway divisions of the North Carolina Department of Transportation will assign appropriate staff to inspect weekly all highway sections with median guardrails. This inspection will include identifying and marking the non-functioning guardrail, and then scheduling it for repair. As soon as the department completes its inspection, the department shall immediately, and in no instance more than 24 hours, notify the appropriate contractor of the damaged guardrail and the contractor will begin repairs as soon as reasonably possible.

NCDOT is a national and international leader in median barrier safety. We have helped other



NCDOT Guidance

GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL

Course Number: MNT 496

Original Publication April 2000

State Road Maintenance Unit North Carolina Division of Highways North Carolina Department of Transportation

Session 6



Timing of Repair

RESPONSE TO NOTIFICATION OF DAMAGE

Attenuator or guardrail damaged by accident is to be scheduled for repair/replacement <u>as soon as possible</u> after the condition is known. If the damaged area is determined by the engineer to present a traffic hazard by nature of the damage itself, or by exposing traffic to some previously protected situation, the area will be properly marked by barricade, warning lights, cones, truck mounted attenuator, etc., as appropriate until such time as repair has been completed.

Session 6

REF: NCDOT GUARDRAIL/ATTENUATOR MAINTENANCE POLICY. December 1993



Timing of Repair (cont'd)

RESPONSE TO NOTIFICATION OF DAMAGE (cont'd)

Examples would be straight pieces of rail exposed by the destruction of an anchor unit, bridge abutment exposed, sign post protection rail destroyed, or areas where rail has been damaged so badly it has to be removed. If there is any question as to the need for delineating such hazards, then the areas should be properly marked.

REF: NCDOT GUARDRAIL/ATTENUATOR MAINTENANCE POLICY. December 1993



Timing of Repairs

2015 House Bill 97

§ 136-18.05. Establishment of "DOT Report" Program.

problem. Excluding potholes, which shall be repaired within two business days of the date the report is received, the Department of Transportation shall properly address (i) safety-related citizen reports no later than 10 business days after the date the report is received and (ii) non-safety-related citizen reports no later than 15 business days after the date the report is received. The Department shall determine, in its discretion, whether a citizen report is safety-related or non-safety-related. The Department shall transmit

Session 6



Damaged End Treatments

Spear –worse than no tension – must be treated (drop rail) immediately- Severe

Session 6



Damaged End Treatments

Spear –worse than no tension – Protect spearing end immediately- Severe

NORTH CAROLINA



Session 6

Damaged End Treatments



Added end section still leaves blunt end



Session 6

Temporary Barrier Delineation

Delineate damaged areas while evaluating damage. Make repairs as soon as practical.



Session 6



Temporary Barrier Delineation

For Cable barrier, removal of damaged posts will eliminate a spearing obstacle for opposing traffic.



Session 6



For HTC Barrier, Keep the Cable Intact

Alternatives to cutting the cable include:

- Removing the vehicle by towing it in the opposite direction from which it hit the system.
- Loosening the cables at the turnbuckles.
- Release the cables at the anchor.
- Cutting the turnbuckle (preferred method to cutting the cable). The adjacent posts on either side of the turnbuckle need to be removed. Be sure that all personnel are clear of the cable and always cut the center of the turnbuckle, between two undamaged posts away from the impact area.



Evaluate the Site

DECISION TO REPAIR/REPLACE OR ELIMINATE GUARDRAIL

Consideration <u>should</u> be given to eliminating the need for the rail by flattening the slope and/or eliminating the hazard. The warrants in the Roadway Design Manual and the drawings in the Roadway Standard Drawings Manual should be used in this determination. The department that eliminates the hazard is responsible for coordinating the removal of the guardrail by the county road maintenance personnel.

REF: NCDOT GUARDRAIL/ATTENUATOR MAINTENANCE POLICY. December 1993



Evaluate the Site

5.2 – Repair or Eliminate

Before repairing the guardrail, consider if it can be eliminated. If the slope can be flattened or the hazard relocated, the barrier is not necessary.

If the roadside obstacle is no longer there, the guardrail is itself a hazard and should be removed

Flatten the slope



REF: NCDOT GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL. April 2000



Determine Extent of Damage



SAFETY-RELATED ????



6-19

When guardrail has been hit, determine the extent or severity of damage. If the damage is minor or so slight that it will function to shield the hazard, schedule the repair with other work. If the damage is severe, schedule it for repair as soon as possible. Until then, clear debris from the road and shoulder, then set out barrels or barricades to warn motorists.

REF: NCDOT GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL. April 2000

Session 6

NORTH CAROLINA



Guardrail – Damage Modes

Severely Damaged

- Rail beam has been severed
- Beam is crushed more than 18" out of line or
- Three or more posts have been broken

Severe damaged needs to be repaired as soon as possible



REF: NCDOT GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL. April 2000



Guardrail – Damage Modes

Moderate Damaged. Repair later if the guardrail will still function properly.

Minor Damage is aesthetic. Repairs may not be needed at all.

Supervisor needs to make decision – is moderate "safety-related" or not; this was intent of NCHRP 656

REF: NCDOT GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL. April 2000



Guardrail

How much deflection (~ 11") – Per TM = moderate



Bends within compressive terminal may cause unwanted buckling – little energy absorption – Safety-related



Session 6



Post separation – Severe or moderate? If height is too low (?"), penetration is likely - Severe











Cable Rail – Damage Modes

Severely Damaged

- Any cable is broken or pulled loose from the anchor or
- Cable is sagging to the point that it would not function properly when hit or
- Four or more posts have been knocked down.

Severe damaged needs to be repaired as soon as possible

REF: NCDOT GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL. April 2000



Cable Rail



End Treatments – Damage Modes

Severely Damaged

- One or more broken posts
- Rail that has been torn loose or
- Damaged cable assembly.

Severe damaged needs to be repaired as soon as possible



REF: NCDOT GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL. April 2000



End Treatments



This could act like a spear if not repaired expeditiously - Severe

Welcome To NORTH CAROLINA

You need to have the manufacturer's installation manual to repair these systems.

シートの見たたにはないのである。

Session 6



End Treatments

- Check for nuisance hits on end treatment to be sure post #1 is not damaged.
- Even with claims of "reusability"
 use best judgment and closely examine all salvageable parts.
- Impact Heads may be re-usable based on state policy and manufacturers recommendations (generally say no).





Sheared end post -No tension capability – Per TM - Severe





Welcome To NORTH CAROLINA





No tension capability and possible spear – Severe

Welcome To NORTH CAROLINA

Non-Energy Absorbing Terminal WRONG here – no Runout Don't know why memorial is here



Session 6





SRT first rail only – not as tested. Light pole nearby may also be a problem. Severity - ????

Welcome To NORTH CAROLINA



Session 6

Impact head not parallel to rail – don't know how serious – Doubt Severe; Just POOR workmanship

ANT ANT ANT ANT ANT



Session 6

6-35



Welcome To NORTH CAROLINA







End Treatments



Bearing plate misaligned Moderate

Welcom To NORTH CAROLINA



Buried plate may not release Severe



Session 6
Missing bearing plate and cable - No tension capability – (Also the head should be parallel to top of rail) – Per TM - Severe











Damaged End Treatments

No tension, impact head damaged - Severe



Urgency of Repair ???





NORTH CAROLINA

Session 6

Urgency of Repair ???



This is a blunt end until repaired - Severe Have manufacturer's Installation Manual available.





NORTH CAROLINA

Impact Attenuators



Ensure all mounting hardware is correct and Repaired per Installation Manual







Impact Attenuators



Typical QuadGuard Cartridges

Typical Universal TAU Cartridges



Place proper cartridges in the correct system & in the proper order



Impact Attenuators



Place sand container in the correct position with the correct amount of sand.

Session 6

NORTH CAROLINA



6-47

REPLACEMENT/REPAIR OF GUARDRAIL COMPONENTS

A. Rail (Steel}

The accident damaged section of rail <u>shall</u> be replaced/repaired to the current design standard as practical. It should be noted when only a portion of a rail system is damaged, consideration should be given to replacing the remaining undamaged length to current standards. However, when the undamaged length of remaining rail is less than 100 feet, the entire rail system shall be replaced to current design standards.

For pre-31" guardrail, the repaired guardrail should be to the latest 29" standard, especially related to height.



A short section of weak post rail should be replaced by standard blocked out W-beam rail

Damaged sections of rail must be repaired to the current design standard as practical. For example, if an old weak post guardrail system that is shielding a hazard has been hit, the damaged section should be replaced by the standard blocked out W-beam system. Note that a 50' transition will be needed from the old weak post rail to the new strong post rail to minimize pocketing effects.

REF: NCDOT GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL. April 2000 p 25



REPLACEMENT/REPAIR OF GUARDRAIL COMPONENTS

B. Rail (Cable)

The damaged section of cable rail <u>shall</u> be replaced/repaired to the current design standard.

It should be noted that periodic inspections of the cable tension is required to insure its proper function. Additionally, large vegetation shall not be allowed to grow within 15 feet of the cable as the system is designed to deflect 15 feet under impact.



REPLACEMENT/REPAIR OF GUARDRAIL COMPONENTS

C. Terminal End Section

The accident damaged end section <u>shall</u> be replaced/repaired to the current design standard except as follows:

Exceptions:

- When only the guardrail end section (buffer or terminal end design) has been damaged (bent), with no post damage, it may be repaired with like kind.
- When adequate shoulder width cannot be obtained economically to meet the current design standard contact Roadway Design for an alternate design.



If any posts of a sub-standard end treatment have been broken, it should be upgraded



REF: NCDOT GUARDRAIL INSTALLATION AND/OR REPAIR PROCEDURE TRAINING MANUAL. April 2000



REPLACEMENT/REPAIR OF GUARDRAIL COMPONENTS

D. Structure Anchor Unit

The accident damaged guardrail attached to a structure (ex: bridge, concrete barrier, etc.) <u>shall</u> be replaced/repaired in accordance with current design standard. If field conditions prevent the use of standard design and it is structurally sound to attach to the structure, assistance in the design of an acceptable replacement and/or repair is available through the Road Maintenance Unit as needed.



<u>REPLACEMENT/REPAIR OF IMPACT</u> <u>ATTENUATORS</u>

Damaged or malfunctioning attenuators shall be replaced/repaired to the current design standard.

Attenuators should be inventoried by type and location and maintained on a regular schedule (every 6 months) to insure proper function.



Median Barrier Inspection/Maintenance

- Requires weekly inspection by each NCDOT highway division.
- All non-functioning section of median barrier identified and marked.
- Appropriate contractor notified of damaged section within 24 hours.
- Repair work to begin "as soon as reasonably possible"

Ref: NCDOT Median Barriers Inspection and Maintenance Policy



Inspect Repairs

Inspection once the repairs are completed, as well as periodic inspection.

6.3 – Maintenance Tips

CDOT

- Before repairing guardrail, consider eliminating it.
- When barrier must be repaired, check the design.
- Keep large vegetation away from the guardrail.
- Watch for material buildup under and in front of the rail.
- Loosen cable turnbuckle in cooler weather, and tighten in warmer weather. <u>???</u> – to Spec

REF: NCDOT GUARDRAIL INSTALLATION AND/OR REAIR PROCEDURE TRAINING MANUAL. April 2000P

Session 6

Review Learning Outcomes

- Recognize how damaged barrier MAY BE assessed for maintenance response.
- Understand when a damaged barrier end treatment MAY no longer function.
- Effectively delineate/treatment of damaged hardware prior to repair.

